

PART 3 NAVIGATION SYSTEM

(b) Using advanced Search


The method for searching waypoints through the **Advanced(more)** button is the same method as searching destination.

📍 [Searching a Destination], page 3-13.


■ Deleting waypoints

① Press the **ROUTE** key.

② Press the **Edit waypoint** button.



③ Select the waypoint and press the **Delete** button.



④ Press the **Yes** button.



⑤ After deleting, press the **Done** button to complete. Guidance will restart after recalculating.

■ Re-ordering waypoints

① Press the **ROUTE** key.

② Press the **Edit waypoint** button.




③ Select the desired waypoint and use the **MOVE ▲**, **MOVE ▼** buttons to change the order.

④ Once re-ordering is complete, press the **Done** button to complete.

Guidance will restart after recalculating the route.


Setting detour distance

- 1 Press the **ROUTE** key.
- 2 Press the **Detour** button.



- 3 Select the desired detour range.
Guidance will restart after recalculating the detour route.



Voice Command

1. Press the  key on the steering wheel remote controller.
2. After the beep sound, say a command.
"Detour <1 or 2 or 5 or 10> miles"
"Detour <1 or 2 or 5 or 10> kilometers"

Setting avoid streets on route

- 1 Press the **ROUTE** key.
- 2 Press the **Avoid streets** button.



- 3 Select the desired streets to avoid ( avoid,  allow) and press the **Done** button to complete.
Guidance will restarted after recalculating.

Setup and Information

Setup menu screen and functions



Press the **SETUP** key on the control panel to display the setup menu screen.



a Main button : Changes to the input keyboard type, voice command feedback ON/OFF settings and system initialization can be made.

- b** Traffic Setup button : Sets whether to display traffic information on map, whether to provide upcoming traffic information voice guidance, and whether to display the detour route popup showing upcoming traffic information.
- c** Navigation button : Navigation related settings can be set.
- d** My Places button : The Address book, Home address, Favorite places, Previous destination can be edited.
- e** System Info button : The system version information can be viewed and system upgrades can be conducted.
- f** Voice Setup button : Adjusts the Navigation guidance volume.
- g** Help button : The help contents can be viewed.

- h** Display button : Adjusts the display setting.

Main setting

- 1 Press the **SETUP** key.
- 2 Press the **Main** button.



- 3 Select the desired changes and press the **Done** button to complete.

Setting keyboard for inputting letter


Press the desired keyboard type button. The selection will be highlighted.

■ Setting voice command feedback ON/OFF

Press the desired setting button.

■ Setting Language

1) Press the **Change** button.




2) Press the desired language.



3) Press the **Done** button to complete.

■ Initializing system

1) Press the **Factory default** button.



2) Press the menu desired for initialization.




3) Press the **Yes** button.

PART 3 NAVIGATION SYSTEM

Navigation setting

① Press the **SETUP** key.

② Press the **Navigation** button.



③ Select the desired changes and press the **Done** button to complete.

■ Setting units (mile/ km)


Select the desired distance unit.

■ Setting arrival time and distance display

Select the desired setting button.

■ Registering avoid area

① Press the **Avoid Area** button.




② Press the **Add new avoid area** button.




③ Set the start position of the avoid area and press the **NEXT** button.



④ Set the end position of the avoid area and press the **NEXT** button.




⑤ Press the **Done** button to complete.



Ⓒ If the Avoid area needs to be renamed, press the **Rename** button.



Ⓓ Rename the Avoid area and Press the **Done** button to complete.




Ⓔ Each time the **Avoid** button is pressed, the function will switch between avoid (🚫) or allow (📍).

Ⓕ Press the **Done** button to complete the setting.


PART 3 NAVIGATION SYSTEM

■ Editing avoid area


1) Press the **Avoid Area** button.



2) Press the **Edit avoid area** button.




3) Select the Avoid area button to edit.



4) If the Avoid area needs to be renamed, press the **Rename** button.



5) Rename the Avoid area and press the **Done** button to complete.




6) Each time the **Avoid** button is pressed, the function will switch between avoid(🚫) or allow(🚦).

7) Press the **Done** button once editing is complete.

■ Deleting avoid area


1) Press the **Avoid area** button.



2) Press the **Edit avoid area** button.



3) Select the **Avoid area** button to delete.




4) Press the **Delete** button.




5) Press the **Yes** button.

■ Deleting all avoid areas

1) Press the **Avoid area** button.



2) Press the **Delete all avoid area** button.



3) Press the **Yes** button.

PART 3 NAVIGATION SYSTEM

■ Setting Q.POI icons


① Press the **Edit Q.POI** button.



② Select the desired menu.



③ Select the desired category.



④ Select the desired sub category.



⑤ Press the **Done** button to complete.

i INFORMATION

Q.POI stands for Quick POI and refers to the function which turns POI icon display on or off on the map.

■ Setting estimate travel time

① Press the **Travel Time** button.



② Press the **<** or **>** button on the Residential, Main street, and Freeway controls to adjust the speed. Press the **Default** button to set the speeds to the default settings.

③ Press the **Done** button to complete the setting.

My places setting

■ Registering new address in address book

There are 3 ways to register a new address in the address book - (a) by DEST menu, (b) by registering address in address book, (c) from map scroll.

(a) by DEST menu

① Press the **DEST** key.

② Search through the desired method.

The search process is the same as the method for destination search.


📍 [Searching a destination], page 3-13.



③ Press the **Add to Address Book** button.



④ Press the desired address book (user) button.




⑤ Input the name and telephone information and press the **Done** button to complete.

📍 [Editing an address of address book], page 3-45.


(b) by registering in the address book

① Press the **SETUP** key.

② Press the **My Places** button.




③ Press the **Address book** button.




④ Press the desired address book (user) button.

PART 3 NAVIGATION SYSTEM



⑤ Press the **New Address** button.



⑥ Press the **Address** button to search the address.

📍 [Searching an address], page 3-13.

i INFORMATION


Press the **Store current position** button to input the address of the current position.

⑦ Input the name and telephone information and press the **Done** button to complete.

📍 [Editing an address of address book], page 3-45.

(c) from map scroll

① In the map screen, scroll the map to the desired position.



② Press the **Add to Address Book** button.




③ Press the desired address book (user) button.

④ Input the name and telephone information and press the **Done** button to complete.

📍 [Editing an address of address book], page 3-45.

■ Editing an address of address book


- ① Press the **SETUP** key.
- ② Press the **My places** button.



- ③ Press the **Address book** button.




- ④ Select the desired address book (user) button .



- ⑤ Select the desired address to edit.




- ⑥ Press the **Name** button to input the address name.



- ⑦ Input the address name and press the **Done** button to complete.



- ⑧ Press the **Address** button to search the address. The process is the same as the method for searching an address.
 [Searching an Address] , page 3-13.

INFORMATION


Press the **Store current position** button to input the address of the current position.

PART 3 NAVIGATION SYSTEM

9) Press the **Phone** button to input the phone number.



10) Input the phone number and press the **Done** button to complete.




11) Press the **Done** button to complete.

■ Deleting an address of address book

1) Press the **SETUP** key.


2) Press the **My places** button.



3) Press the **Address book** button.



4) Select the desired address book (user) button.



5) Select the desired address button to delete.



6) Press the **Delete** button.