


Operating menus during a call

Switching call to the mobile phone



① If you wish to switch the call to the mobile phone while talking on the car handsfree, press the **Private** button or press and hold (over 0.8 seconds) the **CALL** key on the steering wheel.




② As shown, the call will be switched to the mobile phone.


i INFORMATION

If you wish to switch the call to the car handsfree while talking on the mobile phone, press the **Use handsfree** button or press and hold (over 0.8 seconds) the **CALL** key on the steering wheel. The call will be switched to the car handsfree.

Activating Call waiting




① If another person calls while already on a call, the following screen will be displayed.



② Press the **Accept** button or the **CALL** key on the steering wheel to receive the incoming call by switching to the new caller.


Ending a call



① To end a call, press the **End** button or the **END** key on the steering wheel.



② The call will be ended.




③ To switch again to the other caller, press the **Switch** button or the **CALL** key on the steering wheel. The other call will be received and the previous call will switch back to call waiting.

i INFORMATION


End 버튼 또는 스티어링 휠의 **END** key 를 선택 시 현재통화 및 대기통화 모두가 종료 됩니다.

Phone Book

Making a call from the Phone book




1 Press the **Contacts** button on the PHONE screen.




2 The phone book list will be displayed.

i INFORMATION

Upon connecting a mobile phone, the phone book lists saved in the mobile phone will automatically be downloaded. The phone book download function may not be supported in some mobile phones.



3 Select the number you wish to call from the phone book list and press the **SEND** button.




4 The call will be made to the selected number.

i INFORMATION


When there are more than 2 numbers saved in one phone number list, if the list is repeatedly selected, the registered phone numbers will be displayed sequentially on the list.

Select the phone number you wish to connect by repeatedly selecting the phone number list and press the **SEND** button to make the call to the selected number.


Searching the Phone Book



1 Press the **Contacts** button on the PHONE screen.




2 Press the **Search** button on the Contacts screen.




3 Phone numbers can be searched by either **Search by name** or **Search by number**.

From the two methods, select the search method you wish to use.

■ Searching by name



4 Press the **Search by name** button on the Phonebook search screen.




5 Input the name you wish to search and press the **Done** button.




6 The search results will be displayed on the screen.


■ Searching by number



④ Press the **Search by number** button on the Phonebook search screen.




⑤ The search results will be displayed on the screen.



⑥ Input the phone number you wish to search and press the **Done** button.

Call History List


Making a call from Call history



① Press the **SEND** button on the PHONE screen or press the **CALL** key on the steering wheel.




② The call history list will be displayed. Select the number you wish to call from the call history list and press the **SEND** button.



③ The call will be made to the selected number.

Sorting call history




① The call history can be displayed by sorting the incoming calls, outgoing calls and missed calls.


② When pressing the **Dialled**, **Received**, or **Missed** button, the corresponding call history list will be displayed.

PART 5 BLUETOOTH HANDSFREE

■ Dialed number



■ Missed number



■ Received number



i INFORMATION

If there are no entries saved in the **Dialed**, **Received**, or **Missed** lists, the corresponding button will be inactive. Up to 20 entries can be saved in each list.

PHONE MUSIC

Before playing Phone music

Music saved in the mobile phone can be played in the car through Bluetooth audio streaming.

Phone music can be played only when a Bluetooth phone has been connected. To play phone music, connect the Bluetooth phone to the car system. For more information on connecting Bluetooth, please refer to the user's manual **[Pairing and Connecting a Bluetooth phone]**.

If the Bluetooth is disconnected while playing phone music, the music will be discontinued. The audio streaming function may not be supported in some mobile phones. Refer to www.0000 to check the list of Bluetooth compatible phones and other related information.

Only one function can be used at a time between the Bluetooth handsfree or Phone music function.

For example, if you convert to the Bluetooth handsfree while playing Phone music, the music will be discontinued.

Playing music from the car is not possible when there are no music files stored in the mobile phone.

Starting PHONE MUSIC



- 1 Repeatedly press the **CD/AUX** on the front panel or the **MDOE** key on the steering wheel to enter Phone music mode.

PART 5 BLUETOOTH HANDSFREE

i INFORMATION

Each press of the **CD/AUX** button on the front panel will change the function in the order of DISC → USB or iPod → AUX → Phone Music → DISC.

Each press of the **MODE** key on the steering wheel will change the audio mode in the order of FM1 → FM2 → AM → XM1 → XM2 → XM3 → DISC → USB or iPod → AUX → Phone Music → FM1.

It is not possible to enter Phone music mode if the mobile phone is not connected or if the audio streaming setting within Bluetooth handsfree settings has been set to **[Disable streaming audio]**.

For more information on audio streaming setting, please refer to the user's manual **[Bluetooth settings > Setting Audio streaming]**.




② The Phone music screen is displayed.

i INFORMATION

While music saved in the mobile phone will automatically begin playing after converting to the Phone music screen, this music player function may not be supported in some mobile phones.


If music does not begin playing even after converting to the Phone music screen, try starting the music directly from the mobile phone.

Phone music screen layout



- ① Information Bar : displays information for the currently playing song.
- ② File Down button : plays the previous song.
- ③ Play/Pause button : Plays/pauses the song.
- ④ File Up button : plays the next song.
- ⑤ Sound button : sets the FAD/BAL and BAS/MID/TRE.

Selecting Phone music files



- ① Press the **⏮**, **⏭** buttons on the Phone music screen or the **SEEK ▲**, **TRACK ▼** keys on the system.
The previous or next song will be played each time the button or key is pressed.

i INFORMATION

The file selection function may not be supported in some mobile phones.

PART 5 BLUETOOTH HANDSFREE

Bluetooth settings


Pairing and connecting a mobile phone

For more information on pairing and connecting a mobile phone, please refer to [Pairing and Connecting a Bluetooth phone].

Setting mobile phone auto connect priority

i INFORMATION


After turning on the car ignition and the system is booted up, the Bluetooth connection between the car system and mobile phone is automatically made. The Bluetooth connection will be conducted in the order of mobile phone priority. The auto connect priority will be supported only for previously paired mobile phones.



1 Press the **Settings** button on the PHONE screen.



2 Press the **Priority** button on the Settings screen.




3 The paired mobile phone list and the mobile phone connection priority will be displayed.


When wishing to change the priority order, select the mobile phone from the list and use the **↑**, **↓** buttons to change its priority.

Press the **Done** button to save the changed mobile phone priority.

Setting Handsfree volume



1 Press the **Settings** button on the PHONE screen.




2 Press the **Volume** button on the Settings screen.

i INFORMATION

The Bluetooth handsfree volume can be adjusted only when a mobile phone has been connected.

The **Volume** cannot be set if no mobile phone has been connected.



3 Use the **←**, **→** buttons to set the desired volume on the Phone volume screen. Press the **Done** button to save.

i INFORMATION


While on a call, turning the **POWER** knob to the left/right or pressing the **AVOLV** button on the steering wheel will also adjust the call volume.

If the call volume is set too high, the loud incoming call bell may cause a traffic accident.

As a result, if the volume level is set higher than the standard volume level, the volume will automatically be changed to the standard volume level.

PART 5 BLUETOOTH HANDSFREE


Setting Audio streaming



1 Press the **Settings** button on the PHONE screen.



2 Press the **Streaming audio** button on the Settings screen.



3 Streaming audio setting is selected.

INFORMATION


Enable streaming audio: Repeatedly press the **CD/AUX** key or the **MODE** key to enter Phone music mode. Phone music can be played through Bluetooth audio streaming.
Disable streaming audio: Even if the **CD/AUX** key or the **MODE** key is repeatedly pressed, will not enter Phone music mode. Phone music through Bluetooth audio streaming is not supported.

Advanced settings

Bluetooth advanced settings can be changed. Enter advanced settings through the following way.




1 Press the **Settings** button on the PHONE screen.



2 Press the **Advanced setup** button on the Settings screen.


INFORMATION

For safety reasons, operation of Advance setup is not possible when the vehicle is in motion. Please park in a safe place to make changes to Advanced setup.



3 The Advance setup screen will be displayed. In Advance setup, the following four settings can be made.

Searching and modifying my device properties



4 Press the **Device information** button on the Advance setup screen.



5 Displays the Device information such as the name and address of the car system. To modify the device name, press the **Change name** button.




6 Use the key pad to input the Device name you wish to modify.




7 After inputting is complete, press the **Done** button to save.

PART 5 BLUETOOTH HANDSFREE

■ Changing passkey



④ Press the **Change passkey** button on the Advance setup screen.




⑤ Once the Change passkey screen is displayed, input the desired passkey and press the **Done** button.


i INFORMATION

The passkey is a 4-digit authentication code used for a Bluetooth connection between the mobile phone and car system. The default passkey is set to 1234.

■ Deleting all paired phones



④ Press the **Delete all paired phones** button on the Advance setup screen.




⑤ A pop-up asking whether you wish to delete all paired phone will be displayed. Press the **Yes** button to delete all paired phones and the **No** button to cancel.



⑥ If **Yes** button is pressed, all currently paired phones will be deleted.

■ Initializing Bluetooth handsfree




④ Press the **Restore factory settings** button on the Advance setup screen.



⑤ A pop-up asking whether you wish to initialize the Bluetooth handsfree will be displayed. Press the **Yes** button to initialize the Bluetooth handsfree system and the **No** button to cancel.

i INFORMATION

Upon initializing the Bluetooth handsfree, the entire paired phone list will be deleted and all Bluetooth related settings will be restored to factory state.



⑥ If **Yes** is pressed, the Bluetooth handsfree settings will be initialized.

PART 5 BLUETOOTH HANDSFREE

Important information

About pairing mobile phones

Q. I cannot search for mobile phones through the car system. What is the cause?

A. Check to see whether the mobile phone you wish to connect supports Bluetooth function. If your mobile phone supports Bluetooth, check to see that whether the Bluetooth settings in the mobile phone have been set to hidden state or if the Bluetooth power has been turned off. If the device has been set to hidden, release the hidden state and if the Bluetooth power has been turned off, turn the power ON and try searching again.

Q. What is the difference between pairing a mobile phone and connecting a mobile phone?

A. Through a two-way passkey between the car system and mobile phones, up to 5 mobile phones can be paired with the car system. The paired mobile phone will remain paired with the car system until the user deletes it manually.

In addition, the call history lists and phone number books saved in each mobile phone will also be maintained until the paired phone is deleted. For more information on pairing mobile phones, please refer to the manual **[Pairing and Connecting a Bluetooth phone > Pairing a mobile phone]**.

Connect a mobile phone to Bluetooth by selecting the desired mobile phone from the paired phones. Within the car system, only one Bluetooth phone can be connected at one time. For more information, please refer to the manual **[Pairing and Connecting a Bluetooth phone > Pairing a mobile phone]**.

Q. What is a Passkey?

A. A passkey is an authentication code used for two-way authentication of the car system and the mobile phone.

Only 4-digit numbers can be used as passkeys. Passkeys are registered only once when pairing the phone number for the first time. The factory-set passkey is 1234.

About making/answering phone calls

Q. How can I answer a call?

A. When you receive an incoming call, press the **CALL** key on the steering wheel or the **Accept** button on the PHONE screen to answer. To reject the incoming call, press the **END** key on the steering wheel or the **Reject** button on the PHONE screen.

Q. What should I do if I am talking on the Handsfree but wish to switch the call to the mobile phone?

A. To switch the call to the mobile phone, press the **Private** button on the PHONE screen or press and hold (over 0.8 seconds) the **CALL** key on the steering wheel. If you wish to switch the call back to the car handsfree, press the **Use handsfree** button on the PHONE screen or press and hold (over 0.8 seconds) the **CALL** key on the steering wheel.

About Bluetooth device environment

Q. What is the range for Bluetooth wireless connection?

A. The wireless connection range is within 10 meters.

Q. How many mobile phones can be paired?

A. It is possible to pair up to five phones with the car system.

Q. What is the reason why the call quality deteriorates?

A. First, check to see the signal strength of the mobile phone. The call quality may deteriorate when the signal strength is low. Call quality may also deteriorate if metal objects, such as drink cans, are placed near the mobile phone.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum 20 cm between the radiator and your body. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter unless authorized to do so by the FCC.

IC Warning

Operation of this device is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.