

# FOB-4F16 Fob Smart Key

## User Manual

---

### OUTLINE

#### 1. How to use FOB-4F16

- Fob-4F16 is Remote Keyless System.
- This unit controls door lock/door unlock/tailgate open/panic wirelessly.

#### 2. Introduction of Transmitter (FOB-4F16)

- Transmitter has 4 buttons.
- Transmitter use the battery (CR2032)
- Frequency is 433.92MHz

### GENERAL DESCRIPTION

#### PRIMARY FUNCTION

- Remote door lock/unlock/tailgate open/panic – Operation

### Manual

#### 1. LOCK Button

- If the LOCK button is pushed, then TRANSMITTER sends the LOCK Data.

#### 2. UNLOCK Button

- If the UNLOCK button is pushed, then TRANSMITTER sends the UNLOCK Date.

#### 3. TRUNK Button

- If the TAILGATE button is pushed, then TRANSMITTER sends the TAILGATE OPEN Data.

#### 4. PANIC Button

- If the PANIC button is pushed, then TRANSMITTER sends the PANIC Data.