

# FOB-4F19 Fob Smart Key

## User Manual

---

### OUTLINE

#### 1. How to use FOB-4F19

- FOB-4F19 is Remote Keyless System.
- This unit controls door lock/door unlock/tailgate open wirelessly.

#### 2. Introduction of Transmitter (FOB-4F19)

- Transmitter has 4 buttons.
- Transmitter use the battery (CR2032)
- Frequency is 433.92MHz

### GENERAL DESCRIPTION

#### PRIMARY FUNCTION

- Remote door lock/unlock/tailgate/panic open – Operation

### Manual

1. LOCK Button
  - If the LOCK button is pushed, then TRANSMITTER sends the LOCK Data.
2. UNLOCK Button
  - If the UNLOCK button is pushed, then TRANSMITTER sends the UNLOCK Date.
3. TAILGATE Button
  - If the TAILGATE button is pushed, then TRANSMITTER sends the TAILGATE OPEN Data.
4. Panic Button
  - If the TAILGATE button is pushed, then Horn of vehicle will be activated.