

## **User Manual----HandyCase™**

### **Product Specifications**

Bluetooth BLE4.0

Micro USB charging port

Operating Range: Up to 30 feet (10 meters)

Use time: Up to 2 days

Charging time: About 2 hours

Box Contents: HandyCase™, Micro USB Cable, User Manual

Thank you for using the HandyCase™ of HandScape Inc. In order to enhance your experience with HandyCase™, detailed instruction is provided below. Before using this product, please read the user manual carefully. In case of any printing error or typo, we apologize for the inconvenience. We reserve the right for final explanation.

### **Highlight**

The most amazing part of your product is when paired with one of our applications, you are able to see your finger positions as if your screen was transparent! The HandyCase™ will allow you to interact with your phone in a whole new way and open up even more control possibilities.

The application starts by showing touch points. When 4 fingers touching the case, our multi-patented technology will show all your fingers and automatically figure out it's your left or right hand.

### **Connect HandyCase™ to IOS device**

1. Enable your IOS device's Bluetooth.
2. Power on HandyCase™, the red light is on and the blue LED will blink signaling it's on (means searching for bluetooth).
3. Open compatible HandyCase™ app, the HandyCase™ will automatically connect with Bluetooth. (Please search HandScape® in App Store to download apps)
4. The blue LED will be off after successfully connecting after 5 seconds.
5. Now enjoy your HandyCase™.

### **Check Battery**

After HandyCase™ connected to your IOS devices, press the power button again, the LED will display battery status. A green LED indicates that battery power remaining is more

than 25%. A red LED will indicate that the device has less than 25% battery power remaining and that the case need to be charged.

### **Charge HandyCase™**

Use microUSB cable to charge the HandyCase™ battery.

Charging will be indicated by a blinking red LED. When the case is fully charged, the LED will turn green.

After the case is fully charged, please remove the cable.

### **Power off HandyCase™**

When HandyCase™ is on, press power button for 3 seconds, then HandyCase™

will be off. Or HandyCase™ will also be off automatically when staying in searching

Bluetooth status for more than 30 seconds.

HandScape® and HandyCase™ mentioned in the user manual are all trademarks for HandScape Inc.

Apple® and iPhone® mentioned in the user manual are all registered logo for Apple Inc.

### **Company Information**

HandScape Inc.

939 Corporate Way, Fremont, CA 94539 USA

[www.handscape.com](http://www.handscape.com)

### **FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.