

材质：157G双铜，规格：单页尺寸，90*150 双面彩色印刷，折页



User Manual

Arteck HB305-4B Bluetooth® Touch Keyboard





 2 Years Warranty Claim: support@artek.com

Welcome

Thank you for choosing this Arteck HB305-4B bluetooth touch keyboard. To ensure optimum performance and safety, please read these instructions carefully before operating this product. It is strongly recommended you keep the manual for future reference.

Statement

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ARTECK is under license. Other trademarks and trade names are those of their respective owners. "Windows" is a trademarks of Microsoft Corporation in the United States and/or other countries.

Product Specifications

Bluetooth Specification	Bluetooth 5.1
Operating Range	Up to 10 Meters
Modulating System	GFSK
Operating Voltage	3.0-4.2V
Operating Current	< 2.5mA
Standby Current	0.3-0.5mA
Sleeping Current	< 40uA
Charging Current	> 200mA
Standby Time	> 100 days
Charging Time	> 2 hours
Input Voltage	5V
Uninterrupted Working Time	> 64 hours (backlight off)
Battery Style	Rechargeable
Lithium Battery Specification	3.8V/290mAh
Key Strength	50-80g
Key Life	3 million strokes
Operating Temperature	-10 - 50°C

Package Contents:
Arteck HB305-4B Bluetooth Touch Keyboard *1
USB-C charging cable *1
User manual *1

Getting Started Guide
1. Product Overview



1. Power On / Off Switch

① Lights up green for about 4 sec when being turned on.

② Press the key  the power indicator will blink green to show the power meter. When the keyboard is in low battery, the indicator will be blinking green.

③ **Charging Indicator:** The indicator will be red while recharging the keyboard, will become solid green when the keyboard is full charged.

④ **Bluetooth Pairing Indicator:** Press Fn+C, the indicator will blink blue and the keyboard is in pairing mode. Once connected, the light will be off to save power.

⑤ **CAPS Lock Indicator:** Green light on when CAPS on.

⑥ **Touch Pad**

⑦ **Mouse Left Button**

⑧ **Mouse Right Button**

⑨ **USB-C Charging Port:** Used for charging the keyboard.

2. Backlight

This keyboard has built-in colors backlight and 2 brightness level. After the keyboard is connected, press Fn+Space bar (shown ) to turn on the back light, press again to enhance the brightness, press the 3rd time to turn the back light off. When the back light is on, press Fn+Space bar+up (shown ) to change the back light colors.

3. Function Keys

	Fn Lock		Mute		Volume down
	Volume up		Previous Track		Play / Pause
	Next Track		Switch Windows		Brightness down
	Brightness up		Project To		Print Screen
	Battery Meter	Fn+C	Bluetooth Pairing	Fn+Space Bar	Light On / Enhance Light / Light Off
	Switch Backlight Colors	Fn+Right Ctrl	Full Backlight Function (Turn Backlight Function On)		

Note: Brightness down and brightness up can only work on the computer and cannot work on the TV.

Fn Lock Key

The default function of the F1-F12 will be the above table functions. If you press the Fn lock key, the function will change to be F1-F12. The above functions all work well in Windows. Some of the function might not work in Android or iOS due to the limit of the system.

4. TrackPad

The keyboard has built-in trackpad which allows you to work more productively. You can press Fn+right Ctrl to use either in full function or semi function. Press Fn+right Ctrl to turn off the full function mode and press again to turn on full function mode.

In half function mode, the trackpad will only work to move the cursor or scroll up / down.

Other functions are not available, if you wish to use all the function, please make sure that the trackpad is in full function mode.

- One finger: Move one finger to move the cursor.
- Two fingers: Swipe up or down with two fingers will scroll up / down.
- Three fingers: Swipe left or right with two fingers will scroll left or right.
- All three fingers functions are available in full function mode only.

Three fingers: Swipe up or down with two fingers will scroll up / down.

Swipe left or right with two fingers will scroll left or right.

Swipe left or right and hold, the recent apps will come up and move the fingers to the app you want.

4. Left button and right button. Besides tabbing on the trackpad, there're left button and right button. Left button will click as the left button of the mouse, right button will click as the right button of the mouse.

4. Steps of Pairing the Keyboard with Your Device

Step 1: On the keyboard, slide the ON/OFF button on. The indicator light will illuminate green for 4 seconds and then turn off to save power.

Your keyboard is still on.

Step 2: Press Fn+C key, the bluetooth indicator light will blink blue.

Step 3: On your device, select: Setting - Bluetooth - On.

Step 4: Your device will display "Bluetooth 5.1 Keyboard" as an available device.

Step 5: Select "Bluetooth 5.1 Keyboard" on your device, the keyboard is paired to your device now.

Step 6: Press Fn+space bar to turn on the backlight if you wish.

Notice

If you are not able to connect the keyboard to your device, or if you have any problem or questions using the keyboard, please kindly contact with support@artek.com for assistance. We will solve your issue with 100% satisfactory solution.

Touch Pad

When the keyboard can be typed, the touch pad should be working as well. If the touch pad is not working for clicking or 3 fingers function, please press Fn+right Ctrl to turn on / off the touch pad full function mode.

Charge the Battery

Press battery meter key, the power indicator will blink to show the battery meter. Blinking 1 time means the battery is around 25%, blinking 2 times means the battery is around 50%, blinking 3 times means the battery is 75%, blinking 4 times means the battery is full.

When you use the keyboard, the power indicator light keep blinking, it means the battery is low, you need to charge the keyboard with below steps:

- Plug the USB-C charging cable into the keyboard.
- When you use the keyboard, the power indicator light keep blinking, it means the battery is low, you need to charge the keyboard with below steps.
- Charge for 1-3 hours, or until the charge light become solid green.

Troubleshooting

- Make sure the keyboard is on (slide switch in "ON" position).
- Make sure the keyboard is in operating distance (within 10 meters).
- Ensure the battery storage has power.
- Make sure the Bluetooth in tablet / PC / smartphone is on.
- Ensure wireless keyboard have already match with bluetooth.
- If you cannot find "bluetooth 5.1 keyboard" in the "add new devices", it might be because the "bluetooth 5.1 keyboard" in the "bluetooth" and other devices' list, you can delete it or click "forget this device" and "add new device" again.

Caution:

- When not in use for a prolonged period, it is recommended that you turn off the keyboard to lengthen battery life.
- When the power status light flash, it is recommended that charging the keyboard in less than 2 hours.

Energy-saving Sleep Mode

Keyboard's long life battery lasts for several months of normal use. The keyboard will go into sleep mode if left on and not being used; press any key and wait a second or two to bring it out of sleep mode.

Warranty

Our company provides customers with a warranty of 24 months from the date of purchase.

Contact Us

For any inquires or comments concerning our products, please send an email to support@artek.com, and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a replacement or refund by submitting a request to support@artek.com.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.