


# User Manual

## HB336



Thank you for using the keyboard provided by us, please read this manual carefully before using this product.

### Product Overview



Keyboard indicator	Indicator color	Indicator status
Power indicator	Red	The red light turns on for 3 seconds and then off.
Low voltage indicator	Red	When voltage lower than 3.2V, the red light will flash. When the voltage lower than 3.0V, it power off automatically.
Charging indicator	Red/Green	This red indicator light starts on when turn to power for charge. The charging mode will flash once for 1 second and will stop when the connection is successful. If the LED is not passed, the keyboard will enter the dormant state.
Bluetooth pairing indicator	Blue	The coding-matching data will flash once for 1 second and will stop when the connection is successful. If the LED is not passed, the keyboard will enter the dormant state.
Caps lock indicator	Blue	The green light is always on when entering the uppercase state, and the light is off when entering the lowercase state.

### Keyboard Connection Steps

Step 1. Turn on the power switch of the keyboard. Short press FN+( ), the Bluetooth code matching indicator becomes slow flashing blue, enters the pairing state.  
 Step 2. Open the Bluetooth of the device to search, the Bluetooth of the device can be searched by itself or manually to find the keyboard name (Bluetooth name: Bluetooth Keyboard), and click to connect.  
 Step 3. It will show that it has been successfully connected, and the Bluetooth code matching indicator will go out.

### Function Key



Icon	Win	iOS	Android
Home	NA	Home	NA
Search	Search	Search	Search
Next track	Next track	Next track	Next track
Previous track	Previous track	Previous track	Previous track
Mute	Mute	Mute	Mute
Volume +	Volume +	Volume +	Volume +
Volume -	Volume -	Volume -	Volume -
Screen lock	Screen lock	Screen lock	Screen lock
Brightness +	Brightness +	Brightness +	Brightness +
Brightness -	Brightness -	Brightness -	Brightness -
Touchpad switch	Touchpad switch	Touchpad switch	Touchpad switch

### Touchpad Function

Icon	Win 10	iOS	Android
Single finger click	Left mouse button	Left mouse button	Left mouse button
Single one finger	Move the cursor	Move the cursor	Move the cursor
Steady click and hovering with one finger	Left click to select the target and drag	Left click to select the target and drag	Left click to select the target and drag
Two-finger click	Right mouse button	Right mouse button	Right mouse button
Two-finger click	Right mouse button	Right mouse button	Right mouse button
Two-finger scroll	Scroll bar moves vertically	Scroll bar moves vertically	Scroll bar moves vertically
Two-finger scroll	Scroll bar moves horizontally	Scroll bar moves horizontally	Scroll bar moves horizontally
Three-finger click	Enlarge	Enlarge	Enlarge
Three-finger click	Enlarge	Enlarge	Enlarge
Three-finger click	Enlarge	Enlarge	Enlarge

### Touchpad Function

Gesture Diagram	iOS 14.1	Win 10	Android
Open the APP window (Double-click HOME)	Open the task browser window	NA	NA
Zoom in	Zoom out	Zoom out	Zoom out
Application window switching (Win+Tab)	Application window switching (Win+Tab)	Application window switching (Win+Tab)	Application window switching (Win+Tab)
Application window switching (Win+Tab)	Application window switching (Win+Tab)	Application window switching (Win+Tab)	Application window switching (Win+Tab)
Make mouse button	Open Cortana	NA	NA
Back to the desktop	NA	NA	NA
Screen lock	Open Action Center	NA	NA

### Input Method Switching Method

iOS system: Caps+Space or Ctrl+Space or Win+Spacebar (Because the iOS system version is different, the switch is also different, you can try the above methods)  
 Android system: Shift+Space or Ctrl+Space or Win+Spacebar (Because the system version is different, the switch is also different, you can try the above methods)  
 Windows system: Win+Shift  
**Charging**  
 When the voltage is low, the indicator light flashes red quickly (below 3.0V automatically goes out), then you need to charge the keyboard.  
 1) Connect the B end of the original Type-C cable to the keyboard charging port.  
 2) Connect end A of the original USB cable to the power adapter or the USB port of the computer.  
 3) It keeps red when charging, until the battery is saturated and the indicator light turns off.  
**Notice:**  
 1) In order to obtain a longer battery life, charge the keyboard only when the keyboard power light flashes.  
 2) The original power cord must be used for charging during working conditions. If other data lines are used for charging during work, garbled codes and malfunctions may occur.  
**Keyboard Specifications**

Bluetooth Specification	Bluetooth 5.0
Operating Range	Up to 10 meters
Modulation System	FSK

### Safety Caution

- Warning: It can cause fire, electric shock, damage of keyboard system if display the safety notes.
- Dangerous (be careful of highly dangerous)
- Warning (be careful of not dangerous)
- Caution (slight dangerous should be noted)
- 2) Do not Microwave the keyboard.
- 3) Do not place heavy object on the keyboard.
- 4) Do not force or dislodge the keyboard.
- 5) Keep away from oil, chemical or any other organic liquid.

### 触摸板功能

FCC Warning:  
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 ? Reorient or relocate the receiving antenna.  
 ? Increase the separation between the equipment and receiver.  
 ? Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 ? Consult the dealer or an experienced radio/TV technician for help.  
 Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
 RF Exposure Statement  
 This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0 centimeters between the radiator and your body.