



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the

party responsible for compliance could void the user's

authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:


(1) this device may not cause harmful interference, and(1)

(2) this device must accept any interference received,

including interference that may cause undesired operation.

Keyboard Mode Switch Method

After 🛜 🚯 1 🚱 2 connected, short press the channel button to switch devices between Bluetooth mode and 2.4GHz wireless mode.



When the battery of the keyboard is very low, the working

channel 🝙 🚱 😡 indicator light will flash until the keyboard turns off, please recharge the keyboard at this time to make sure the keyboard can work properly. When the battery is too low, delay or slow response will appear while typing.

Keys	Windows OS	Android OS	iOS	Mac OS
☆	Light -	Light -	Light -	Light -
✻	Light +	Light +	Light +	Light +
合	Home Page	Back to Desktop	Back to Desktop	NA
Ð	Switch apps(not working for iphone)	Switch apps	Switch apps	Switch app
♪	back in web browse	Return	N/A	N/A
٩	Search	Search	Search	Search
Ы	Previous	Previous	Previous	Previous
DII	Play & Pause	Play & Pause	Play & Pause	Play & Paus
Ы	Next Track	Next Track	Next Track	Next Track
¢×	Mute	Mute	Mute	Mute
圦)	Volume Down	Volume Down	Volume Down	Volume Dov
く))	Volume Up	Volume Up	Volume Up	Volume Up
	Screenshot	Screenshot	Screenshot	Screensho
	Calculator	N/A	N/A	N/A

Safety Instructions

▲ Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed b Danger (high risk) x Warning (Moderate risk) ▲Note (Poor risk)

- ×1. Away from edge tool
- 2. Away from microwave radiation source
- X 3. Do not place heavy objects on this product ×4. No shocking and bending
- 5. Away from oil, chemical, or organic solvents

