Showmo Mobile Application Manual (Android version)

1. Installation and connection

1.1 Installation considerations

• do not place a liquid container (such as a bottle, electronic equipment, metal items, etc.) around the device.

• check the power supply voltage to prevent the occurrence of voltage mismatch caused the device damage.

- equipment to avoid the installation in the environment of violent vibration.
- the dust on the circuit board will cause a short circuit in the moisture.

1.2 Connected power supply

(1) Firstly, you should screw the device into an E27 screw lampholder, the device will automatically turn on when you power up.

(2) The electric light is red when you power up, after a few seconds the device starts, the red light flashes with welcome language.

(3) Then you should use the showmo mobile application to add device, detailed steps to see the following video camera mobile client.

Note: If the power supply is not normal, it will lead to show camera can not work, even damage show camera, please use a stable power supply.

2. Camera mobile client usage instructions

2.1 Download Software

Way1: Search "showmo" in

Google play

and install to mobile phone.

(Require android OS above V4.1)

Way2: Scan the QR code on the packing box to download to mobile phone locally.

2.2 Registration

User needs to register a user account before experiencing the feature IPC365.

Please tap Register and finish the registration step by step.

Please use your email address to create a new account. You will receive a verification code in your mailbox and enter it to finish the registration. After you enter your password, you can login to the account.

| | ∠ Back Register | < Back Register |
|----------------------------------|------------------------------------|-----------------------|
| | | |
| Account(Mobile/Email) | Account(Mobile/Email) | Password |
| <pre>Password(6-18 digits)</pre> | Verification code(6 digits) Obtain | Password(6-18 digits) |
| Remember password Demo camera > | Next | Confirm password |
| Login | | Confirm |
| Register Forgot password? | | |
| | | |
| | | |
| Manta Antonia | Maila Arminer | Man An and a frank |


2.3 Retrieve Password

Once you forgot the password, please tap Forgot password? to jump to the reset page and enter your user account and new password. You will find the verification code in your mailbox and need to enter it to finish the modification.

| Demo camera > | | Back Reset password |
|--|----------------|---------------------|
| O Account | Account Obtain | Password |
| Password (6-18 digits) ● ✓ Remember password | Next | Confirm password |
| Login | | Confirm |
| | | |
| Forgot password? | Marta Marta | Maton Soundally |

2.4. Add camera

When the camera's red light is blinking with the sound "Welcome to showmo,



please enter the password for wifi", you can tap


Please turn up the volume of the volume of the mobile phone, and close to camera, until you hear the ding-dong tone, which means the camera has received setup information.

After you enter the password of wifi, you need to wait for a few seconds.

When you heard indicating sound"Ding-dong", please wait the camera connecting to network;

When you heard "Wrong password, please re-enter", please get back to re-enter the right password;

When you heard "Camera ready", please wait until automatically jump to name box.



2.5 Preview

After adding a new camera, it will automatically turn to live preview, and you



to live preview.

It supports the panorama 3D function, touch and slide the live view screen to 3D operation. And it also supports the digital zoom, rotation operation.



Connecting



Preview image





| lcon | Feature |
|------|-----------------------------------|
| | Stop preview |
| | SD card playback |
| | Sound switch button |
| HD | Mode selection: HD, SD, automatic |
| -Ò. | LED light control button |

2.6 Remote playback



When SD card is inserted in the camera, user can use the APP to playback the video

footage. Tap • and choose the time period to

playback with icon **9**.

2.7 Password modification

| Enter ye passwo | our account and new | / |
|--------------------|---------------------|-----|
| | | |
| | count | |
| 010 | d password | 0 |
| 🕂 Nev | w password | |
| ⊕ Co | nfirm new passwo | ord |
| | Modify | |
| | | |
| | | |

Tap A and choose "Modify password" to

modify the user's password. You will be required to enter your old password to modify successfully.

2.8 Setting



Tap it to set camera and APP. You can make camera setting and APP setting according to your preferences. You can rename or delete the camera, turn on/off the alert switch and voice prompt, and you can know MAC address IP address APP version.....at camera information. And you can tap "More" check upgrade and give us feedback.

2.9 Quit & Change User

Tap A and choose "Switch account" to log out and return to the login page,

choose "Quit" to quit the program.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

 \Box Reorient or relocate the receiving antenna.

□ Increase the separation between the equipment and receiver.

□ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

□ Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body