
## **HB031 Bluetooth Speaker Instruction Manual**

Thank you for choosing our wireless Bluetooth SpeakerlBefore you use the speaker make sure to completely charge the device, and become familiar with the Bluetooth function on your paired devices.

#### How to use the Bluetooth Speaker

#### The General Features



- 1 Volume Knob
  - (1). Volume control: Long-turn left or right the knob to reduce or add volume
  - (2).Last and next music control: short-turn left or right the knob to change to the previous or next track
  - (3). Short press inwards to stop playing and short press again to play.
  - (4).Phone call control: Long-press inwards to reject the call;short-press inwards to answer call
- 2. On/Off Button:

Bluetooth mode: Pull the switch to "Bluetooth" to enter into Bluetooth mode. Aux-in mode: Pull the switch to "MP3" to enter into Aux-in mode. FM mode: Pull the switch to "MP3" and long press inwards the knob "1" to enter into FM mode.

- 3. Status ligth.
- Charging port: Play the provided cable into this port and other side (USB) to DC 5V power source.
- 5. TF card playing: After inserting the TF card, the product will get into TF card the product will playing mode. It can ready to play music with MP3 or WAV format.

#### Pairing with Mobile Device

The speaker needs to be connected with a Mobile Device to use the wireless Bluetooth function. If the mobile device has paired with a Bluetooth speaker previously, the match will finish automatically.

- Active Bluetooth mode on mobile device and turn speaker ON.Speaker will automatically enter pairing mode.
- Search for the Bluetooth Speaker from your mobile device
- Mobile device will display the Bluetooth Speaker as"HB031" in list of available devices. Select pair.
- Follow instruction on mobile device to complete pairing. If pass-code is needed, enter "0000"
- After the Mobile Device and Bluetooth Speaker connect, sound can be controlled from the Volume Buttons(1)

#### **Technology Specifications**

### **Speaker Specification**

Speaker	phi 40 external magnetic 4 Ω 3 w
Frequency response	100-20KHZ
Signal to noise ratio	70db
Bluetooth Version	2.1+EDR
Output	2.5W
Play time	1-3 hours, due to the volume
Size	60*50 mm

#### Safety Information:

- Avoid contact with liquids and damp areas
- · Charging battery fully before use
- · If speaker is damaged seek professional consultation, do not repair
- Do not take speaker apart to avoid electrocution
- Keep speaker away from flame
- · Keep out of reach of children

# **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.