


# Bluetooth Speaker Instruction Manual

Thank you for choosing our wireless Bluetooth Speaker! Before you use the speaker make sure to completely charge the device, and become familiar with the Bluetooth function on your paired devices.

## How to use the Bluetooth Speaker

### The General Features



#### 1. On/Switch

Switch the " **OFF/ON** " button to power the device ON or OFF

#### 2. Micro USB Slot:recharge by DC5V

3. TF Card Slot:After inserting the TF card,the Speaker will get into TF card playing mode.It is ready to play music.

#### 4. PREV/Volume Less Button

Click the" **-** "button to play the previous track.Hold in the " **-** " to lessen the volume

#### 5. Play/Pause Button & Hands free

When speaker connected with a mobile phone, short press to play or pause music.When the call coming, short press to answer the phone, and short press again to hang up the phone. When the call coming,long press to reject the call.

#### 6. NEXT/Volume Plus Button

Click the" **+** "button to play the next track.Hold in the " **+** " to add the volume

## Pairing with Mobile Device

The speaker needs to be connected with a Mobile Device to use the wireless Bluetooth function. If the mobile device has paired with a Bluetooth speaker previously, the match will finish automatically.

- Active Bluetooth mode on mobile device and turn speaker ON. Speaker will automatically enter pairing mode.
- Search for the Bluetooth Speaker from your mobile device
- Mobile device will display the Bluetooth Speaker as "BT speaker" in list of available devices. Select pair.
- Follow instruction on mobile device to complete pairing. If pass-code is needed, enter "0000"
- After the Mobile Device and Bluetooth Speaker connect, sound can be controlled from the Volume Buttons (4,6)

## Technology Specifications

Parameters	Index
Bluetooth Version	2.1+EDR
Communication distance	10 M
Frequency response	100HZ-20KHZ
Horn Output power	3W
Playing time	3-4hours
Size	85MM×75MM×68MM

## Safety Information:

- Avoid contact with liquids and damp areas
- Charging battery fully before use
- If speaker is damaged seek professional consultation, do not repair
- Do not take speaker apart to avoid electrocution
- Keep speaker away from flame
- Keep out of reach of children

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.