


Front

Bluetooth speaker Instruction Manual

Thank you for choosing our wireless Bluetooth speaker! Before you use the speaker make sure to completely charge the device, and become familiar with the Bluetooth function on your paired devices.

How to use the Bluetooth speaker

The General Features



1. Control panel:
 - (a). On/Off Button: Long press "⏻" to power on or off the speaker.
 - (b). Next/Volume Plus Button: Long press "+" to add volume.
Short press "+" to play next music track.
 - (c). PREV/Volume Less Button: Long press "-" to lessen volume.
Short press "-" to play previous music track.
 - (d). Play/Pause Button: Short press "⏮" to play or pause the music.
(When using it for hands-free phone calls, press "☎" to answer or hang up the call.)
2. Status light
The status light will flash blue when the speaker Bluetooth is ready to pair. Once paired the light will stop flashing.
The status light will be red when charging. It turns blue when speaker is fully charged.
3. Microphone
When using the speaker for hands-free calls, the Mic will pick up your voice so the other caller can hear your voice.
4. Light control: Gently touch the net to control the light brightness: Maximum, Medium, Minimum, or turn on/off the light.

Back

5. Charging interface

Plug the provided charging cable into this port and other side (USB) to DC 5V power source.

6. AUX-IN/Reset interface

Plug the provided audio cable into this port and the other side into the music source to play music.

There is a reset button inside of it. To restart the speaker, please use a cylinder object insert into it, and press the reset button.

Bluetooth Pairing Instructions

- Active Bluetooth mode on mobile device and turn speaker ON. Speaker will automatically enter pairing mode.
- Search for the Bluetooth Speaker from your mobile device
- Mobile device will display the Bluetooth Speaker as "HB096" in list of available devices. Select pair.
- Follow instruction on mobile device to complete pairing. If pass-code is needed, enter "0000".
- After the Mobile Device and Bluetooth Speaker connect, sound can be controlled from the Buttons "+", "-", and "⏮".
- If the mobile device has paired with a Bluetooth speaker previously, the match will finish automatically.

Technology Specifications

Bluetooth version	4.0
Frequency response	120-20kHz
Play time	6 hours, due to the volume
Size	80 mm*80mm*114 mm

Safety Information:

- Avoid contact with liquids and damp areas
- If speaker is damaged seek professional consultation, do not repair
- Do not take speaker apart to avoid electrocution
- Keep speaker away from flame
- Keep it away from children

Front

Bluetooth Speaker Instruction Manual

WARNING

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.