



Quick Start Guide for iOS Setup

Before you begin your SmartCam Setup, please:

- ✓ Have your SmartCam and power adapter ready.
- ✓ Have your iOS device available to download the SmartCam app.
- ✓ Make sure you are within range of the same WI-FI network you'll use for your camera.
- ✓ Record your WI-FI network password here: _____

Please visit samsungsmartcam.com for extended User Manual, mobile app manual and FAQs.

If you have questions or need help installing your SmartCam, please contact our free technical support team at: 00800-8010-8022

Product Views For Setup

Use the following diagrams to familiarize yourself with the camera setup features:



- | | |
|------------------------------------|------------------------|
| 1) MicroSD Card Slot (up to 128GB) | 4) Wi-Fi Direct Button |
| 2) Power/Wi-Fi Status LED | 5) Reset Button |
| 3) Power Input | |

For a more detailed diagram, please refer to the User's Manual.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference. and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution

Any changes or modifications (including the antenna) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be co-located or operation in conjunction with any other antenna or transmitter.

This equipment complies with FCC

Create User Account

Please follow these easy steps to create a user account, before setting up your camera.



1. Go to the App Store from your iPhone or iPad.



2. Search for "Samsung SmartCam" and install the app.



3. Open the app.




4. Tap "Create new account".



5. Tap "Start".



6. Enter user ID, password, name and e-mail. Tap "Register".



7. Tap "Next" to register your camera.

Record Your SmartCam User Account Information Here:

USER ID: _____
8-14 letters or letters with numbers
Example: johnsmith or johnsmith12

USER PASSWORD: _____
10-14 letters and numbers combination
Example: smartcam123

iOS Wireless Camera Setup

Continue with camera setup by following the app wizard instructions.



1. Tap "Wireless Setup".




2. Connect the power and and follow the on-screen instructions to set up Wi-Fi connection. When done, click "Next".



3. Exit SmartCam app by pressing the home button.



4. Go to the "Settings" on your iPhone/iPad, and tap "Wi-Fi".




5. Turn on your Wi-Fi, and pick the network ending in the last 4 characters of your camera's serial number. If a password is required, enter "smartcam". Once connected, exit "Settings" and return to the SmartCam app.



6. In SmartCam app, select your home Wi-Fi network.




7. Enter your home Wi-Fi network password and tap "Connect".



8. When the LED light turns green on the camera, you will automatically be directed to Step 9.



9. Create name and password for your camera. (Name: 1-20 letters and numbers. Password: 1-8 letters and numbers)



10. To continue to setup your camera preferences, select "Yes".



11. Select your Time Zone and then tap "Next".



12. Enable motion and/or audio detection to receive event alerts on your devices.

CONGRATULATIONS!

You have successfully completed the SmartCam setup!


Camera Setup Information:












CAMERA NAME: _____
1-20 letters and/or numbers
Example: kitchen or kitchen123 or 123

CAMERA PASSWORD: _____
1-8 letters and/or numbers
Example: password or password123 or 123

SmartCam Control Guide

Once setup is complete and live video appears on your iOS device, tap the screen to display the SmartCam tool bar. This chart serves as a reference to navigate onscreen controls and customize your SmartCam experience.



Number	Description
 1. Phone recording	The user can save the video in <Manage saved video clips.> in Settings
 2. SD Save	Tap to save streaming video onto the SD card
 3. Capture	Tap to capture and save a still image during monitoring
 4. Two-Way Talk	Tap to begin and end Two-Way Talk between mobile device and camera
 4A. Microphone Button	To talk, press and hold the mic button on the screen, release to listen
 5. HQ	Tap to view the highest video quality available
 6. Melody	Tap to view and choose melody selection to play through camera
 7. Brightness Control	Tap to adjust screen image brightness
 8. Flip Control	Tap to flip screen image vertically or horizontally
 9. Motion Zone Select	Tap to enable Motion Zone Select by drawing up to three boxed areas on your screen for motion alerts in only those specific areas
 10. Audio Message Recorder	Tap to record up to 10 messages to be played through the camera speakers



Quick Start Guide for Android Setup

Before you begin your SmartCam Setup, please:

- ✓ Have your SmartCam and power adapter ready.
- ✓ Have your Android device available to download the SmartCam app.
- ✓ Make sure you are within range of the same WI-FI network you'll use for your camera.
- ✓ Record your WI-FI network password here: _____

Please visit samsungsmartcam.com for extended User Manual, mobile app manual and FAQs.

If you have questions or need help installing your SmartCam, please contact our free technical support team at: 00800-8010-8022

Product Views For Setup

Use the following diagrams to familiarize yourself with the camera setup features:



- 1) MicroSD Card Slot (up to 128GB) 4) Wi-Fi Direct Button
2) Power/Wi-Fi Status LED 5) Reset Button
3) Power Input

For a more detailed diagram, please refer to the User's Manual.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference. and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution

Any changes or modifications (including the antenna) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons. This device must not be co-located or operation in conjunction with any other antenna or transmitter.


This equipment complies with FCC

Create User Account

Please follow these easy steps to create a user account, before setting up your camera.




1. Go to the Play Store from your Android device.



2. Search for "Samsung SmartCam" and install the app.



3. Open the app.




4. Tap "Create new account".



5. Tap "Start".



6. Enter user ID, password, name and e-mail. Tap "Register".



7. Tap "Next" to register your camera.

Record Your SmartCam User Account Information Here:

USER ID: _____
8-14 letters or letters with numbers
Example: johnsmith or johnsmith12

USER PASSWORD: _____
10-14 letters and numbers combination
Example: smartcam123

Android Wireless Camera Setup

Continue with camera setup by following the app wizard instructions.



1. Tap "Wireless Setup".



2. Connect the power and follow the on-screen instructions to set up Wi-Fi connection. When done, click "Next".



3. Select your camera's serial number and tap "Next".



4. Select the Wi-Fi connection you use for your SmartCam Camera.




5. Enter your home Wi-Fi network password and tap "OK".




6. When the LED light turns green on the camera, you will automatically be directed to Step 7.




7. Create name and password for your camera. (Name: 1-20 letters and numbers. Password: 1-8 letters and numbers)



8. To continue to setup your camera preferences, select "Yes".



9. Select your Time Zone and then tap "Next".



10. Enable motion and/or audio detection to receive event alerts on your devices.

CONGRATULATIONS!

You have successfully completed the SmartCam setup!


Camera Setup Information:











CAMERA NAME: _____
1-20 letters and/or numbers
Example: kitchen or kitchen123 or 123

CAMERA PASSWORD: _____
1-8 letters and/or numbers
Example: password or password123 or 123

SmartCam Control Guide

Once setup is complete and live video appears on your Android device, tap the screen to display the SmartCam tool bar. This chart serves as a reference to navigate onscreen controls and customize your SmartCam experience.



Number	Description
 1. Phone recording	The user can save the video in <Manage saved video clips> in Settings
 2. SD Save	Tap to save streaming video onto the SD card
 3. Capture	Tap to capture and save a still image during monitoring
 4. Two-Way Talk 4A. Microphone Button	Tap to begin and end Two-Way Talk between mobile device and camera To talk, press and hold the mic button on the screen, release to listen
 5. HQ	Tap to view the highest video quality available
 6. Melody	Tap to view and choose melody selection to play through camera
 7. Brightness Control	Tap to adjust screen image brightness
 8. Flip Control	Tap to flip screen image vertically or horizontally
 9. Motion Zone Select	Tap to enable Motion Zone Select by drawing up to three boxed areas on your screen for motion alerts in only those specific areas
 10. Audio Message Recorder	Tap to record up to 10 messages to be played through the camera speakers