# **US\*GENERAL**

### 4-TIER SHELVING RACK

Model 91883

#### **ASSEMBLY INSTRUCTIONS**



Visit our website at: http://www.harborfreight.com



Read this material before using this product. Failure to do so can result in serious injury. SAVE THIS MANUAL.

Copyright® 2004 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

For technical questions or replacement parts, please call 1-800-444-3353.

#### **SPECIFICATIONS**

Overall Dimensions	51-5/8" H X 23" W X 12" D
Shelve Spacing	14-1/2" High
Materials	H/D Polypropylene
Capacity per Shelf	44 lb. (dead weight)
Total Capacity	176 lb. (evenly distributed)

#### **SAVE THIS MANUAL**

You will need the manual for the safety warnings and precautions, assembly instructions, operating and maintenance procedures, parts list and diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Keep the manual and invoice in a safe and dry place for future reference.

## SAFETY WARNINGS AND PRECAUTIONS

WARNING: When using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.


Read all instructions before assembling this product!

- Keep work area clean. Cluttered areas invite injuries.
- Use eye protection. Always wear ANSI-approved impact safety goggles when assembling this product.
- Stay alert. Watch what you are doing, use common sense. Do not assemble this product when you are tired.
- 4. Check for damaged parts. Before using this product, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for loose

- parts and any other condition that may affect the use of this product. Replace loose or worn parts immediately. Any part that is damaged should be properly repaired or replaced.
- Replacement parts. When servicing, use only identical replacement parts. Use of any other parts will void the warranty.
- 6. **Distribute weight evenly.** Uneven weight distribution could cause tipping. Put heavier items on lower shelves. Maximum weight per shelf is 44 lb. Do not allow children to climb on the shelves as Shelving Rack could trip over. Avoid setting up the Shelving Rack on an uneven surface.
- 7. The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

#### UNPACKING

When unpacking, make sure the parts listed in the parts list at the end of this manual are included. If any parts are missing or broken, please call Harbor Freight Tools at the number on the cover of this manual.



#### ASSEMBLY INSTRUCTIONS


- 1. Attach each Shelf (3) with the Supporting Poles (2) as shown in *Figure 1*. It is recommended that you start assembling bottom shelves first and work upward.
- On the bottom Shelf (3), push in the four Stand Feet (4). See Figure 1. Stand Shelf Rack upright. Tap on the Top Pole Covers (1) in the holes in the top Shelf (3) for a finished look. Check to see that the Shelf Rack is level.

**CAUTION!** Distribute weight evenly on shelves. Each shelf has a capacity of 44 lb. maximum. Place Shelf Rack on a smooth, hard, level surface.

#### PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

#### PARTS LIST AND DIAGRAM



#### **LIMITED 90 DAY WARRANTY**

Harbor Freight Tools Co. makes every effort to assure that its products meet high quality and durability standards, and warrants to the original purchaser that this product is free from defects in materials and workmanship for the period of 90 days from the date of purchase. This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance. We shall in no event be liable for death, injuries to persons or property, or for incidental, contingent, special or consequential damages arising from the use of our product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation of exclusion may not apply to you. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES. EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

To take advantage of this warranty, the product or part must be returned to us with transportation charges prepaid. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection verifies the defect, we will either repair or replace the product at our election or we may elect to refund the purchase price if we cannot readily and quickly provide you with a replacement. We will return repaired products at our expense, but if we determine there is no defect, or that the defect resulted from causes not within the scope of our warranty, then you must bear the cost of returning the product.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

3491 Mission Oaks Blvd. • PO Box 6009 Camarillo, CA 93011 • (800) 444-3353