

BINGO GAME SET

Model 96674

SET UP AND OPERATING INSTRUCTIONS



WARNING

CHOKING HAZARD –

Toy contains a small ball. Not for children under 3 yrs.

Visit our website at: <http://www.harborfreight.com>



**Read this material before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.**

Copyright© 2007 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools. Diagrams within this manual may not be drawn proportionally. Due to continuing improvements, actual product may differ slightly from the product described herein. Tools required for assembly and service may not be included.

For technical questions or replacement parts, please call 1-800-444-3353.

SAVE THIS MANUAL

Keep this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures. Write the product's serial number in the back of the manual near the assembly diagram (or month and year of purchase if product has no number). Keep this manual and the receipt in a safe and dry place for future reference.

SPECIFIC SAFETY RULES



WARNING! Read all instructions
Failure to follow all instructions listed below may result in serious injury.

1. **CHOKING HAZARD** – Toy contains a small ball. Not for children under 3 yrs.
2. For supervised use by children ages 9 and up.
3. Inspect before use. Do not use if parts are missing or damaged.
4. Use for intended purposes only. Do not modify this Bingo Game Set to perform a task that it was not designed for.
5. Keep fingers away from all moving parts.
6. The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.



SAVE THESE INSTRUCTIONS.

UNPACKING

When unpacking, make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.

SET UP INSTRUCTIONS



Read the **ENTIRE IMPORTANT SAFETY INFORMATION** section at the beginning of this manual including all text under subheadings therein before set up or use of this product.

Note: For additional information regarding the parts listed in the following pages, refer to the Parts List and Diagram.

1. Remove the plastic wrap from the two Ball Holder Trays (3).
2. Unfasten the latch on the trap door that is on the outside of Rotary Cage (1). Place thumb under the latch's oval tab and lift up. The latch may be difficult to operate initially, a fair amount of pressure may be needed.
3. Once the door latch is open, place all seventy-five Numbered Balls (2) into the Rotary Cage (1).
4. Shut the latch on the Rotary Cage (1) and the game is ready to be played.

PLAYING INSTRUCTIONS

1. Select the version of Bingo that will be played. There are many variations to the game. For instance, in “Blackout” Bingo, ALL the numbers on a player’s Bingo Card (5) must be covered to have a winning combination.
2. Give each player a Bingo Card (5). Depending on the number of players in the game, each player may use more than one Bingo Card.
3. Each player will use one of the Game Markers (4) to cover the “Free” space on their Bingo Card (5). Depending on the number of players, a player may use only a particular color of Game Marker (4) if he or she desires.
4. When all the Numbered Balls (2) are in the Rotary Cage (1), use the handle to spin the Rotary Cage. The scoop inside the Rotary Cage will take a ball and roll it out of the Rotary Cage. The player spinning the cage will then read out that Numbered Ball (“I-3” for example).
5. Each player will use a Game Marker (4) to cover the “I-3” slot (or whichever combination is called) if that combination exists on their Bingo Card (5).
6. Continue to spin the Rotary Cage (1) and call out indicated letter-number combinations. All players will cover the corresponding slots on their Bingo Card (5).
7. When a player is the first to cover a straight row of numbers on his or her Bingo Card (5)-either in a horizontal, vertical, or diagonal line-that player is the winner.
8. A player with a winning combination of numbers should call out “BINGO!” to


alert the other players of their winning combination.

MAINTENANCE AND SERVICING

1. **BEFORE EACH USE**, inspect the general condition of the Bingo Game Set. Check for loose parts, dented or cracked Numbered Balls, chipped Game Tokens, and any other condition that may affect its safe operation.
2. When finished using Bingo Game Set, store in a safe location out of reach of children under 3 years old.

PARTS LIST AND DIAGRAM

Part	Description	Qty
1	Rotary Cage	1
2	Numbered Ball	75
3	Ball Holder Tray	2
4	Game Marker (30 each – Red, Blue, Green, Yellow and Clear)	150
5	Bingo Card	18



PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.