

JBL CINEMA® SB150

Quick Start Guide

1 What's in the box

Soundbar X 1

Wireless subwoofer X 1

Remote Control X 1

Wall mount accessories X 1

Soundbar power cable X 1

Subwoofer power cable X 1

Optical cable X 1

Bluetooth

DOBY DIGITAL DECODING

NOTE: For complete information about using all of your JBL Cinema SB150, download the JBL Cinema 5.1 manual from www.jbl.com

2 Buttons and Controls

2a. Remote control

1. Power on/Standby
2. Bluetooth
3. ALCi (i)
4. Audio feedback on/off
5. Optical
6. Mute
7. Volume +/-
8. Bass volume +/-
9. Music EQ
10. Movie EQ
11. News EQ

2b. Soundbar top panel

1. Power on/Standby
2. Source selection
3. Volume +/-
4. Mute
5. Bluetooth source pairing

2c. Subwoofer

1. Power Input AC
2. Wireless pairing indicator
3. Wireless pairing button

Note: Before using the remote control, remove the plastic protecting the battery at the bottom of the remote control.

2d. Soundbar rear panel

1. Power Input AC
2. LED indicator
3. ALCi
4. ALCi pairing
5. Optical
6. ALCi in
7. ALCi out
8. Software download

3 Connections

2a. Subwoofer

1. Power Input AC
2. Wireless pairing indicator
3. Wireless pairing button

Note: Before using the remote control, remove the plastic protecting the battery at the bottom of the remote control.

2b. Soundbar rear panel

1. Power Input AC
2. LED indicator
3. ALCi
4. ALCi pairing
5. Optical
6. ALCi in
7. ALCi out
8. Software download

4 Placement

Wall mounting

Table placement

5a. Subwoofer pairing

5b. Press the pairing button on the subwoofer for more than 3 seconds to pair the subwoofer to the soundbar.

5c.

6 Bluetooth pairing

6a. The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unshielded "dangerous energy" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electrical shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (including disassembly) instructions in the literature accompanying the appliance.

Safety

1. Read these instructions – All the safety and operating instructions should be read before the product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Head all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
6. Do not install near any heat sources such as radiators, heaters, stoves, or other appliances (including amplifiers) that produce heat.
7. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
8. Only use attachments/accessories specified by the manufacturer.
9. Only use the power cord and accessories supplied by the manufacturer. Use only with the car, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a car or rack is used, use caution when moving the car/truckette and combination to avoid injury from tip-over.
10. Unplug the apparatus during lightning storms or when unused for long periods of time.
11. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unshielded "dangerous energy" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electrical shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (including disassembly) instructions in the literature accompanying the appliance.

SAFETY

- Read these instructions – All the safety and operating instructions should be read before the product is operated.
- Keep these instructions – The safety and operating instructions should be retained for future reference.
- Head all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
- Follow all instructions – All operating and use instructions should be followed.
- Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
- Do not install near any heat sources such as radiators, heaters, stoves, or other appliances (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Only use the power cord and accessories supplied by the manufacturer. Use only with the car, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a car or rack is used, use caution when moving the car/truckette and combination to avoid injury from tip-over.
- Unplug the apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.

7 Important Safety Instructions

1. This equipment is a Class II or double in sublet electrical appliance. It has been designed in such a way that it does not require a safety connector to electrical earth.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unshielded "dangerous energy" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electrical shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (including disassembly) instructions in the literature accompanying the appliance.

SAFETY

- Read these instructions – All the safety and operating instructions should be read before the product is operated.
- Keep these instructions – The safety and operating instructions should be retained for future reference.
- Head all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
- Follow all instructions – All operating and use instructions should be followed.
- Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
- Do not install near any heat sources such as radiators, heaters, stoves, or other appliances (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Only use the power cord and accessories supplied by the manufacturer. Use only with the car, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a car or rack is used, use caution when moving the car/truckette and combination to avoid injury from tip-over.
- Unplug the apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.

8 Important Safety Instructions

1. This equipment is a Class II or double in sublet electrical appliance. It has been designed in such a way that it does not require a safety connector to electrical earth.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unshielded "dangerous energy" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electrical shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (including disassembly) instructions in the literature accompanying the appliance.

SAFETY

- Read these instructions – All the safety and operating instructions should be read before the product is operated.
- Keep these instructions – The safety and operating instructions should be retained for future reference.
- Head all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
- Follow all instructions – All operating and use instructions should be followed.
- Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
- Do not install near any heat sources such as radiators, heaters, stoves, or other appliances (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Only use the power cord and accessories supplied by the manufacturer. Use only with the car, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a car or rack is used, use caution when moving the car/truckette and combination to avoid injury from tip-over.
- Unplug the apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.

9 Important Safety Instructions

1. This equipment is a Class II or double in sublet electrical appliance. It has been designed in such a way that it does not require a safety connector to electrical earth.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unshielded "dangerous energy" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electrical shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (including disassembly) instructions in the literature accompanying the appliance.

SAFETY

- Read these instructions – All the safety and operating instructions should be read before the product is operated.
- Keep these instructions – The safety and operating instructions should be retained for future reference.
- Head all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
- Follow all instructions – All operating and use instructions should be followed.
- Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
- Do not install near any heat sources such as radiators, heaters, stoves, or other appliances (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Only use the power cord and accessories supplied by the manufacturer. Use only with the car, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a car or rack is used, use caution when moving the car/truckette and combination to avoid injury from tip-over.
- Unplug the apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.

10 Important Safety Instructions

1. This equipment is a Class II or double in sublet electrical appliance. It has been designed in such a way that it does not require a safety connector to electrical earth.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unshielded "dangerous energy" within the product's enclosure that may be of sufficient magnitude as to constitute a risk of electrical shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (including disassembly) instructions in the literature accompanying the appliance.

SAFETY

- Read these instructions – All the safety and operating instructions should be read before the product is operated.
- Keep these instructions – The safety and operating instructions should be retained for future reference.
- Head all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
- Follow all instructions – All operating and use instructions should be followed.
- Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool and the like.
- Do not install near any heat sources such as radiators, heaters, stoves, or other appliances (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Only use the power cord and accessories supplied by the manufacturer. Use only with the car, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a car or rack is used, use caution when moving the car/truckette and combination to avoid injury from tip-over.
- Unplug the apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.

DE Kurzanleitung

1. Verpackungsinhalt

2. Tasten und Bedienelemente

3. Bluetooth-Verbinden

4. Aufstellung als Soundbar

5. Subwoofer-Pairing

6. Bluetooth-Pairing

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

IT Guida di avvio rapido

1. Contenuto della confezione

2. Pulsanti e comandi

3. Connessioni

4. Posizionamento

5. Accoppiamento del subwoofer

6. Accoppiamento Bluetooth

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

NL Snelstartgids

1. Verpakking inhoud

2. Tasten en bedieningselementen

3. Aansluitingen

4. Plaatsing

5. Subwoofer koppeling

6. Bluetooth koppeling

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

KO 빠른 시작 가이드

1. 구성품

2. 버튼 및 제어 요소

3. 연결

4. 벽걸이 배치

5. 서브우퍼 페어링

6. Bluetooth 페어링

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

DA Hurtigtstartgude

1. Head der i æsken

2. Knapper og kontroler

3. Tilslutninger

4. Placering

5. Paring af subwoofer

6. Bluetooth-parring

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

JP クイックスタートガイド

1. 商品

2. ボタンとコントロール

3. 接続

4. 設置

5. サブウーファーペアリング

6. Bluetoothペアリング

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

RU Краткое руководство

1. Комплект поставки

2. Соединения

3. Установка на стену

4. Соприжение сабвуфера

5. Bluetooth-Verbinden

6. LED-Status

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

CHS 快速入门指南

1. 产品清单

2. 连接和控制

3. 连接

4. 位置

5. 低音配对

6. 蓝牙配对

7. Bluetooth-Verbinden

8. LED-Status

9. Bluetooth-Verbinden

10. LED-Status

11. Bluetooth-Verbinden

12. LED-Status

permanem a suas respectivas propriedades. Fabricado com tecnologia de Dolby Laboratories, Dolby e o símbolo do double-D são marcas registradas de Dolby Laboratories.

permanem a suas respectivas propriedades. Fabricado com tecnologia de Dolby Laboratories, Dolby e o símbolo do double-D são marcas registradas de Dolby Laboratories.