



HARMAN

JBL CINEMA® SB450


4K Ultra-HD 2.1 Soundbar with Wireless Subwoofer

Quick Start Guide



1 What's in the box

JBL Cinema SB450



HDMI Cable



Optical cable



Power cable



Wall mount accessories



Soundbar power cable




Subwoofer power cable



2 Buttons and Controls


2a. Soundbar top panel



2b. Source LED


SOURCE LED BEHAVIOR	
● HDMI 1/2/3	● Aux
● HDMI TV	● Optical

2c. Remote control




Note: Before using the remote control, remove the plastic tab protecting the battery at the bottom of the remote control.

2d. Soundbar Rear Panel




- 1) USB (Software updates only)
- 2) Power In
- 3) Aux IN
- 4) Optical IN
- 5) HDMI 1
- 6) HDMI 2
- 7) HDMI 3
- 8) HDMI TV
- 9) Subwoofer pairing button
- 10) Wall Mount / Table Mount EQ switch

2e. Subwoofer Rear Panel




- 1) Power
- 2) Wireless Pairing Button
- 3) Crossover
- 4) Power Input AC
- 5) Phase

3 Connecting Devices



4 Bluetooth


- Press the Bluetooth button to pair up to 3 wireless devices.
- 1. Short-press to connect a new device
- 2. Long-press to disconnect all paired devices.



LED BEHAVIOR	
● Bluetooth icon	Bluetooth Pairing
● Bluetooth icon	Bluetooth Paired

5 JBL SoundShift®


- 1) SB450 is connected to TV and it is playing TV Sound. Press SoundShift Button, SoundShift Button light turns blue (SoundShift ON).



LED BEHAVIOR

● SoundShift icon	Soundshift is off
● SoundShift icon	Soundshift is on

- 2) Press play on a Bluetooth-paired phone, SB450 will auto switch to play phone sound.




You can always turn SoundShift off at any time by pressing the button.


6 JBL Connect

Wirelessly links multiple JBL Connect compatible speakers together.

- 1) Press connect button on both speakers



- 2) Speakers connect together and play



LED BEHAVIOR


● JBL Connect icon	Seeking JBL Connect Speaker
● JBL Connect icon	Paired with JBL Connect Speaker

NOTE: Only Bluetooth Audio can be shared among the SB450 and other JBL devices.


7 TV Remote Control Learning

Program the soundbar to respond to your own TV remote Control.

- 1) Enter Learning Mode



- 2) Learn Power



- 1. Press button on soundbar
- 2. Press button on TV remote control

LED BEHAVIOR	
● Power icon	Command is learned 1s


- 3) Complete Learning

VOLUME + : Press 'Volume +' on the soundbar and then press 'Volume +' on the TV remote control.
 VOLUME - : Press 'Volume -' on the soundbar and then press 'Volume -' on the TV remote control.
 MUTE: Press 'Volume +' and 'Volume -' together on the soundbar and then press 'Mute' on the TV remote control.

Press and hold the top panel 'Surround' key again to exit learning mode (the LED will stop blinking).

8 Stereo / Harman Display Surround

Experience virtual surround sound without additional wires or speakers with Harman Display Surround.



To reset the SB450, press and hold Volume+ and Virtual Surround buttons for 5s.



Note: For complete information about using all of your JBL Cinema SB450, download the full Owner's Manual from www.jbl.com.

RESTRICTED


DESIGN ADAPTATION / IMAGE / FINAL ART

TR & Job No: TR02323
Job Description: TR02323_JBL_SB450_QSG_A
Version : 8
Date: 2016-06-14
Other: N/A



Developed by
GP01/UK02/UK03/UK04/RT05/EDI06/RT07/RT08

**EQUITY COLORS:
REPRESENTATION:**



IMPORTANT NOTE : THE PRINT/PDF IS FOR LAYOUT AND TEXT ILLUSTRATION ONLY. THE COLOURS INDICATED HERE MAY NOT APPEAR SAME IN THE FINAL PROOF. ALTHOUGH EVERY EFFORT HAS BEEN MADE TO CHECK THE CORRECTION OF LAYOUT AND TEXT. IT IS CLIENT RESPONSIBILITY TO VERIFY BEFORE GIVING THE FINAL APPROVAL.