





Quick Start Guide

**1 What's in the box**




**2 Buttons and Controls**



**2b. Source LED**


SOURCE LED BEHAVIOR	
● HDMI 1/2/3	● Aux
● HDMI TV	● Optical

**2c. Remote control**




Note: Before using the remote control, remove the plastic tab protecting the battery at the bottom of the remote control.

**2d. Soundbar Rear Panel**




**2e. Subwoofer Rear Panel**

Your soundbar and subwoofer are already paired out of the box. If the subwoofer does not automatically connect, press the pairing buttons on soundbar and subwoofer.




**3 Connecting Devices**



**4 Bluetooth**


- Press the Bluetooth button to pair up to 3 wireless devices.
- Short-press to connect a new device
  - Long-press to disconnect all paired devices.



LED BEHAVIOR	
● Bluetooth icon	Bluetooth Pairing
● Bluetooth icon	Bluetooth Paired


**5 JBL SoundShift®**

- SB450 is connected to TV and it is playing TV Sound. Press SoundShift Button, SoundShift Button light turns blue (SoundShift ON).



LED BEHAVIOR	
● SoundShift icon	SoundShift is off
● SoundShift icon	SoundShift is on

- Press play on a Bluetooth-paired phone, SB450 will auto switch to play phone sound.




You can always turn SoundShift off at any time by pressing the button.


**6 JBL Connect**

Wirelessly links multiple JBL Connect compatible speakers together.

- Press connect button on both speakers



- Speakers connect together and play




LED BEHAVIOR	
● JBL Connect icon	Seeking JBL Connect Speaker
● JBL Connect icon	Paired with JBL Connect Speaker

NOTE: Only Bluetooth Audio can be shared among the SB450 and other JBL devices.


**7 TV Remote Control Learning**

Program the soundbar to respond to your own TV remote Control.

- Enter Learning Mode



- Learn Power




- Complete Learning

VOLUME + : Press 'Volume +' on the soundbar and then press 'Volume +' on the TV remote control.  
VOLUME - : Press 'Volume -' on the soundbar and then press 'Volume -' on the TV remote control.  
MUTE: Press 'Volume +' and 'Volume -' together on the soundbar and then press 'Mute' on the TV remote control.

Press and hold the top panel 'Surround' key again to exit learning mode (the LED will stop blinking).

**8 Stereo / Harman Display Surround**

Experience virtual surround sound without additional wires or speakers with Harman Display Surround.



To reset the SB450, press and hold Volume+ and Virtual Surround buttons for 5s.



Note: For complete information about using all of your JBL Cinema SB450, download the full Owner's Manual from www.jbl.com.

**RESTRICTED**


## DESIGN ADAPTATION / IMAGE / FINAL ART

**TR & Job No:** TR02323  
**Job Description:** TR02323\_JBL\_SB450\_QSG\_A  
**Version :** 8  
**Date:** 2016-06-14  
**Other:** N/A



Developed by  
GP01/UK02/UK03/UK04/RT05/EDI06/RT07/RT08

**EQUITY COLORS:  
REPRESENTATION:**



**IMPORTANT NOTE : THE PRINT/PDF IS FOR LAYOUT AND TEXT ILLUSTRATION ONLY. THE COLOURS INDICATED HERE MAY NOT APPEAR SAME IN THE FINAL PROOF. ALTHOUGH EVERY EFFORT HAS BEEN MADE TO CHECK THE CORRECTION OF LAYOUT AND TEXT. IT IS CLIENT RESPONSIBILITY TO VERIFY BEFORE GIVING THE FINAL APPROVAL.**