

1.if at the first time using the product can not turn on, it's perhaps not enough power for the battery please try to charge the battery then open again 2. please close the machine when the battery charging, it's good for the life of battery, also please use the dedicated equipment for battery

charging in the package attached. 3. please charge at least 4hours in the first time using, next time could be 2-3 hours.

4. long time no using product please remember to charge the battery firstly

5. please don't put product under hot sunshine, near the temperature 45'c and nor can fire, in case the damage happened.

6. please don't tear open the machine if you are not professional for this machine 7. input voltage of player if too high will be damaged

the product, too low will not work 8.if the battery power is low will lead to the button


not work or the volume diminution ,and charging will solve the problem.



Please don't put the product on wet and raining side when use.

UNCTION:

- 1.wire Bluetooth play music
- 2. LINE IN
- 3. built-in li-battery



年 (7) Sling hole Working guiding light Aux audio import jack

03

Charging

First time use we suggest to charge the product, please connect with the micro usb between product and computer, charge when off is red indictor, charge finish is blue indictor



Connect bluetooth

0

Please turn product "on" (in the same time Please ensure the battery power is full.) it's have operating prompt sound when the product is ON state, when the TF card, the default for music play mode, long press "M" button or pull out TF card to switch to the Bluetooth mode, will can matching.

05

Connect mobile phone

First step

Open the bluetooth in your mobile phone, the phone will show the symbol of bluetooth, iphone will enter research the bluetooth mode automatically.

Second step

Open the bluetooth step up in your mobile phone, point the scan research the equipment

If mobile phone show "ERIX AUDIO", your phone now already found with the bluetooth speaker, then you will enter the matching status.

Fourth step

During match please input password if needed

Matching is automatically no need setting, if success, the Bluetooth symbol of your phone

06

Connect computer

If your computer is with bluetooth function then you no need set up the bluetooth, if no pls set up the bluetooth driver firstly and insert the bluetooth adapter

First step

Pls choose bluetooth symbol, chose "add device"

Second step

The adaptor is searching the bluetooth, until it display "ERIX AUDIO"

Third step

Double click "ERIX AUDIO", it will set up the driver until it set up successfully.

Fourth step

During match please input password if needed

Fifth step

If you would like to control last and next song please choose the media player of computer attached itself. (Part mobile phone and online download player can't support)

if bluetooth is not ok pls check if it change to bluetooth mode, if it already is bluetooth model, pls confirm again the bluetooth speaker and computer is connected. Pls also check the equipment manager.

Matching and connecting

Mobile phone matching---- if last time you did not connect with bluetooth then bluetooth enter matching status, if speaker have been connected, it will connect the equipment same as last time, if not successfully, after 15-30 seconds it will enter the matching status

Connecting mode---- start to enter the matching mode

Matching status will keep 20-30seconds,if during this period ,equipment in standby state, this time can't and other bluetooth devices search and connecting.


Play music

computer player, play music ,speaker button will control mobile phone music play, pause, last song /vol- \ next song/vol+ so on operate.(part mobile phone and player can't support) .

80

LINE IN

Insert the 3.5mm audio cable to AUX and another connecter to PC or mobile phone of PSP, will auto switch LINE IN mode. 3.5mm stereo audio input ,can connect the laptop ,digital music player and PC.



09

TECHNICAL PARAMETER

Battery specification	3.7v/400mah li-battery; mode bl-5b
Speaker specification	φ40mm (diameter) ,3w 3.6ω
Charge time	2h
Frequency response	80hz-15khz
Snr	≥80db
Distortion	thd<1%
Usb specification	usb2.0, compatible with usb1.1
product size	φ75mm(diameter)x40mm(high)

Use power

he product is built-in li-battery ,through the

System form

- 1. speaker 2. 3.5mm audio line
- 3. USB cable
- 4. use manual

10

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.