

## SYSTEM DESCRIPTION, INSTALLATION, AND MAINTENANCE MANUAL

MCS-4200/7200 Multi-Channel SATCOM System

power-on counter, 6-77, 6-83  
 power-on self-test, 2-9, 5-57, 6-4, 6-5, 6-6, 6-9, 6-29,  
 6-35  
 priority 4 calls, 5-66  
 private automatic branch exchange, 3-1  
 Psid-channel frequencies, 2-2, 2-6  
 Psmc-channel, 2-1, 2-4, 2-5  
     frequency, 2-2, 2-3, 2-6  
 PSU. See power supply unit  
 push to test, 1-30  
 push-to-talk, 1-10, 3-14, 6-6

### R

radio frequency module, 6-6  
 radio frequency unit, 1-9  
 radio frequency unit interface adapter, 1-9  
     ARINC 600 connector requirements, 5-3  
 radio management panel, 1-4  
 Rd-channel, 2-4, 2-5  
 real-time clock, 6-19  
 return ID, 1-24  
 RF channels  
     C-channel, 2-4, 2-7, 2-13, 2-15, 2-16  
     P-channel, 2-1, 2-2, 2-3, 2-4, 2-6, 2-7  
     R-channel, 2-3, 2-4, 2-5  
     T-channel, 2-4, 2-5  
 RF loop back test, 6-6  
 RFM. See radio frequency module  
 Rsmc-channel, 2-4, 2-5  
 RTC. See real-time clock

### S

SATCOM control and display unit, 1-11, 2-6, 2-17, 2-19,  
 2-27, 3-14, 5-65, 5-67, 5-69, 6-6, 6-7, 6-8, 6-10,  
 6-17, 6-20, 6-22, 6-87, 6-88  
     display, 6-20, 6-21  
     page, 2-11  
         displays for dual systems, 6-110  
         hierarchy, 6-25, 6-29  
     pages, 6-10, 6-20, 6-24, 6-89  
         configuration data, 6-27, 6-38, 6-39, 6-40, 6-41,  
         6-42, 6-43, 6-44, 6-45, 6-46, 6-47, 6-48, 6-49,  
         6-50, 6-51, 6-52, 6-54, 6-55, 6-56, 6-57, 6-59  
         data loader, 6-60, 6-61, 6-62, 6-63, 6-64, 6-65,  
         6-66  
         ground report, 6-27, 6-79, 6-80  
         ground report troubleshooting data, 6-27, 6-81,  
         6-82  
         last leg class 3 faults, 6-27, 6-77, 6-79  
         last leg report, 6-27, 6-66, 6-67  
         LRU identification, 6-27, 6-71, 6-73, 6-74  
         previous legs report, 6-27, 6-68, 6-69, 6-70, 6-71

SATCOM main menu, 6-24, 6-26, 6-29, 6-110  
 SATCOM maintenance, 6-27, 6-29, 6-59, 6-66,  
 6-110  
 SATCOM self-test, 6-35, 6-36, 6-37, 6-38  
 SATCOM submenu, 6-27, 6-28, 6-66  
 test, 6-27, 6-29, 6-30, 6-31, 6-32  
 troubleshooting data, 6-27, 6-75, 6-76  
 SATCOM main menu page, 3-15  
 satellite data unit, 1-16, 2-5, 2-6, 2-7, 2-10, 2-11, 2-12,  
 2-13, 2-16, 2-17, 2-18, 3-1, 3-2, 3-5, 3-9, 3-12,  
 3-15, 5-57, 5-58, 5-59, 5-60, 5-61, 5-63, 5-65, 5-66,  
 5-67, 5-69, 6-1, 6-3, 6-5, 6-6, 6-7, 6-8, 6-9, 6-18,  
 6-19, 6-20, 6-22, 6-66, 6-72, 6-84, 6-85, 6-87, 6-88,  
 6-89, 6-110, A-4, A-10, B-1, B-4, B-8, C-1  
     ARINC 600 connector requirements, 5-3  
     codec, 2-15, 2-27, 3-1, 3-14, 5-68  
     configuration pin, 5-64  
     cooling requirements, 4-3  
     failure reporting, 6-10  
     front panel  
         connector, 5-1  
         indicators and controls, 6-10  
         light emitting diodes, 6-11  
     installation dependent considerations, 4-2  
     master, 2-16, 2-17, 2-18, 2-19  
     mechanical installation data, 4-1  
     modem, 3-5  
     number, 5-64  
     rear connector, 5-1  
     slave, 2-16, 2-17, 2-18, 2-19  
     software upload, 2-9  
     software/database updates, 2-8  
     to WH-10 handset actions, 3-5  
     voice codec, 3-5, 3-6  
 scratchpad, 6-20, 6-21, 6-23, 6-65, 6-88  
 SDI. See source destination identifier  
 secure voice, coding unit, 2-15  
 shop replaceable unit, 6-3, 6-75, 6-77, 6-81  
 sign/status matrix, 5-57, 6-4, 6-5, 6-6, 6-9, 6-84, 6-87,  
 A-19, A-21, A-22  
 signal conditioning unit, A-4, A-9, A-16, A-17, A-18,  
 A-19, A-21, A-22  
     automatic input selection, A-19  
     built-in test, A-17, A-19  
     control functions, A-18  
     front panel, A-17  
     light emitting diode, A-17, A-19  
     manual signal selection, A-18  
 single channel per carrier, 1-12  
 SMT, surface mount technology, 1-25  
 software, upload, 2-8, 2-9  
     validation, 2-9  
 source destination identifier, 5-61, 5-64, 6-16, 6-84  
 space segment, 1-2  
 spot beam, 2-1, 2-2, 2-4, 2-5, 2-6  
     handover, 2-6

## SYSTEM DESCRIPTION, INSTALLATION, AND MAINTENANCE MANUAL

MCS-4200/7200 Multi-Channel SATCOM System

satellite, 2-1  
search table, 2-3  
SRU, shop replaceable unit, 1-25  
SSM. See sign/status matrix  
standard ground test, 6-87  
strap parity, 5-60  
swift channel module, 1-23  
system address label, 2-9  
system table, 2-2, 2-3, 3-9

---

### T

terminal interface function, 2-15  
terrestrial data and voice, 1-2  
time division multiple access, 1-12  
time division multiplex, 1-12  
time since power-on, 6-77, 6-83  
total on-time clock, 6-18, 6-19  
triple transcoder modem, 1-21

---

### U

UTC. See coordinated universal time

---

### V

VCM. See voice codec module  
vendor equipment, 4-4, A-1  
voice codec module, 3-14  
    audio switching, 3-15  
    dedication, 3-17  
    sidetone, 3-15  
    stored audio messages, 3-15  
voltage standing wave ratio, 4-2, A-2

---

### W

weight-on-wheels discrete, 6-7, 6-39

---

### X

XTB. See cross-talk bus