

TR-86x VDR User's Manual

The VDR Components Maintenance Manual (CMM), A09-3829-002, contains component maintenance levels for repair, testing, and configuration confirmation of the VDR assembly, including all software loading. This document can be obtained from the Honeywell Online Technical Publications Website.

System Description and Installation Manual (SDIM), A15-6720-001, supplies general system description information for the PRIMUS EPIC Digital Modular Radio System (Modular Radio System). The Modular Radio System is made up Modular Radio Cabinets (MRCs), and associated controls, displays, and antennas. Each MRC combines the VIDL, ADF, DME, VDR, and diversity Mode S transponder. It includes description and operation for the VDR as well as installation information. This document can also be obtained from the Honeywell Online Technical Publications Website.