

M/N: MID950

	9\"/> 	In the box	Buttons, ports & hardware
Quick Start Guide			

Google Play™	Charging the tablet	Power ON / OFF	Connecting
<p>Google Play™ is a digital content experience from Google where you can find and enjoy your favorite music, movies, TV shows, books and Android™ apps and games. If your entertainment fun you can access it from the web or from your Android device, and if your content is already available, access your devices.</p>	<p>Battery Tips:</p> <ul style="list-style-type: none"> Turn off Wi-Fi when it's not in use. Lock the tablet during the display off to shorten charging time. To optimize battery time and performance, adjust the "Brightness" and "Screen timeout" options in the Settings panel. 	<p>Turning ON the tablet Press and hold the Q button until the startup screen appears.</p> <p>Power off the tablet Press & hold the Q button until the "Power off" options appear.</p> <p>Lock the tablet (standby) Briefly press the Q button. Lock the tablet to conserve the battery.</p> <p>Unlock the tablet Briefly press the Q button, and slide the "lock open" to the right.</p>	<p>Wi-Fi and Bluetooth® To setup Wi-Fi or connect the tablet to a Bluetooth device, swipe down on the top right of the home screen as shown below to access the Quick Settings panel.</p>

Home screen	Apps screen	Widgets
<p>Appears when connecting the tablet to a PC.</p>	<p>Click here to go back to Home screen</p>	<p>Press and hold Widgets to place them on the Home screen.</p>
Micro SD card	Legal information	Limited warranty
	<p>Inserting a Micro SD card The tablet supports Micro SD cards up to 64GB (not included). To insert a Micro SD card into the tablet, insert the card as shown below into the card slot until it clicks and locks into place. To remove the Micro SD card, gently press it inward to eject.</p>	<p>BATTERY DISPOSAL & RECYCLE This device contains a lithium-ion battery. The battery should never be recharged or disposed of as waste. Contact your local waste management office for information on battery recycling or disposal. #W40AG04337</p>

