



# User Guide

htc one<sup>®</sup> remix

# Contents

---

## Unboxing

---

HTC One remix	15
Your Verizon Wireless SIM card	16
Storage card	19
Charging the battery	22
Switching the power on or off	23
Want some quick guidance on your phone?	24

---

## Phone setup and transfer

---

Setting up your new phone for the first time	25
Transferring content from an Android phone	26
Transferring content from an iPhone	27
Transferring contacts from your old phone through Bluetooth	28
Other ways of getting contacts and other content	29
Transferring photos, videos, and music between your phone and computer	30
Home screen	30
Using Quick Settings	31
Getting to know your settings	32
Updating your phone's software	33

Getting apps from Google Play	35
Downloading apps from the web	37
Uninstalling an app	38

---

## Your first week with your new phone

---

About your phone	39
Basics	41
HTC BlinkFeed	57
Notifications	62
Working with text	64
Battery	72

---

## Personalizing

---

Making HTC One remix truly yours	78
Ringtones, notification sounds, and alarms	78
Home wallpaper	79
Launch bar	80
Adding Home screen widgets	81
Adding Home screen shortcuts	83
Editing Home screen panels	84
Changing your main Home screen	86
Grouping apps on the widget panel and launch bar	87
Arranging apps	88
Lock screen	90

---

## Camera

---

Camera basics	92
Taking a photo	95
Tips for capturing better photos	96
Recording video	98
Taking continuous camera shots	99
Taking selfies	99
Improving portrait shots	100
Taking a panoramic photo	100
Using HDR	101
Recording videos in slow motion	102
Manually adjusting camera settings	102
Saving your settings as a camera mode	103

---

## Gallery

---

Viewing photos and videos in Gallery	105
Viewing photos and videos organized by time	105
Viewing photos and videos by album	105
Viewing photos by location	108
Editing your photos	110
Creating an animated gif	113
Creating an action sequence shot	114
Editing a group shot	114
Removing unwanted objects in a photo	115

Trimming a video	116
Saving a photo from a video	116
Creating a Zoe in Gallery	117

---

## Phone calls

---

Making a call with Smart dial	119
Making a call with your voice	119
Dialing an extension number	120
Returning a missed call	120
Speed dial	121
Calling a number in a message, email, or calendar event	122
Making an emergency call	122
Receiving calls	123
What can I do during a call	124
Setting up a three-way call	125
Call History	125
Changing ringtone settings	127
Global Ready	128
Using Assisted dialing	128
Changing the HTC One remix network connection	131

---

## Messages

---

Verizon Messages	132
HTC Messages	133

---

## Search and web browser

---

Searching HTC One remix and the Web	139
Getting instant information with Google Now	141
Browsing the Web	145
Bookmarking a webpage	146
Clearing your browsing history	146

---

## Entertainment

---

Music	147
YouTube	154
Wireless media	156

---

## Storage

---

Phone storage	161
Google Drive	166

---

## Sync, backup, and reset

---

Online sync	171
Backup	173
HTC Sync Manager	179
Reset	183

---

## People

---

Your contacts list	187
Setting up your profile	189
Adding a new contact	190
Editing a contact's information	192
Getting in touch with a contact	192
Importing or copying contacts	193
Merging contact information	195
Sending contact information	196
Contact groups	197
Private contacts	199

---

## Email

---

Gmail	201
Mail	204

---

## Calendar

---

Viewing the Calendar	213
Scheduling or editing an event	215
Choosing which calendars to show	216
Sharing an event	217
Accepting or declining a meeting invitation	217
Dismissing or snoozing event reminders	218

---

## Travel and maps

---

Location settings	220
Google Maps	221
HTC Car	225
VZ Navigator	228

---

## Other apps

---

Using Scribble	230
Using the Clock	234
Checking Weather	235
Keeping track of your tasks	236
Kid Mode	237

---

## Internet connections

---

Data connection	240
Managing your data usage	241
Wi-Fi	243
Wi-Fi Enhanced Connectivity	245
Connecting to VPN	246
Using HTC One remix as Mobile Hotspot	248
Sharing your mobile data connection by USB tethering	249



---

## Wireless sharing

---

Turning Bluetooth on or off	251
Connecting a Bluetooth headset	251
Unpairing from a Bluetooth device	253
Receiving files using Bluetooth	253
Using NFC	255

---

## Settings and security

---

Airplane mode	259
Do not disturb mode	260
Scheduling when to turn data connection off	262
Automatic screen rotation	263
Setting when to turn off the screen	263
Screen brightness	263
Changing the display font	264
Touch sounds and vibration	264
Changing the display language	265
Accessibility settings	266
Turning Magnification gestures on or off	266
Installing a digital certificate	267
Disabling an app	267
Lock screen notifications	268
Hiding the caller from the lock screen	268
Setting a screen lock	269

Setting up face unlock	269
Bypassing the lock screen	270
Navigating HTC One remix with TalkBack	271

---

## Trademarks and copyrights

---

---

## Index

---

## IMPORTANT CUSTOMER INFORMATION

Please be advised that many services and applications offered through this unique device are provided by various device manufacturers, operating system, software and application developers (e.g. Google®, Motorola®, Microsoft®, BlackBerry®). If you use, link to or download such a service, or an application such as a non-Verizon Wireless location based GPS-type service, chat room, marketplace or social network from this device, you should carefully review the terms of such service or application. If you use any of these non-Verizon Wireless services or applications, personal information you submit may be read, collected, or used by the service or application provider and/or other users of those forums.

Verizon Wireless is not responsible for your use of those applications or information you choose to submit or share with others. Specific terms and conditions, terms of use, and privacy policies apply to those applications and services. Please review carefully any and all terms and conditions applicable to those applications and services including those related to any location-based services for any particular privacy policies, risks or waivers.

Your Verizon Wireless Customer Agreement Terms and Conditions and certain other specifically identified terms govern your use of any Verizon Wireless products and services.

## Conventions used in this guide

In this user guide, we use the following symbols to indicate useful and important information:



This is a note. A note often gives additional information, such as what happens when you choose to do or not to do a certain action. A note also provides information that may only be applicable to some situations.



This is a tip. A tip gives you an alternative way to do a particular step or procedure, or lets you know of an option that you may find helpful.



This indicates important information that you need in order to accomplish a certain task or to get a feature to work properly.



This provides safety precaution information, that is, information that you need to be careful about to prevent potential problems.

## Important RF Notice


This device was tested for compliance with the applicable FCC and Industry Canada specific absorption rate (SAR) limits for radio frequency (RF) exposure during typical body-worn operations. To ensure that RF exposure levels remain at or below the tested levels, use a belt-clip, holster, or similar accessory that maintains a minimum separation distance of 1.0 cm between your body and the device, with either the front or back of the device facing towards your body. Such accessories should not contain any metallic components. Body-worn accessories that do not meet these specifications may not ensure compliance with applicable SAR limits and their use should be avoided.

### **Important note on recoverable data**

Files and other data that have been deleted, cleared, removed, or erased from your device may still be recoverable by third-party data recovery software. Even a factory reset may not permanently erase all data from your phone, including personal information.

# Unboxing

## HTC One remix



1. USB connector
2. Dual speakers
3. VOLUME
4. microSD™ card tray with eject hole
5. Front camera
6. 3.5mm headset jack
7. POWER
8. Proximity sensor
9. Notification LED
10. nano SIM card tray with eject hole



If you want to use a case, please don't cover and block the proximity sensor. Purchase a case designed for HTC One remix.

## Your Verizon Wireless SIM card

Use your Verizon Wireless SIM card to make and receive calls, text, and email messages and surf the Web while traveling outside of the U.S. in supported destinations.



Your SIM (Subscriber Identity Module) card stores your phone number and other important information. Do not bend or scratch your SIM card. Avoid exposing it to static electricity, water or dirt. If your SIM card is lost or damaged while in the U.S., please dial \*611 from your Verizon Wireless device or 1-800-922-0204 from any phone to speak with a Customer Service Representative. From outside of the U.S., please refer to the Verizon Wireless Global Support Guide, welcome letter and calling card that came with your device. This will enable you to make calls toll free from landlines in most countries where we offer Global Phone service.



---

## nano SIM card

---


HTC One remix uses a nano SIM card. The nano SIM card contains your phone number, service details, and memory for storing phonebook contacts and/or text messages.

---

## Inserting the nano SIM card

---

1. Hold the phone face up.
2. Insert the tip of the tray eject tool into the tray eject hole next to the nano SIM card tray slot.



3. Push the tip all the way into the hole until the nano SIM card tray ejects.

4. Pull the nano SIM card tray out, and place the nano SIM card (contacts facing down) into the tray.



5. Insert the nano SIM card tray back into the slot.


---

### Removing the nano SIM card

---

**F** Make sure to switch off HTC One remix before removing your nano SIM card.

1. Hold the phone face up and the top panel facing you.
2. Insert the tip of the tray eject tool into the tray eject hole next to the nano SIM card tray slot.



3. Push the tip all the way into the hole until the nano SIM card tray ejects.
4. Pull the nano SIM card tray out, and remove the nano SIM card.

After removing the nano SIM card, make sure that you insert the empty nano SIM card tray back into the slot.

## Storage card

Use a storage card to store your photos, videos, and music. When you need to free up phone storage space, you can also move certain apps to the storage card, if the apps support this feature.



The storage card is optional and sold separately.



- Moving apps to the storage card doesn't back up the apps. If you do a factory reset, your phone loses the apps. You'll need to reinstall them.
- When you remove the storage card and insert it in another phone, the apps on the storage card won't be installed automatically to the other phone. You'll need to reinstall them.


---

## Inserting the microSD card


---

1. Hold the phone face up.

2. Insert the tip of the tray eject tool into the tray eject hole next to the microSD card slot.



3. Push the tip all the way into the hole until the microSD card tray ejects.
4. Pull the microSD card tray out, and place the microSD card into the tray.



5. Insert the microSD card tray back into the slot.

---

## Unmounting the storage card

---

When you need to remove the storage card while HTC One remix is on, unmount the storage card first to prevent corrupting or damaging the files in the storage card.

1. Go to Settings, and then tap **Storage**.
2. Tap **Unmount SD card**.

---


## Removing the microSD card

---



Make sure to unmount your microSD card before removing it.

1. Hold the phone face up and the top panel facing you.
2. Insert the tip of the tray eject tool into the tray eject hole next to the microSD card slot.



3. Push the tip all the way into the hole until the microSD card tray ejects.
4. Pull the microSD card tray out, and remove the microSD card.


After removing the microSD card, make sure that you insert the empty microSD card tray back into the slot.

## Charging the battery

Before you turn on and start using HTC One remix, it is recommended that you charge the battery.

Use only the adapter and the USB cable that came with HTC One remix to charge the battery. When the battery power is too low, make sure to use the power adapter to charge, not the USB cable connection with your computer.

1. Insert the small end of the USB cable into the USB connector.



2. Insert the other end of the USB cable into the power adapter.
3. Plug in the power adapter to an electrical outlet to start charging the battery.



- As a safety precaution, the battery may stop charging to avoid overheating.
- When you're using the Internet and charging the battery, HTC One remix may become warmer. This is normal.
- To conserve energy, unplug the power adapter from the electrical outlet after you finish charging.

## Switching the power on or off

---

### Switching the power on

---

Press the POWER button until HTC One remix vibrates.



When you turn on HTC One remix for the first time, you'll need to set it up.

---


### Switching the power off


---

1. If the display is off, press the POWER button to turn it back on. If you've set up a lock screen, you need to unlock it.
2. Press and hold the POWER button for a few seconds.
3. Tap **Power off** on the options menu.

## Want some quick guidance on your phone?

Check out the friendly walkthroughs and the FAQs in Tips & Help to learn how to use your phone.

- When you see a Tips & Help tile in HTC BlinkFeed™, just tap the tile to know more about the tip.
- To open Tips & Help from the Home screen, tap  > **Help** > **Tips & Help**

You can then browse by subject matter and topic. Or tap , and then enter what you want to search for.



# Phone setup and transfer

## Setting up your new phone for the first time

When you switch on your new phone for the first time, you'll be asked to set it up.



You can enable TalkBack to navigate by voice feedback before selecting the language. Press and hold two fingers on the screen until you hear a message saying that accessibility mode is enabled.

Walk through the on-device setup to choose your Internet connection, select how you want to set up your new phone, and more.

- You can choose to setup accounts and personalize your new phone using a computer. When the HTC Get Started reminder appears, tap it on the Notification panel to use HTC Get Started. Or, press and hold an empty space in a Home screen panel, and then tap **Home screen wallpaper > Computer photos**.

Your phone shows you the URL of the HTC Get Started site and a pair code. On your computer's web browser, just go to the URL and enter the pair code to start your web setup. You need an HTC Account to save your accounts and settings on the Web and download them to your phone.

- If you have content from an old phone, you can choose to do a direct phone-to-phone transfer.



Some features that need to connect to the Internet such as location-based services and auto-sync of your online accounts may incur extra data fees. To avoid incurring data fees, disable these features under Settings. For more information on location services, see [Turning location services on or off](#) on page 220.

## Transferring content from an Android phone

On your old Android™ phone, download the HTC Transfer Tool and use it to transfer your content to your new HTC phone. The types of locally stored content on your old phone that the tool can transfer include contacts, messages, calendar events, web bookmarks, music, photos, and videos. Some settings can also be transferred.



- You need Android version 2.2 or later to use the HTC Transfer Tool on your old phone.
- If your old phone has Android version 2.1 or an earlier version, you need to use Bluetooth® transfer. For details, see [Transferring contacts from your old phone through Bluetooth](#) on page 28.

1. Go to Settings, and then tap **Get content from another phone**.
2. Choose whether to transfer from an old HTC Android phone or other Android phone.
3. Tap **Full transfer**, and then tap **Next**.
4. Follow the steps shown on your new phone to download the HTC Transfer Tool from Google Play™ to your old phone, install it, and open the tool.

5. When you see a PIN on your old phone, make sure the same PIN also appears on your new phone before you continue.



If the PIN code doesn't appear, this may mean that your old phone is unable to connect to your new phone. If this happens, try another transfer method.

6. On your old phone, choose the types of content you want to transfer, and then tap **Start** or **Transfer**.
7. Wait for the transfer to finish.
8. Tap **Done** on both phones.

## Transferring content from an iPhone

If you have an iPhone®, it's fast and easy to transfer your contacts, messages, and other content when you use HTC Sync Manager.

To find out how, see [Transferring iPhone content and apps to your HTC phone](#) on page 182.

If you only need to migrate your contacts, you can also use Bluetooth transfer. For details, see [Transferring contacts from your old phone through Bluetooth](#) on page 28.

## Transferring contacts from your old phone through Bluetooth

Use Bluetooth to transfer contacts from an iPhone, a phone that has Android version 2.1 (or earlier version), or other types of phones. Depending on the capabilities of your old phone, you may be able to transfer not only contacts but also other data such as calendar events and text messages to your new HTC phone.



Use HTC Sync Manager to transfer more types of content from an iPhone.

1. Go to Settings, and then tap **Get content from another phone**.
2. Choose whether to transfer from an Android phone, iPhone, or other phone types. If you chose to transfer from an Android phone, tap **Quick transfer**.
3. On your old phone, turn Bluetooth on.
4. Follow the onscreen instructions on your old and new phones to pair them and start the data transfer.

## Other ways of getting contacts and other content

There are different ways you can individually add contacts and other content to HTC One remix.

<b>Sync with your computer</b>	<p>Use HTC Sync Manager to sync contacts, documents, playlists, and more between HTC One remix and your computer running a Windows® or Mac OS® operating system.</p> <p>You can also use it to transfer your iTunes® backup that contains contacts, messages, and other content from an iPhone from your computer to HTC One remix.</p>
<b>Google Account</b>	<p>Google contacts are imported to HTC One remix after you sign in to your Google Account. You can also create more Google contacts right from HTC One remix.</p>
<b>Social network accounts</b>	<p>Log in to your favorite social networks to sync contact information from them.</p>
<b>Microsoft Exchange ActiveSync®</b>	<p>HTC One remix syncs your work contacts from the Microsoft Exchange ActiveSync Server in your workplace.</p>
<b>Phone contacts</b>	<p>You can create contacts locally on HTC One remix, if you don't prefer to store them on your online accounts.</p>

## Transferring photos, videos, and music between your phone and computer

There are two ways you can transfer your media from or to your computer.

- Connect HTC One remix to your computer. Your computer will recognize it just like any removable USB drive, and you can copy your media between them.
- Download and use the HTC Sync Manager software on your computer. You can set it up to automatically get music, photos, and videos off HTC One remix to your computer. You can also sync playlists from your computer to the phone.


If you have an iPhone, you can even connect it and transfer camera roll photos to your computer. Then reconnect HTC One remix and copy them over.

## Home screen

After you've turned on and set up HTC One remix for the first time, you'll see HTC BlinkFeed.


- Customize HTC BlinkFeed to show posts from your social networks, headlines from your favorite news media, and more. For details, see [Your dynamic Home screen](#) on page 57.
- Swipe left and you'll discover widget panels for adding your favorite widgets, apps, and more so they're just a tap away. If you need more room for your stuff, you can add more panels. For details, see [Personalizing](#) on page 78.
- You can change the apps on the launch bar at the bottom of the Home screen. See [Launch bar](#) on page 80.




While you're in another screen or app, press  to return to the last Home screen you visited.

## Using Quick Settings

In the Quick Settings panel, easily turn settings such as Wi-Fi® and Bluetooth on or off.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. To turn a setting on or off, just tap its tile.
3. To change the options for a setting, press and hold its tile. Or tap .





You can also tap  to switch to Quick Settings from the Notifications panel.

---

## Customizing Quick Settings

---

Aside from the default tiles, there are several other tiles available in Quick Settings.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap  and do one of the following:
  - In the Quick Settings list, press and hold  next to the item you want to move and drag it to rearrange the list.



- Under Hidden items, press and hold  and drag it up to make it available in Quick Settings.



There is a limit to the number of tiles that can be shown in Quick Settings. You may need to remove an existing item to make space for another one. To remove an item, drag it below Hidden items.

## Getting to know your settings

Want to change the ringtone, set up a Wi-Fi connection, or add your accounts? Do this and more in Settings.

1. Open Settings either from the Quick Settings panel or the Apps screen.
  - With two fingers, swipe down from the status bar to open Quick Settings, and then tap .
  - From the Home screen, tap  to switch to the Apps screen, and then tap **Settings**.
2. Here are some of the basic settings you can change:
  - Tap the **On/Off** switch next to an item such as Wi-Fi to turn it on or off. Tap the item itself to configure its settings.
  - Tap **Sound** to set a ringtone, choose a sound profile, and configure incoming call sound settings.
  - Tap **Personalize** to change the wallpaper, add apps and widgets to the Home screen, and more.
  - Tap **Accounts & sync** to add and sign in to your different accounts, such as email, social networks, and more.



- Tap **Security** to help secure HTC One remix, for example with a screen lock.

## Updating your phone's software

HTC One remix can check and notify you if there's a new update available. You can also choose to manually check if there's an available update.



Visit [www.htc.com/us/go/htc-software-updates/](http://www.htc.com/us/go/htc-software-updates/) for news and details about your phone's software updates.

---

## Checking your system software version

---


Before installing a system software update, you can check first what Android and HTC Sense® versions you have on your phone.

1. Go to Settings, and then tap **About**.
2. Tap **Software information**.

---

## Installing a software update

---

When Internet connection is on and there's a new software update available, the update notification icon  appears in the status bar.

1. Slide the Notifications panel open, and then tap the system update notification.
2. If you don't want to download the update using your data connection, select **Update over Wi-Fi only**.

3. Tap **Download**.
4. When download is complete, select **Install now**, and then tap **OK**.

After updating, HTC One remix will restart.

---

## Installing an application update

---

When Internet connection is on and there's an available update for your HTC or Verizon Wireless apps, the update notification icon (📲) appears in the status bar.

1. Slide the Notifications panel open, and then tap the update notification.  
The Updates screen opens with the list of application updates to be installed.
2. Tap an item to view its details, and then tap ↶.
3. When you're done reviewing the updates, tap **Install**. You'll be asked to restart HTC One remix if needed.

---

## Checking for updates manually

---



You need an internet connection to check for software updates. Turn on mobile data or connect to a Wi-Fi network.

Go to Settings, and then tap **Software update > Check new**. HTC One remix checks if updates are available.

## Getting apps from Google Play

Google Play is the place to go to find new apps for HTC One remix. Choose from a wide variety of free and paid apps ranging from productivity apps, entertainment, to games.



A Google Wallet™ payment service is required to purchase a paid app. You will be asked to confirm method of payment when you purchase an app.

---

### Finding and installing an app

---

When you install apps and use them on HTC One remix, they may require access to your personal information or access to certain functions or settings. Download and install only apps that you trust.



Be cautious when downloading apps that have access to functions or a significant amount of your data on HTC One remix. You're responsible for the results of using downloaded apps.

1. Open the Play Store app.
2. Browse or search for an app.
3. When you find the app that you like, tap it and read its description and user reviews.
4. To download or purchase the app, tap **Install** (for free apps) or the price button (for paid apps).
5. Tap **Accept**.



Apps sometimes get updated with improvements or bug fixes. To automatically download updates, after installing the app, tap **⋮** > **Auto-update**.

To open the app, go to the Apps screen and tap the app.

---

## Restoring apps from Google Play

---

Upgraded to a new phone, replaced a lost one, or performed a factory reset? Restore apps that you previously downloaded.

1. Open the Play Store app.
2. Tap **≡** to open the slideout menu.
3. Tap **My apps**, swipe to the All tab, and then tap the app you want to restore.
4. Install the app.

For more details, refer to the Google Play help.

## Downloading apps from the web

You can download apps directly from websites.



- Apps downloaded from websites can be from unknown sources. To help protect HTC One remix and your personal data, we strongly recommend that you only download from websites you trust.
- Before you can install the downloaded app, make sure that you've set HTC One remix to allow installation of third-party apps in **Settings > Security > Unknown sources**.

1. Open the browser, and then go to the website where you can download the app you want.
2. Follow the website's download instructions for the app.



After installing the app, make sure to go back to **Settings > Security** and clear the **Unknown sources** option.

## Uninstalling an app

If you no longer need an app that you've downloaded and installed, you can uninstall it.



Most of the preloaded apps cannot be uninstalled.

From the Apps screen, press and hold the app you want to remove, and then drag it to **Uninstall**.



If you purchased an app in Play Store, you can uninstall it for a refund within a limited time. To know more about the refund policy for paid apps, refer to the Google Play help.

# Your first week with your new phone

## About your phone

---

### Features you'll enjoy on HTC One remix

---

HTC One remix gives you options for quick and easy setup. Transferring your old phone's content such as your contacts, messages, and media can be done right from HTC One remix.

Also, enjoy taking shots with the camera, checking personalized content with HTC BlinkFeed, and more.

## Easy phone setup and transfer

- With our HTC Get Started service, you can set up and personalize HTC One remix from your computer, and just download your settings to HTC One remix. See [Setting up your new phone for the first time](#) on page 25.
- Easily transfer your contacts, messages, music, photos, videos, and more from an Android phone to HTC One remix. See [Transferring content from an Android phone](#) on page 26.

By using **HTC Sync Manager**, you can even migrate content from an iPhone. See [Transferring iPhone content and apps to your HTC phone](#) on page 182.

## Dynamic Home screen

With **HTC BlinkFeed**, personalize your Home screen with the information and updates that matter most to you. See a variety of content such as feeds about news and your interests, social network updates, HTC One remix tips, and more. The content refreshes periodically when you're connected to the Internet. See [Your dynamic Home screen](#) on page 57.

## New ways to share memories

Show off the excitement of your event. A **Zoe** is automatically created from selected highlights of an event or album with background music and special effects. See [Creating a Zoe in Gallery](#) on page 117.

## Outstanding camera features

- Choose from a variety of pre-defined camera modes, or create your own camera profiles. See [Choosing a capture mode](#) on page 93.
- With **VideoPic**<sup>®</sup>, you can snap a picture while you're shooting video. See [Taking a photo while recording a video — VideoPic](#) on page 98.
- Switch to **Sweep panorama** and pan the camera to capture a wide-angle view of the scenery. See [Taking a panoramic photo](#) on page 100.
- Use **Continuous shooting** mode to capture consecutive shots of a subject in motion.
- By just tapping the shutter button, take multiple shots of your subject at different exposures and combine them into a nice, evenly exposed photo. See [Using HDR](#) on page 101.



## Immerse in music

- Watch mesmerizing visualizations as you play songs in HTC Music. And if lyrics are available, they'll show onscreen. See [Viewing song lyrics](#) on page 153.
- With HTC BoomSound™, you'll hear fine details not only while you listen to music but also when you watch videos, play games, and the like. See [HTC BoomSound profile](#) on page 149.

## Google Drive integration

HTC One remix features an additional 50GB of Google Drive™ storage free for 2 years. See [Activating your free Google Drive storage](#) on page 167.




## Basics

---

### Onscreen navigation buttons

---

HTC One remix has onscreen navigation buttons at the bottom of the screen which rotate when you change the orientation.

	Goes to the previous screen.
	Goes to the home screen.
	Shows thumbnails of the most recently used apps.

Swipe up from any of the navigation buttons to access Google search.

## Sleep mode

---

Sleep mode saves battery power by putting HTC One remix into a low power state while the display is off. It also stops accidental button presses when HTC One remix is in your bag.

### Switching to Sleep mode

To turn off the display and switch to Sleep mode, briefly press the POWER button.

HTC One remix also automatically goes into Sleep mode when it's left idle for a while. You can change the time before HTC One remix sleeps by setting the screen timeout. For details, see [Setting when to turn off the screen](#) on page 263.

### Waking up from Sleep mode

Press the POWER button.


---

## Unlocking the screen

---



- Swipe up to unlock the screen, swipe right to go directly to HTC BlinkFeed, or swipe left to go to the Home widget panel.

- You can also press and hold the lock icon, and then drag it up, right, or left.



If you've set up a screen lock, you'll be asked to provide your credentials before HTC One remix unlocks.



If you've set an event reminder or an alarm, you can snooze or dismiss the event or alarm right from the lock screen. Just drag  or  up.

## Motion gestures

Use motion gestures to mute HTC One remix, lower the ring volume, and more.

### Flip to mute



If your phone is facing up when a call comes in, turn the phone over to mute it.

If you go to Settings and then tap **Sound > Flip to mute**, you can set your phone to:

<b>Mute once</b>	Mute only once after flipping the phone. While the phone is still facing down, it will ring again when there are other incoming calls.
<b>Mute always</b>	After flipping the phone to mute a call, keep it always muted while it's still facing down when there are other incoming calls.

## Pick up to lower volume



In a business meeting or restaurant, pick HTC One remix up when a call comes in to lower the ring volume automatically.

You can turn this feature on or off. Go to Settings, tap **Sound**, and then select or clear **Quiet ring on pickup**.


## Increase ring volume automatically while phone is in your pocket or bag



Pocket mode makes HTC One remix recognize when your phone is in your bag or pocket and raise the ring volume so that you can hear it in noisy environments.

You can turn this feature on or off. Go to Settings, tap **Sound**, and then select or clear **Pocket mode**.

## Rotate HTC One remix for a better view



For many screens, you can automatically change the screen orientation from portrait to landscape by turning HTC One remix sideways.

When entering text, you can turn HTC One remix sideways to bring up a bigger keyboard.

---

## Touch gestures

---

Use touch gestures to get around the Home screen, open apps, scroll through lists, and more.

### Tap




- Tap the screen with your finger when you want to select onscreen items such as application and settings icons, or press onscreen buttons.
- After you've scrolled down a long list or screen (in apps such as Mail and People), tap the status bar to jump straight to the top of your screen.

## Press and hold



To open the available options for an item (for example, a contact or link in a webpage), just press and hold the item.

## Swipe or slide



Quickly swipe your finger vertically or horizontally across the screen to go to other Home pages, scroll through documents, and more.




## Drag



Press and hold your finger with some pressure before you start to drag. While dragging, don't release your finger until you have reached the target position.

## Flick



Flicking the screen is similar to swiping, except that you need to swipe your finger in light, quicker strokes, such as when moving right and left on the Home screen, or flicking through a contacts or message list.


## Press and flick



On the Home screen, you can easily move a widget or icon from one screen to another.

Press and hold the widget or icon with one finger, and flick the screen to the new location with another finger.

## Slide with two fingers




In some apps, like Gallery, Messages, Mail, or the web browser, slide two fingers apart to zoom in when viewing a picture or text.




Slide two fingers together to zoom out of the picture or text.

## Two-finger swipe



Swipe down from the status bar using two fingers to access Quick Settings.

## Three-finger swipe



- Swipe up using three fingers to choose a device where to share content such as photos, videos, and music from HTC One remix. You can also share streaming media from apps such as YouTube\*.
- Swipe down to disconnect from the device.



**Media gesture** is turned on in Settings by default, which makes the three-finger gesture work only when sharing content or using HTC apps.

## Three-finger tap



While using the HTC Car app, tap the screen with three fingers to activate the voice command mode.

---

## Opening an app

---

- Tap an app on the launch bar at the bottom of the Home screen.
- Tap to go to the Apps screen, and then tap the app you want to use.
- On the Apps screen, tap , and then enter the name of the app you're looking for.

## Opening an app or folder from the lock screen

On the lock screen, drag an app or folder icon up to unlock the screen and directly go to the app or folder.



The shortcuts on the lock screen are the same ones on your Home screen's launch bar. To change the lock screen shortcuts, replace the apps or folders on the launch bar.




If you've set up another security layer like a screen lock pattern or PIN, you'll be asked to provide your credentials first before HTC One remix opens the app or folder.

---

## Sharing content

---

Have something to share, such as a photo or video?

- In an app, just tap the share icon:  or .
- If you don't see the icon, tap  > Share.


---


## Switching between recently opened apps

---


When you're multitasking and using different apps on HTC One remix, you can easily switch between the apps you've recently opened.

Press  to see recently-opened apps.



- To switch back to an app, just tap it.
- To remove an app from the list, drag it up.
- To clear the recent apps list, tap .



To see a list of apps that are running, tap .

---

## Refreshing content

---

In some apps, you can easily refresh content that's synced or downloaded from the Web with a simple finger gesture.

1. While viewing content such as weather or Mail inbox, scroll to the top of the screen.
2. Pull down with your finger, and then release to refresh.

---

## Capturing your phone's screen




---

Want to show off your high game score or write a blog post about HTC One remix features? It's easy to take a picture of the screen and share it from Gallery.

Press and hold POWER and VOLUME DOWN at the same time.

The image is saved in the Screenshots album in Gallery.



You can also share the image when you see  in the status bar. Open the Notifications panel and tap  under the screenshot notification. If you don't see , slide two fingers apart on the screenshot notification.



## HTC BlinkFeed

### Your dynamic Home screen

Get the latest about your interests or stay in touch with friends right on HTC BlinkFeed. Set up which social networks, news sources, and more will appear.



- Swipe up or down to browse stories on HTC BlinkFeed.
- Tap a tile to view the content or to comment on a post or status update.
- While viewing a news article, swipe left or right to see more stories.
- While in HTC BlinkFeed, you can press  $\Delta$  or  $\curvearrowright$  or tap the status bar to scroll to the top.
- Scroll to the top and pull down on the screen to manually refresh the stream.
- Swipe right on HTC BlinkFeed to open the slideout menu where you can choose the type of feeds or add your custom topics to display.




You'll see the clock widget on HTC BlinkFeed if you've set HTC BlinkFeed as the main Home screen.

---

## Turning HTC BlinkFeed on or off

---

1. On HTC BlinkFeed, slide two fingers together, and then tap .
2. While HTC BlinkFeed is selected, tap **Remove**.
3. To add it back, swipe right, and then tap the **+** button that has the word **BlinkFeed**.

---



## Ways of adding content on HTC BlinkFeed

---

Personalize HTC BlinkFeed to show articles and status updates from your favorite news sources, categories, editions, and apps.

### Selecting feeds

Discover stories and articles on HTC BlinkFeed based on your interests, favorite categories, and popular news channels or websites.


1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Add content**.
3. Choose a category.  
Or, if it's your first time to add content on HTC BlinkFeed, tap the tile that says **Get automatic recommendations from BlinkFeed**. Sign in to get recommendations.
4. Select one or more feed sources.  
You can tap a name first to check out a particular feed, and then tap  to add it to HTC BlinkFeed.

## Showing content from your apps and social networks

See your friends' posts in social networks or show content from your HTC apps right on HTC BlinkFeed.




You need to sign in to your social networks to see their feeds on HTC BlinkFeed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Services & Apps**, and then select the apps and social networks you like.


## Searching and adding a topic of interest

Looking for a more specific topic? Search for and select topics of interest to display them on HTC BlinkFeed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap **Search for content**, and then enter the topic you're looking for.
3. Tap a result, and then tap  to add it under Custom topics.

## Subscribing to multiple regional editions

Want to keep up to date on current events in more than one region? You can show one or more editions of your choice on HTC BlinkFeed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap  > **Add content**.

3. Tap ▼ , and then select a locale or region.
4. Select the feed sources to add.

---

## Customizing the Highlights feed

---

Go to the Highlights feed to see a mix of top trending articles and status updates from the feed sources you added. You can also set the Highlights feed to only show items from your favorite news sources, categories, and apps.



You cannot add custom topics to the Highlights feed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap ■ > **Settings** > **Choose Highlights topics**.
3. Select the feed sources you want to appear in Highlights.

---

## Saving articles for later

---

Don't have time to read that potentially interesting article? You can bookmark articles to your reading list.

Do one of the following:

- While viewing an article, tap ☰.
- On HTC BlinkFeed, press and hold the tile of the article you want to bookmark. Then tap **Read later**.

You'll find the reading list in the slideout menu.

---

## Posting to your social networks

---

You can easily post a status update from HTC BlinkFeed.

1. On HTC BlinkFeed, swipe right to open the slideout menu.
2. Tap **⋮** > **Compose**, and then choose a social network.
3. Compose your status update and post it on your social network.

---

## Removing content from HTC BlinkFeed

---

Whether it's a tile or an entire feed, you can remove content you don't want to see on HTC BlinkFeed.

- To remove a tile, press and hold the tile you want to remove, and then tap **Remove**.
- To remove a feed source, in the slideout menu, tap **⋮** > **Remove content**, select one or more items, and then tap **Remove**.  
To unsubscribe to a localized edition, tap **⋮** on the Remove content screen. Tap **Remove editions**, select one or more items, and then tap **Remove**.

## Notifications

---


### Notifications panel


---


Notification icons inform you of new messages, calendar events, alarms, and activities in progress such as files downloading.



When you see notification icons, open the Notifications panel to check out details of the notifications that you've received.

1. To open the Notifications panel, slide down from the top of the screen. If you have several notifications, scroll down the screen to see them all.
2. To quickly access the Notifications panel from Quick Settings, tap .




- To see more information, such as email previews and calendar events, slide two fingers apart to expand a notification. To collapse it, slide two fingers together.
- Some notifications allow you to take immediate action. For example, tap a missed call notification to return the call or reply with a text message.
- Tap the notification icon on the left to open the corresponding app.
- To dismiss just one notification in the list, drag it left or right. To dismiss all notifications and close the Notifications panel, tap .

## Notification LED

---

The notification LED shows a:



- Solid green light when HTC One remix is connected to the power adapter or a computer and the battery is fully charged.
- Flashing green light when you have a pending notification and the display is off.
- Solid orange light when the battery is being charged.
- Flashing orange light when the battery level reaches very low.

## Working with text

---


### Selecting, copying, and pasting text

---

In HTC apps such as Mail, you can select and copy text, and then paste or share it.

1. Press and hold on a word.
2. Drag the start and end anchors to highlight the surrounding text you want to select.





You can use the magnifier to zoom in while selecting your text. To turn on the magnifier, go to **Settings > Accessibility**, and then select the **Show magnifier** option. You'll see the magnifier when you press and hold one of the text selection anchors.

3. After you have selected the text you want to copy, tap **Copy**. The selected text is then copied to the clipboard.
4. In a text entry field (for example while composing an email), press and hold at the point where you want to paste the text.
5. Tap **Paste**.

## Sharing text

1. After you have selected the text you want to share, tap **Share**.
2. Choose where to paste and share the selected text, such as in an email message or social network status update.

## The HTC Sense keyboard

---

Typing is fast and accurate with the HTC Sense keyboard.

- Word prediction also saves typing time. As you type, you'll see word suggestions that you can choose from. You can even add words, phrases, and shortcuts to the word prediction dictionary. See [Entering text with word prediction](#) on page 69.
- You can type words by just speaking. See [Entering text by speaking](#) on page 72.
- Turn on the Trace keyboard so you can type words by just sliding your finger from one letter to another. See [Using the Trace keyboard](#) on page 71.
- Just swipe right to access the numeric and symbol keyboard. Or swipe left to switch between languages.
- The keys have secondary numbers, punctuation symbols, or other characters that you can insert without having to switch to the numeric and symbol keyboard.  
For example, just press and hold a key on the first row to insert a number.
- Choose from a wide selection of emoji.
- Show or hide navigational arrow keys on the keyboard. If you enable the arrow keys in Settings, they'll only appear on the portrait keyboard.



---

## Entering text


---

The onscreen keyboard becomes available when you tap a text field in an app. Enter letters and numbers, change the keyboard layout or language, and more.

Tap the keys on the onscreen keyboard to enter letters and numbers, as well as punctuation marks and symbols.

- Tap  to enter an uppercase letter. Tap twice to turn on caps lock.
- Press and hold keys with gray characters at the top to enter numbers, symbols, or accented letters. Some keys have multiple characters or accents associated with them.
- Swipe right to show number and symbol keys. To return to the main keyboard, swipe left.
- Press  to close the onscreen keyboard.



To open the keyboard settings, press and hold the comma key if you see  above the key. Or go to **Settings > Language & keyboard > HTC Sense Input**.

## Selecting a keyboard layout

Choose a keyboard layout that suits your typing style.

1. Go to Settings, and then tap **Language & keyboard > HTC Sense Input**.
2. Tap **Keyboard selection > Keyboard types**.
3. Select the keyboard layout that you want to use.

## Choosing and switching between keyboard languages

If multiple keyboard languages are available on HTC One remix, you can choose which languages to enable in the onscreen keyboard.

1. Go to Settings, and then tap **Language & keyboard** > **HTC Sense Input**.
2. Tap **Keyboard selection**, and then choose the languages you want.

To change the keyboard language, do any of the following:

- Swipe left on the onscreen keyboard (not available if you're using trace keyboard).
- Tap the language key (for example, **EN**) until you see the keyboard language you want to use.
- Press and hold the language key, and then drag your finger to the keyboard language you want to use.

---

## Entering text with word prediction

---

Ever started typing something you weren't sure how to spell? With word prediction, you'll see suggested words displayed just above the keyboard.



Word prediction and next word prediction are enabled by default.

To enter text in word prediction mode, do any of the following:

- Tap the space bar to insert a highlighted word in the suggestion list.
- Tap a word from the suggestion list.
- Tap the arrow next to the suggestion list to see more choices.



If you've accidentally chosen a wrong word from the suggestion list, you can always go back and change it by tapping the word and selecting another suggestion.

## Setting a second language for word prediction

You can set the word prediction to be bilingual. As you type, you'll get word suggestions in the languages that you've selected.



Bilingual prediction is available only when you're using a Latin-based keyboard.

1. Go to Settings, and then tap **Language & keyboard** > **HTC Sense Input**.

2. Tap **Keyboard selection** > **Bilingual prediction**, and then choose the language you want.

### Adding words and phrases to the word prediction dictionary

Add frequently-used names, acronyms, and even phrases to the word prediction dictionary to easily find them in the suggestion list.

Type even faster when you create text shortcuts to words and phrases. Instead of typing "Talk to you later", save a few keystrokes by adding the `ttl` shortcut. In your message or email, just type "`ttl`", and then tap the spacebar to enter the complete phrase.

1. Go to Settings, and then tap **Language & keyboard** > **HTC Sense Input**.
2. Tap **Personal dictionary** > **+**.
3. Enter a word or phrase, and then enter its text shortcut. Be sure to remember this shortcut, including the uppercase and lowercase letters you've typed.
4. Tap **OK**.




While you're entering text using the Standard keyboard layout, tapping a suggested word that's not in the dictionary (usually the first word shown in the suggestion list) automatically stores it.

### Editing or deleting words and phrases in the word prediction dictionary

1. Go to Settings, and then tap **Language & keyboard** > **HTC Sense Input**.

## 2. Tap Personal dictionary.

- To edit a word, phrase, or shortcut, tap the item in the list.
- To delete items from the dictionary, tap  > **Delete**. Select the words you want to remove, and then tap **Delete**.

---

## Using the Trace keyboard

---

Instead of tapping the keys on the onscreen keyboard, you can “trace” to type words.



You need to turn on the Trace keyboard in **Settings > Language & keyboard > HTC Sense Input**.

1. Slide your finger from one letter to the next to enter a word.
2. Lift your finger when the word is completed.
3. If you want to continue entering text, slide your finger over the letters again to enter the next word.



If the word that appears after you traced isn't the one you want, you can:


- Tap a word from the suggestion list.
- Tap the arrow next to the suggestion list to see more choices.

---

## Entering text by speaking

---

No time to type? Try speaking the words to enter them.

1. Tap an area where you want to enter text.
2. On the onscreen keyboard, press and hold .
3. When you see the animated microphone button and the words "Speak now", say the words you want to enter.



To set the voice input language, tap the language bar above the microphone button. You can choose one or more languages. Available languages may vary.

4. If a word doesn't match what you've spoken and it's underlined, tap the underlined word to delete it or to see more choices.
5. Enter punctuation marks by saying the name (for example, say "comma").

## Battery

---

### Displaying the battery percentage

---

You can check the percentage of remaining battery power right from the status bar.

1. Go to Settings, and then tap **Power**.
2. Select **Show battery level**.



---

## Checking battery usage

---

See a ranking list of apps that are using the battery. You can also see how much and how long the battery has been used for each app.

1. Go to Settings, and then tap **Power**.
2. Tap **Usage**, and then tap an app to check how it's using the battery. You'll see how much battery power is used by resources such as the CPU for the app and other use details.



If you see buttons while viewing an app's battery use details, you can tap them to adjust settings that affect battery usage, stop the app, and more.

---

## Checking battery history

---

Check how long you've been using HTC One remix since the last charge. You can also see a chart that shows how long the screen has been on, and how long you've been using connections like the mobile network or Wi-Fi.

1. Go to Settings, and then tap **Power**.
2. Tap **History**.
3. If you've used HTC One remix for a long time since the last charge, swipe left or right to scale the graph that details battery usage over time.

You can also slide two fingers together or apart to scale the graph.

---

## Tips for extending battery life

---

How long the battery can last before it needs recharging depends on how you use HTC One remix. HTC One remix power management helps to increase battery life.

If you like more control by tweaking settings on your own, try out some of these battery saving tips.

### Check your battery usage

Monitoring your battery usage helps you identify what's using the most power so you can choose what to do about it. For details, see [Checking battery usage](#) on page 73.

### Manage your connections

- Turn off wireless connections such as mobile data, Wi-Fi, or Bluetooth when not in use.
- Turn GPS on only when a precise location is needed, such as while using navigation or location-based apps. See [Turning location services on or off](#) on page 220.
- If the **Sleep mode** option in **Settings > Power** is enabled, at low peak times, your phone will turn off the data connection after the screen has been off for 15 minutes and there's no network activity (no downloads, streaming, or data usage). The data connection resumes when you switch the screen back on.
- Turn on Airplane mode when you don't need any wireless connections and you don't want to receive calls or messages.

## Manage your display

Lowering the brightness, letting the display sleep when not in use, and keeping it simple helps save battery power.

- Use automatic brightness (the default), or manually lower the brightness.
- Set the screen timeout to a shorter time.
- Don't use a live wallpaper for your Home screen. Animation effects are nice to show off to other people but they drain your battery. Changing your wallpaper to a plain, black background can also help a little. The less color is displayed, the less battery is used.

For more details, see [Settings and security](#) on page 259 and [Personalizing](#) on page 78.


## Manage your apps


- Install the latest software and application updates. Updates sometimes include battery performance improvements.
- Uninstall or disable apps that you never use.  
Many apps run processes or sync data in the background even when you're not using them. If there are apps that you don't need anymore, uninstall them.  
If an app came preloaded and can't be uninstalled, disabling the app can still prevent it from continuously running or syncing data. See [Disabling an app](#) on page 267.


## Limit background data and sync

Background data and sync can use a lot of battery power if you have many apps syncing data in the background. It's recommended not to let apps sync data too often. Determine which apps can be set with longer sync times, or sync manually.

- In Settings, tap **Accounts & sync** and check what types of data are being synced in your online accounts. When the battery is starting to run low, temporarily disable syncing some data.
- If you have many email accounts, consider prolonging the sync time of some accounts.

In the Mail app, select an account, tap  > **Settings** > **Sync, Send & Receive**, and then adjust the settings under Sync schedule.

- When you're not traveling from one place to another, sync weather updates of only your current location, rather than in all of your named cities. Open the Weather app, and then tap  to edit and remove unneeded cities.
- Choose widgets wisely.  
Some widgets constantly sync data. Consider removing the ones that are not important from your Home screen.

- In Play Store, tap  > **Settings**, and then clear **Add icon to Home screen** to avoid automatically adding Home screen app shortcuts whenever you've installed new apps. Also tap **Auto-update apps** > **Do not auto-update apps** if you're fine with updating apps from Play Store manually.

## Other tips

To squeeze in a little bit more battery power, try these tips:

- Tone down the ringtone and media volume.
- Minimize the use of vibration or sound feedback. In Settings, tap **Sound** and choose which ones you don't need and can disable.
- Check your apps' settings as you may find more options to optimize the battery.

# Personalizing

## Making HTC One remix truly yours

Make HTC One remix look and sound just the way you want it.

- Choose a ringtone and other sounds that you like to use. See [Ringtones, notification sounds, and alarms](#) on page 78.
- Personalize your Home screen with a different wallpaper. See [Home wallpaper](#) on page 79.
- Change the apps on the launch bar. See [Launch bar](#) on page 80.
- Populate your Home screen with widgets and shortcuts. See [Adding Home screen widgets](#) on page 81 and [Adding Home screen shortcuts](#) on page 83.
- Need another widget panel? See [Adding or removing a widget panel](#) on page 84.
- Set HTC BlinkFeed or a widget panel as your main Home screen. See [Changing your main Home screen](#) on page 86.
- Organize your apps. See [Arranging apps](#) on page 88.

## Ringtones, notification sounds, and alarms

1. Go to Settings, and then tap **Personalize**.

2. Under Sound, choose different sounds for your ringtone, system notification, and alarm.

Go to the Messages, Mail, Calendar, and Tasks apps to choose sounds for new messages, email, calendar, and task reminders respectively.



Want alarms to ring louder but notifications to be more discreet? In Settings, tap **Sound > Volumes** and set the volume levels for each sound type.

## Home wallpaper


Choose from the available wallpapers, or use any photo you've taken with the camera.


1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Choose wallpaper**.
3. Choose from where you want to select a wallpaper.
  - To use a photo you captured with the camera, tap **Gallery**, choose and crop a photo, and then tap **Done**.
  - Tap **Computer photos** to use the HTC Get Started service to choose a photo from your computer.

## Launch bar

The launch bar gives you one-touch access to commonly used apps (and other shortcuts). You can replace the apps on the launch bar with the ones you often use.

1. Press and hold the app you want to replace, and then drag it out to



2. Tap  to go to the Apps screen.
3. Press and hold an app, and then drag it to the empty slot on the launch bar.



- You can also group apps on the launch bar into a folder. See [Grouping apps on the widget panel and launch bar](#) on page 87.
- The apps (or other shortcuts) on the lock screen are the same as the ones on the launch bar.



## Adding Home screen widgets

Widgets make at-a-glance important information and media content easily available. Choose from a selection of widgets and add the most useful ones to your Home screen.

1. Press and hold an empty space on a widget panel.
2. In the pop-menu, tap **Add apps and widgets**.
3. Tap ▼ > **Widgets**.
4. Scroll through the widgets, or tap 🔍 to search for a specific widget.

Some widgets are available in different styles and sizes.

5. Press and hold and then drag the widget to a widget panel you want to add it to.


You can also add widgets that allow you to quickly switch on or off certain settings such as Wi-Fi and Bluetooth.


---

## Changing the settings of a widget

---

You can modify basic settings of some widgets (for example, the People widget).

1. Press and hold a widget on your Home screen, and then drag it to .



2. Customize the widget settings.

---

## Resizing a widget

---

Some widgets can be resized after you've added them to your Home screen.

1. Press and hold a widget on the Home screen, and then release your finger. If a border appears, that means the widget is resizable.
2. Drag the sides of the border to enlarge or shrink the widget size.

## Adding Home screen shortcuts

Place apps you often use on any widget panel of your Home screen. You can also add shortcuts to frequently used settings, bookmarked webpages, and more.

1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Add apps and widgets**.
3. Tap ▼ > **Apps** or **Shortcuts**.
4. Scroll through the apps or shortcuts, or tap 🔍 to search for one.
5. Press and hold and then drag an app or a shortcut to a widget panel you want to add it to.



To add an app from the Apps screen, press and hold the app, and then drag it to a widget panel.

## Editing Home screen panels

---

### Adding or removing a widget panel

---



- You won't be able to add a new widget panel if you've already reached the maximum limit.
- HTC BlinkFeed always appears as the first panel (if it's not removed). A widget panel cannot be added before HTC BlinkFeed.

1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Manage home screen panels**.
3. To add a new widget panel, swipe left until you see the **+** icon, and then tap it.
4. To remove a widget panel, swipe left or right until you see the panel, and then tap **Remove**.
5. When done, press **↶**.

### Arranging widget panels

---



A widget panel cannot be moved and inserted before HTC BlinkFeed.

1. On HTC BlinkFeed or any widget panel, slide two fingers together to customize the Home screen.

2. Press and hold a widget panel thumbnail, and then drag it left or right to the position that you want.
3. When you're done arranging widget panels, press **⌘**.


---

### Moving a widget or icon

---

You can easily move a widget or icon from one widget panel to another.

1. Press and hold the widget or icon with one finger.
2. With another finger, flick left or right to rotate the screen to another widget panel.




3. Release the widget or icon.

---


## Removing a widget or icon

---



1. Press and hold the widget or icon you want to remove, and then drag it to .
2. When the widget or icon turns red, lift your finger.

## Changing your main Home screen

Set HTC BlinkFeed or a widget panel as your main Home screen.


1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Manage home screen panels**.
3. Swipe left or right until you see the panel that you want to use as your main Home screen.
4. Tap **Set as home**.
5. Press .



Pressing  from an app will first return you to the last panel you were in. Just press  again to go to your main Home screen.

## Grouping apps on the widget panel and launch bar

1. Press and hold an app, and then drag it over to another app to automatically create a folder.




2. Tap the folder to open it.
3. Tap the folder window's title bar, and then enter a new folder name.
4. Add more apps into the folder. Tap **+**, select your apps, and then tap **Done**.

You can also add shortcuts to settings or information to a folder. Add a shortcut first to a widget panel, and then drag it over to the folder.

---




### Removing items from a folder

---

1. On the launch bar or widget panel, tap a folder to open it.
2. Press and hold an app or shortcut in the folder, and then drag it out to .

## Arranging apps






On the Apps screen, you can rearrange the apps and change the layout.

1. From HTC BlinkFeed or any widget panel, tap .
2. Tap , and then choose how to arrange apps, such as alphabetically.  
If you want to group apps into folders or rearrange them, select **Custom**.
3. Tap  > **Grid size** to choose whether to display more or fewer apps per page.

---

## Moving apps and folders

---

1. On the Apps screen, tap  > **Custom**.
2. Tap  > **Rearrange apps**.
3. Press and hold an app or folder, and then do one of the following:
  - Drag the app or folder to another position on the same page. Wait until you see the occupying icon move away before releasing your finger.
  - Drag the app or folder to the  or  arrow to move it to another page.
4. When you're done moving apps and folders, tap .



---

## Grouping apps into a folder

---

1. On the Apps screen, tap ▼ > **Custom**.
2. Tap ■ > **Rearrange apps**.
3. Press and hold an app, and then drag it over to another app to automatically create a folder.
4. To add more apps, drag each app over to the folder.
5. To name the folder, open the folder, tap its title bar, and then enter a folder name.
6. When done, tap ✓.

---

## Removing apps from a folder

---

1. On the Apps screen, tap ▼ > **Custom**.
2. Tap ■ > **Rearrange apps**.
3. Tap the folder to open it.
4. Press and hold an app, and then drag it out to the Apps screen. Wait until you see the occupying icon move away before releasing your finger.
5. When you're done removing apps, tap ✓.

---

## Hiding or unhiding apps

---

1. On the Apps screen, tap ■ > **Hide/Unhide apps**.

2. Select the apps you want to hide, or clear their check boxes to unhide them.
3. Tap **Done**.

## Lock screen

---

### Changing the lock screen wallpaper

---

Use the home wallpaper, or use any photo you've taken with the camera as the lock screen wallpaper.

1. Go to Settings, and then tap **Personalize**.
2. Tap **Lock screen wallpaper**
3. In the pop-up menu, tap **Use home screen wallpaper** or tap **Use custom wallpaper** to select a photo from Gallery.

---

### Adding a widget on the lock screen

---

Choose from our selection of lock screen widgets.




Before you can add a widget on the lock screen, you must select the **Enable lock screen widgets** option in **Settings > Security**.

1. On the lock screen, pull from the right edge until you see a **+** icon.
2. Tap **+**.

3. Tap a widget that you want to add to the lock screen.

### Moving or deleting a lock screen widget

1. On the lock screen, pull from the right edge until you see the widget you want to move or delete.
2. Press and hold the widget, and then drag it left or right to the position that you want.
3. Press and hold the widget, and then drag it to  to remove it.

---

### Changing lock screen shortcuts

---

To change apps (or other shortcuts) on the lock screen, change the ones on the launch bar. To find out how, see [Launch bar](#) on page 80.

---

### Turning the lock screen off

---

Rather not have to unlock your phone every time you wake it up? You can turn the lock screen off in Settings.


1. Go to Settings, and then tap **Security**.
2. Tap **Screen lock > No lock screen**.


To turn the lock screen on again, in Security settings, tap **Screen lock > Lock screen**.

# Camera

## Camera basics

Take great photos and videos with the camera, and make them more memorable by applying a variety of filters and scenes.

Open the Camera app and tap  to see all controls on the Viewfinder screen. You can use the controls to switch capture modes, add filters, set the flash, and more.



See a collection of camera scenes when taking photos and videos.

Choose an ISO level or set it back to **Auto**. Higher ISO works best in low light conditions.

Adjust the exposure settings. Higher exposure settings capture more light for your photos or videos.



Select a white balance setting that matches your current lighting environment.



Apply photo or video filters.



Modify basic and advanced camera settings.

---

## Choosing a capture mode

---

HTC One remix gives you a variety of capture modes to use.

On the Viewfinder screen, tap , and then select a capture mode to use.

---

## Zooming

---

- Before taking a photo or video, slide two fingers apart to zoom in or together to zoom out.
- When you're recording video, you can freely zoom in or out while recording.

---

## Applying a filter

---

Use the available filters to make your photos and videos look like they've been taken through special lenses.



Some camera modes may not support filters.

1. On the Viewfinder screen, tap  to show the camera options.

2. Tap , and then choose one of the available filters.

---

### Turning the camera flash on or off

---

Tap the flash icon to choose a flash mode.



When using Flash on or Auto flash mode, the camera intelligently sets the best flash brightness for your photo.

---

### Using the volume buttons for taking photos and videos

---


If you feel much comfortable with using push-buttons when taking photos and videos, you can set HTC One remix to use the VOLUME buttons as the Camera app's shutter release or zoom controls.



1. Switch to **Camera** or **Video** mode.
2. On the Viewfinder screen, tap  to show the camera options.
3. Tap  > **Volume** button options.
4. Choose how you want to use the volume buttons when you're in the Camera app.


---

## Closing the Camera app


---

To give you a full view of the Viewfinder screen, HTC One remix replaces , , and  with small dots.

Tap a dot to show these buttons again, and then tap  or  to close the Camera app and return to the Home screen or the previous screen.



## Taking a photo

1. Open the Camera app.
2. Switch to **Camera** mode.
3. Point the camera at what you want to capture. The camera adjusts the focus automatically as you move it.
4. When you're ready to take the photo, tap .

## Tips for capturing better photos

To get better captures with the Camera app, here are some tips on what to do while taking your shots.

### Improving focus and sharpness

- HTC One remix has autofocus, which works best on a subject that is not moving too much. To change the focus, on the Viewfinder, tap the one you want to focus on.
- If the subject is moving, on the Viewfinder, press and hold the subject to lock the focus.
- You can manually adjust the sharpness of a photo by editing in Gallery. You can also set the sharpness before taking a photo in the Camera settings.

Generally, it is better to sharpen a blurry image rather than to reduce the sharpness in an image.

### Taking well-lit photos

- HTC One remix automatically adjusts the focus and exposure. If the image appears underexposed or that it appears dark on the Viewfinder, tap a part of the image that is in shadow. Conversely, tap a well-lit object in the image if the image seems to be overexposed. Focus on an object with a neutral tone for a balanced exposure. Keep in mind that tapping on another object may shift the focus from your subject.







- If you are using the default settings and the photo still appears too dark, switch to Night scene, but place HTC One remix on a level surface to keep it steady.
- If there are parts of the image that are in shadows and others are in highlights, use HDR to capture multiple shots of different exposures and combine them into one shot. Keep HTC One remix steady or place it on a level surface when using HDR.
- When taking a panoramic photo, consider the whole scene and focus on an object that has a neutral tone to help keep the exposure balanced in the composite image.
- If your subject is lit from the back, use Backlight scene to highlight the foreground and keep some details of the background.

## Other tips

- In Camera settings, tap **Grid** to help frame the subject better or improve the composition.
- If taking photos under fluorescent or incandescent bulbs and the subject appears to be off-color, tap **AWB**, and then choose a white balance setting. Check the image on the Viewfinder and select the option that displays the closest color to the natural color of the subject.
- In Camera settings, you can tap **Image adjustments** and adjust the contrast, saturation, and sharpness before taking the photo.
- After capturing the photo, you can continue to edit the contrast, brightness, and other settings in Gallery.

## Recording video

1. Open the Camera app.
2. Switch to **Video** mode.
3. When you're ready to start recording, tap .
4. Change focus to a different subject or area by just tapping it on the Viewfinder screen.
5. Tap the flash icon to turn the flash on or off.
6. Tap  to pause the recording, and then tap  to resume.
7. To stop recording, tap .


---

### Taking a photo while recording a video — VideoPic

---




Choose **Normal** scene to use this feature.

While you're recording video using the main camera, tap  to capture a still shot of your subject.

---

### Setting the video resolution

---

1. Switch to **Video** mode.
2. On the Viewfinder screen, tap  to show the camera options.
3. Tap .



4. Tap **Video Quality**, and then choose a video resolution.

## Taking continuous camera shots

Do you want to take photos of moving subjects? Whether it's your kid's football game or a car race, you can capture the action.



Choose **Auto** scene to use this feature.

1. Open the Camera app.
2. Switch to **Camera** mode.
3. On the Viewfinder screen, just press and hold . The camera takes up to 20 consecutive shots of your subject.
4. To keep just one photo, select the photo that you like the most, and then tap **Best shot**.  
To save the photos as a batch, press .

## Taking selfies

No one around to take your photo?

1. Open the Camera app.
2. Switch to **Selfie** mode.  
Or, switch to the front camera by swiping from the left or right edge of your phone's screen.





3. Tap anywhere on the screen to start the timer. The camera takes a photo after the countdown.



Some camera features are not available when you're using the front camera, such as zooming.

## Improving portrait shots

If you'd like your family or friends to look their best in your photos, make sure to use the Portrait scene. It smoothens the skin of the people in your shots.

1. Open the Camera app.
2. Switch to **Camera** or **Selfie** mode.
3. On the Viewfinder screen, tap  to show the camera options.
4. Tap  > .
5. When you're ready to take the photo, tap .





## Taking a panoramic photo

Get a wider shot of landscapes in one sweep.



Some camera features are not available when you're in this mode, such as zooming.

1. Open the Camera app.


2. Switch to **Camera** mode.
3. On the Viewfinder screen, tap  to show the camera options.
4. Tap , and then tap .
5. When you're ready to take the shot, tap .
6. Pan left or right in either landscape or portrait view. Hold HTC One remix as smoothly as you can to automatically capture frames.




You can also tap  to stop capturing anytime.

The camera stitches the frames into a single photo.

## Using HDR

When shooting portraits against a bright background, use HDR, short for High Dynamic Range, to capture your subjects clearly. HDR brings out the details of both the highlights and shadows, even in high contrast lighting.

 HDR works best when your subject is steady. The camera takes multiple shots at different exposure levels and combines them into one enhanced photo.






1. Open the Camera app.
2. Switch to **Camera** mode.
3. Tap , and then tap .
4. To take an HDR photo, tap .

## Recording videos in slow motion

Relive high speed action bit by bit and add a touch of suspense to your videos.




Audio is recorded when you're in this scene, but will only be available when video is played back in normal speed.


1. Open the Camera app.
2. Switch to **Video** mode.
3. On the Viewfinder screen, tap  to show the camera options.
4. Tap  beside the menu button, and then tap .
5. Tap  to start recording.
6. To stop recording, tap .

## Manually adjusting camera settings

Want to take expert command of your camera settings for different environments or lighting conditions. You can manually increase or decrease the values for settings like white balance, exposure, ISO, and more.

1. Open the Camera app.
2. Switch to **Camera** mode.
3. On the Viewfinder screen, tap  to show the camera options.

4. Tap **AUTO**, and then tap **M**.
5. Tap an item at the bottom of the Viewfinder screen, and then drag its slider up or down to adjust the setting.



6. When done, tap **⏏** to show or hide the manual settings.
7. Tap **📷** to take a photo.



You can save your customized settings as a new camera mode.

## Saving your settings as a camera mode

Save a scene or custom settings as a new camera mode so you can conveniently use it anytime you need it.

1. Open the Camera app.
2. Switch to the camera mode you want to use.



Some camera modes may not support modifying the camera settings.

3. On the Viewfinder screen, tap to show the camera options.
4. Modify the settings as desired.
5. When done, tap > **Save custom camera**.
6. Enter a name, and then tap **Save**.

To select and use the newly created camera mode, tap on the Viewfinder screen.

---

### Modifying a camera mode you've created

---

1. Switch to a camera mode that you've created.
2. Modify the scene or settings.
3. Tap > **Save custom camera**.
4. Tap **Yes** to save changes to the existing mode.



To delete a custom camera mode, tap . Press and hold a camera mode you've created, and then drag it to to delete it.



# Gallery

## Viewing photos and videos in Gallery

Reminisce about good times. Use Gallery to view all your photos and videos. View them by time, album, or location. When viewing your photos and videos, the onscreen navigation buttons will be hidden. Tap anywhere on the screen to see Gallery controls and onscreen navigation buttons.

## Viewing photos and videos organized by time

Photos and videos on HTC One remix are grouped together in Timeline view according to when they were taken.

1. On the Gallery app's main screen, swipe to the Timeline tab. You'll see thumbnails for every time period.
2. Scale the time period by sliding two fingers together or apart or tapping ▼. You can choose between event, day, month, and year.
3. Tap a time period to see all related photos and videos.
4. Tap a photo or video to see it in full screen.

## Viewing photos and videos by album

1. On the Gallery app's main screen, swipe to the Albums tab.

2. Tap a tile to open an album.
3. Tap a photo or video to see it in full screen.

---

### Viewing photo highlights

---



Easily see all your favorite photos in one place. Gallery automatically groups all your most viewed or shared photos (your highlights) in one album. You can also manually edit the Highlights album.

- To view these favorite photos, open the Highlights album.
- To manually add a photo, find and view the photo in full screen, tap the photo, and then tap ★.
- To remove a photo from the Highlights album, press and hold the thumbnail and then tap **Remove**.

---

### Copying or moving photos or videos to another album

---

1. On the Gallery app's main screen, swipe to the Albums tab.
2. Tap a tile to open an album.
3. Tap  > **Move to** or **Copy to**.
4. Select the photos or videos you want to move or copy and then tap **Next**.
5. Select an album to move or copy the photos or videos to. To create a new album to move or copy to, tap .




To move or copy a single photo or video, open an album and then press and hold the photo or video. Choose whether to move or copy the photo or video and then select the destination album or create a new album.

---

## Showing or hiding albums

---

Have too many albums cluttering up Gallery? You can choose to show or hide albums.

1. On the Gallery app's main screen, swipe to the Albums tab.
2. Tap  > **Show/hide albums** and choose which albums you'd like to show or hide.

---

## Renaming an album

---

If you have created albums to organize photos, you can rename these albums.

1. On the Gallery app's Albums tab, press and hold the album that you want to rename.
2. Tap **Rename**.





Some albums, such as Camera shots and Highlights, cannot be renamed.

## Viewing photos by location


Using Map view, you can view photos according to location.



Only photos with geo-tag info appear on the map.

1. On the Gallery app's main screen, swipe to the Locations tab. You'll see tiles of photos taken at specific locations, with numbers that indicate how many photos were taken in each location.
2. Tap  to display Map view.
3. Zoom out or pan across the map until a numerical location indicator  appears. The number in the location indicator shows how many photos were taken in that area.
4. Tap the location indicator to see the photos taken in that area.



Want to know where you took a particular photo? While viewing the photo in full screen, tap anywhere on the screen, and then tap  > **Show on map**. (**Show on map** is available when you've enabled Geo-tag photos in Camera.)

---

## Adding location information

---

Want to specify more than just the city? You can add names of points of interests (POI) to your photos too.

1. On the Gallery app's main screen, swipe to the Locations tab.
2. Tap a tile to open it.
3. Swipe to the Places tab.
4. Tap **Tap to edit location > Add a new place**.
5. Tap a point of interest to add a POI from Foursquare\* or tap **New place** to manually enter a new name.
6. Tap **Save**.

---

## Changing location information

---

1. On the Gallery app's main screen, swipe to the Locations tab.
2. Tap a tile to open it.
3. Swipe to the Places tab.

4. Find the grouping you want to rename, then tap **⋮** and try one of the following:

**Selecting another POI**

1. Tap **Edit location** > **Tap to edit location**.
2. Tap a point of interest to add a POI from Foursquare or tap **New place** to manually enter a new name.
3. Tap **Save**.



**Renaming the location**




1. Tap **Rename this place**.
2. Enter a new name.
3. Tap **Save**.

You'll only see **Rename this place** if the name is stored on HTC One remix.

## Editing your photos

Make your pictures even better. Gallery has an array of editing tools that let you crop, rotate, apply and create photo filters, and much more to your photos.

1. In Gallery, open the photo you want in full screen, tap it, and then tap .
2. Do any of the following:
  - Tap  to apply a special effect to the photo.

- Tap  to apply a filter to the photo.
  - Tap  to add a decorative frame to the photo.
  - Tap  to draw, rotate, crop, flip, or straighten the photo.
3. Tap **Save**.







Except for when applying rotation, edited photos are saved as copies of the original.

---

## Drawing on a photo

---

Get more creative with your photos or highlight an interesting part.

1. In Gallery, open the photo you want in full screen, tap it, and then tap .
2. Tap  > **Draw**.
3. Tap  and then choose a pen stroke, color, and thickness.
4. Draw on the photo.
5. Tap **Done** > .

The edited photo is saved as a copy. The original photo remains unedited.







---

## Applying custom filters to photos

---




Filters can only be applied to photos that are stored locally.






1. In Gallery, open the photo you want in full screen, tap it, and then tap .
2. Tap  > . You'll find  at the right end of the predefined filters bar.
3. On the Custom Effects screen you can:
  - Make changes to the filter by adjusting the controls on exposure, saturation, white balance, and more.
  - Rearrange filters to modify the effect. Press and hold the filter you want to move. Then drag it to a new position.
  - Remove filters. Press and hold the filter you want to remove. Then drag it to **Remove**.
  - Tap  to add more filters.
4. Tap **Save Preset** to name your filter and save it. After saving your filter, you'll see a preview of your photo with the filter applied.
5. Tap  to save the modified photo as a new photo.



## Creating an animated gif

Create an animated gif that you can quickly upload and share.

 You can save a batch of shots that was captured with continuous shooting mode as an animated gif.

1. In Gallery, open the photo you want in full screen, tap it, and then tap .
2. Tap  > . You'll see an animation of the frames.
3. Drag the trim sliders to the part where you want the animated gif to begin and end.
4. Tap Next.
5. On the next screen, you can choose the direction you want the animation to play, set the speed of the animation, choose which frames you want to include, and more.
6. Tap  to save, or tap  to save and share the edited GIF.





The edited photo is saved as a copy. The original photo remains unedited.

## Creating an action sequence shot

Hop, skip, or jump. Create a sequence shot to stitch a series of actions into one photo.



This feature is available for a batch of shots that was captured with continuous shooting mode.

1. In Gallery, open the photo you want in full screen, tap it, and then tap .
2. Tap  > . You'll see frames that you can combine in one photo.
3. Select the frames that you want to include in the sequence shot.
4. Tap Done > .


The edited photo is saved as a copy. The original photo remains unedited.




## Editing a group shot

Finding it difficult to choose a group shot with the most smiles and the fewest blinks? Retouch a group shot so everyone looks their best in the photo.



This feature is available for a batch of shots that was captured with continuous shooting mode.

1. In Gallery, open the photo you want in full screen, tap it, and then tap .

2. Tap  > . You'll see circles around any faces detected in the photo.
3. Select one face at a time and drag it sideways with your finger to select the expression you want.
4. Tap Done > .






The edited photo is saved as a copy. The original photo remains unedited.

## Removing unwanted objects in a photo

Did a pedestrian or passing car ruin your otherwise perfect shot of a famous landmark? Retouch the photo to remove unwanted people or objects.



This feature is available for a batch of shots that was captured with continuous shooting mode.


1. In Gallery, open the photo you want in full screen, tap it, and then tap .
2. Tap  > . You'll see frames around areas in the photo where objects have been automatically removed.
3. To retain an object, tap  on its image on the film strip.
4. Tap Done > .



The edited photo is saved as a copy. The original photo remains unedited.

## Trimming a video

1. On the Gallery app's main screen, swipe to the Timeline or Albums tab.
2. Tap a tile to open a time period or album.
3. When you see the video you want, tap it to play in full screen.
4. Tap the onscreen controls to pause or resume playback, adjust the volume, and more.



Tap  to share the video on your home network.


5. To trim the video, tap  > **Edit**.
6. Drag the trim sliders to the part where you want the video to begin and end.
7. Tap  to preview your trimmed video.
8. Tap **Save**.

The trimmed video is saved as a copy. The original video remains unedited.

## Saving a photo from a video

It's easy to save a still shot from a video.

While you're watching a video in Gallery, tap  to capture a still shot.

You can also pause the playback and drag the slider to the image you want before tapping .

## Creating a Zoe in Gallery

When you view a group of photos and videos such as an album, Gallery automatically composes a Zoe™. A Zoe is a collection of photos and videos that Gallery has preselected, with added background music and special effects.

You can change the content, theme, and music. You can also save or share the Zoe as a video.

1. On the Gallery app's main screen, swipe to the Timeline, Albums, or Locations tab.
2. Tap a tile to open a group of photos and videos. You'll then see the Zoe play automatically.
3. In portrait view, tap the Zoe tile if you want to edit it.
4. To change the content in the Zoe:
  - Swipe to the Content tab to select the ones you want to include in the Zoe.
  - Tap **⋮** > **Remix** to shuffle the content.
  - Tap **⋮** > **Choose start and end clips** to select specific photos or videos to start and end the Zoe.
5. Swipe to the Themes tab to choose the special effects and music to apply to the Zoe.
6. Swipe to the Music tab, tap **Search my library** to change the background soundtrack for all themes.  
To restore the default soundtrack, tap **⋮** > **Restore theme's music**.



Do not reproduce, distribute, or otherwise use copyrighted materials in connection with the Zoe unless you have secured the copyright owner's permission first.

7. To trim the chosen soundtrack and include audio that was captured with the video included in the Zoe, tap **⋮** > **Music settings**.
8. To preview the Zoe in full screen, hold HTC One remix in landscape orientation.
9. To create a video file of the Zoe, tap **⋮** > **Save**, and then choose a video quality.

Your video will be saved in the Zoe Highlights album.



# Phone calls

## Making a call with Smart dial

You can either dial a number directly, or use Smart dial to quickly place a call. Smart dial searches and calls a stored/synced contact or a number from your call history.

1. Open the Phone app.
2. Enter the phone number or first few letters of the contact's name to see the top matching contact.
3. If there are a number of matches found (for example, 8 matches), tap the number to see all the matches.
4. Tap the contact you want to call.




- To check other phone numbers associated with the contact, tap  beside the contact name.
- If the phone number has an extension, tap  after connecting to the main line and then dial the extension number.

## Making a call with your voice

Call a contact hands-free using your voice.

1. Open the Phone app.

2. Tap .
3. Say the name of contact you want to call. For example, say "Call [person's name in phonebook]."
4. Follow screen instructions to make the call.


## Dialing an extension number

To skip voice prompts when dialing an extension number, do one of the following:

- After dialing the main number, press and hold **\***. The letter **p** is added to the number you are dialing. Enter the extension number, and then tap **Call**. You will be connected to the mainline and then to the extension number.
- After dialing the main number, press and hold **#** to add a **w**. Enter the extension number after the letter **w**, and then tap **Call**. After connecting to the main line, tap **Send** to dial the extension number.

You can save phone numbers with an extension in the People app.

## Returning a missed call

You'll see the missed call icon  in the status bar when you miss a call.



1. Slide the Notifications panel open to check who the caller is.
2. To return the call, spread your two fingers on the missed call notification to expand it, and then tap **Call back**.



If you have multiple missed calls, tap the missed calls notification to open the Call History tab.

## Speed dial

Use Speed dial to call a phone number with a single tap.

1. Open the Phone app.
2. Tap  > **Speed dial** > . You can also press and hold an unassigned key on the dialpad, and then tap **Yes**.
3. Select a contact from the list.
4. On the Speed dial screen, choose the phone number of the contact to use, and a speed dial key to assign.
5. Tap **Save**.

To use Speed dial, press and hold the speed dial number you want to call.

## Calling a number in a message, email, or calendar event

When you receive a text message, email, or calendar event that has a phone number in it, you can just tap the number to place a call.

## Making an emergency call



If you don't have a network signal, you won't be able to make an emergency call.

1. Open the Phone app.
2. Dial the emergency number for your locale, and then tap **Call**.



If you've enabled but forgotten your lock password or lock pattern, you can still make emergency calls by tapping **Emergency call** on the screen.

## Receiving calls

When you receive a phone call from a contact, the Incoming call screen appears.





HTC One remix will automatically adjust the ringtone volume when you use the polite ringer and pocket mode features.

---

### Answering or rejecting a call

---

Do one of the following:

- If the display is on when you get a call, tap **Answer** or **Decline**.
- If the display is locked when you get a call, drag  or  upwards.
- Press the POWER button twice to reject a call.

---

### Muting the ringing sound without rejecting the call

---

Do one of the following:

- Press the VOLUME DOWN or VOLUME UP button.
- Press the POWER button.
- Place HTC One remix face down on a level surface.



If HTC One remix is already facing down, it will still ring when there are subsequent incoming calls.

## What can I do during a call

When a call is in progress, use the buttons onscreen to mute or unmute the microphone or to turn the speakerphone on or off.




---

### Turning the speakerphone on or off during a call

---





To decrease potential damage to your hearing, do not hold HTC One remix to your ear when the speakerphone is on.

- On the call screen, tap . The speakerphone icon  appears in the status bar.
- To turn the speakerphone off, tap .

---

### Muting the microphone during a call

---


On the call screen, tap  to toggle between turning the microphone on or off. When the microphone is turned off, the mute icon  appears in the status bar.

---

### Ending a call



---

Do one of the following to end the call:

- On the call screen, tap **End Call**.
- Slide the Notifications panel open, then tap .

## Setting up a three-way call


Three-way calling with your friends, family, or co-workers is easy. Make the first call, and then dial another number to add it to the call.

1. Make a call to the first participant.
2. When connected, tap  > **Add call**, and then dial the number of the second participant. The first participant is put on hold when you dial the second participant.
3. When connected to the second participant, tap .

To end the call, tap **End call**.

## Call History

Use Call History to check missed calls, your dialed numbers, and received calls.

1. Open the Phone app.
2. Swipe to view the Call History tab.
3. Do one of the following:
  - Tap a name or number in the list to call.
  - Press and hold a name or number in the list to display the options menu.
  - Tap  to display just a particular type of call such as missed calls or outgoing calls.

---

## Adding a new phone number to your contacts from Call History

---

1. On the Call History tab, tap **+** next to the new phone number.
2. Choose whether to create a new contact or save the number to an existing contact.

---

## Clearing the Call History list

---

1. On the Call History tab, tap **⋮** > **Remove call history**.
2. Select the items you want to delete, or tap **⋮** > **Select all**.
3. Tap **Delete**.

---

## Blocking a caller

---

When you block a phone number or a contact, all calls from the phone number or contact will be declined automatically.

On the Call History tab, press and hold the contact or phone number you want to block, and then tap **Block contact**.



You can always remove a caller from your blocked list. On the Call History tab, tap **⋮** > **Blocked contacts**. Press and hold a contact, and then tap **Unblock contacts**.

## Changing ringtone settings

---

### Switching between silent, vibrate, and normal modes

---

Do one of the following:

- To change from silent to normal mode, press the VOLUME UP button.
  - To change from vibrate to normal mode, press the VOLUME UP button twice.
  - Go to Settings, and then tap **Sound > Sound profile**.
- 

### Lowering the ring volume automatically

---

HTC One remix has a quiet ring feature that automatically lowers the ring volume when you move it.

1. Go to Settings, and then tap **Sound**.
  2. Select the **Quiet ring on pickup** option.
- 

### Making HTC One remix ring louder in your pocket or bag

---

To help avoid missing incoming calls when HTC One remix is in your pocket or bag, the pocket mode feature gradually increases the ring volume and vibrates when you receive a call.

1. Go to Settings, and then tap **Sound**.
2. Select the **Pocket mode** option.

## Global Ready

HTC One remix offers you reliable, consistent voice service at home and abroad.

Use one phone and one number for voice coverage in more than 205 countries. Get one bill for both domestic and international calls.

In order to get the full benefits of Global Phone service you must subscribe to a Global Phone calling plan. Go to [verizonwireless.com/global](http://verizonwireless.com/global) for rates, countries, coverage limitations and features.



Voice and data roaming charges may apply. Data service plans sold separately.

## Using Assisted dialing

When you're on a trip abroad, it's easy to dial friends and family from home. Your home country code is automatically added when you make calls to your contacts while roaming.

1. On the Home screen, tap **Phone**.
2. Enter the phone number or first few letters of the contact's name to see the top matching contact.
3. If there are a number of matches found (for example, 8 matches), tap the number to see all the matches.



4. Tap the contact you want to call.

If you selected a contact whose phone number has a leading zero, HTC One remix will automatically prepend it with your home country code when dialing. If there's already a plus (+) sign and country code before the phone number, HTC One remix will just dial as is.




HTC One remix dials as is and does not prepend your home country code when you call phone numbers that are not stored in HTC One remix. When manually entering a phone number to call, you need to enter a plus (+) sign and country code before the number.

---

## Editing a country's international call settings

---

1. Go to Settings, and then tap Call.
2. Tap Assisted Dialing > Reference Country.
3. Under Reference Country, select the country whose settings you want to edit.
4. Tap  > Edit.
5. Edit the **Country Code**, **IDD Prefix** (International Direct Dial), **NDD Prefix** (National Direct Dial), **Area/City Code** and **National Number Length** (length of phone number).
6. Tap Save.
7. Tap Done.

---

## Resetting the reference country to default

---

1. Go to Settings, and then tap **Call**.
2. Tap **Assisted Dialing > Reference Country**.
3. Under Reference Country, tap the bar and select the country whose settings you want to set to default values.
4. Tap **⋮ > Set Default**.
5. Tap **Done**.

---

## Turning off Assisted dialing

---

1. Go to Settings, and then tap **Call**.
2. Tap **Assisted Dialing**.
3. Clear the **Use Assisted Dialing** option.
4. Tap **↩**.

## Changing the HTC One remix network connection

HTC One remix is set to Global mode and connects to the appropriate network (CDMA or GSM) in your location. In countries where both CDMA and GSM networks are present, you can select which network to use.



Voice and data roaming charges may apply.

1. Go to Settings, and then tap **Call**.
2. Tap **Preferred Network**, and then select the phone network you want to use.



# Messages

## Verizon Messages

---


### Sending a text or multimedia message via Verizon Messages

---

1. Open the Verizon Messages app.
2. Tap .
3. Enter a contact name or mobile number in the **To** field, or tap  to select a contact from the People app.
4. Tap the box that says **Type a message**, and then enter your message.



Your text message becomes a multimedia message when you attach an item or if you are sending to multiple recipients. Group Messages are also charged as a multimedia message (MMS).

5. To add a multimedia attachment, tap **+**, choose an attachment type, and then select or create the item to attach.
6. Tap **Send**, or tap  to save the message as a draft.



For more information about Verizon Messages, visit [www.verizonwireless.com/vzmessages](http://www.verizonwireless.com/vzmessages).

## HTC Messages


---

### Sending a text message (SMS)

---

1. Open the Messages app.
2. Tap **+**.
3. Enter a contact name or mobile number in the **To** field.
4. Tap the box that says **Add text**, and then enter your message.
5. Tap , or press  to save the message as a draft.







- There is a limit on the number of characters for a single text message (displayed above ). If you exceed the limit, your text message will be delivered as one but will be billed as more than one message.
- Your text message automatically becomes a multimedia message if you enter an email address as the recipient, attach an item, or compose a very long message.

### Sending a multimedia message (MMS)

---

1. Open the Messages app.
2. Tap **+**.
3. Enter a contact name, mobile number, or email address in the **To** field.
4. Tap the box that says **Add text**, and then enter your message.


5. Tap , and then choose an attachment type.
6. Select or browse for the item to attach.
7. After adding an attachment, tap  to see options for replacing, viewing or removing your attachment.
8. Tap , or press  to save the message as a draft.



---

## Sending a group message

---


Group messaging makes it easy to send a message to multiple contacts all at once. You can choose to send a group SMS or group MMS.

 The text or MMS message you send for each recipient will count towards your monthly message allowance. For example, if you send a group text message to five contacts, five text messages will be deducted from your monthly message allowance.

1. Open the Messages app.
2. Tap .
3. Tap , and then select multiple recipients.
4. Tap OK on the Group Messaging dialog box.

5. Tap the button below the To field, and then select how you want to send the group message.

<b>Individual messages</b>	Your message will be sent to the recipients as individual text message. Your recipients will not see anyone on the list and can reply only to you.
<b>Group conversation</b>	Similar to a group chat, sending a group MMS lets your recipients join the conversation you've started. HTC One remix also organizes message replies in a single conversation thread. If this is your first time to send a group MMS, you may need to enter your mobile phone number.


6. Tap the box that says **Add text**, then enter your message.
7. Tap .

---


## Resuming a draft message

---

If you switch to another app or if you receive an incoming call while composing a text message, the message is automatically saved as a draft.

Open a draft message right from the All messages screen, edit the message, and then tap .




To see all draft messages in one place, tap  on the Messages screen, and then tap **Drafts**.

---

## Replying to a message



---

1. On the All messages screen, tap a contact (or phone number) to display the exchange of messages with that contact.
2. Tap the box that says **Add text**, and then enter your message.
3. Tap .

### Replying to a contact's other phone number

When a contact has multiple phone numbers stored on HTC One remix, you can select which phone number to reply to.

Keep in mind that if you don't select another number, your response will be sent to the phone number that your contact used to send the last message.

1. On the All messages screen, tap a contact (or phone number) to display the exchange of messages with that contact.
2. Tap  and select which phone number you want to reply to.
3. Tap the box that says **Add text**, then enter your reply message.
4. Tap .

---

## Saving a text message as a task

---

Save a text message in your Tasks list so you can remind yourself when to reply.

1. On the All messages screen, tap a contact (or phone number) to display the exchange of messages with that contact.



2. Tap the message you want to save, and then tap **Save as task**.

---

## Forwarding a message


---

1. On the All messages screen, tap a contact (or phone number) to view the exchange of messages with that contact.
2. Tap a message, and then tap **Forward**.

---

## Copying a text message to the nano SIM card

---

1. On the All messages screen, tap a contact (or phone number) to display the exchange of messages with that contact.
2. Tap the message, and then tap **Copy to SIM**. A nano SIM card icon  is displayed.

---


## Deleting messages and conversations

---

On the All messages screen, do any of the following:


### Delete a message

Open the conversation thread with a contact, tap the message, and then tap **Delete message**.

To delete multiple messages within a conversation, tap  > **Delete messages** > **Delete by selection**, and then select the messages to delete.

**Delete a conversation**

Press and hold a contact (or phone number), and then tap **Delete**.


To delete multiple conversations, on the All messages screen, tap  > **Delete threads**, and then select the conversations to delete.



In the Messages settings, tap **General** > **Delete old messages** to auto delete old messages.

**Preventing a message from being deleted**

You can lock a message to prevent it from being deleted even if you delete the other messages in the conversation.

1. On the Messages screen, tap a contact (or phone number) to display the exchange of messages with that contact.
2. Tap the message that you want to lock.
3. Tap **Lock message** on the options menu. A lock icon  is displayed.

# Search and web browser

## Searching HTC One remix and the Web

You can search for information on HTC One remix and on the Web. In the Google app, start your search by entering a keyword or by using Google Voice Search™.

To open Google, tap **Google** on the Apps screen. Or just swipe up from the onscreen navigation buttons.



Some apps, such as People or Mail, have their own search function, which you can use to search only within those apps.


---

## Performing searches on the Web and HTC One remix

---

1. Open the Google app.



If you've already set up a Google account on HTC One remix, you will be given the option to sign in to Google Now™. To sign in to Google Now at a later time, tap . See [Getting instant information with Google Now](#) on page 141.

2. In the search box, enter what you want to search for. As you type, matching items on HTC One remix and suggestions from Google web search are shown.



To search for the information exclusively on HTC One remix, swipe your finger up the screen, and then tap **Search Phone**.



3. If what you're searching for is in the list of suggestions, tap the item to open it in its compatible app.

---

### Searching the Web with your voice

---



Use Google Voice Search to find information on the Web by speaking to HTC One remix.

1. Open the Google app.
2. Tap , and then say what you want to search for. After speaking, matching items from Google web search are shown.
3. If what you're searching for is in the list, tap the item to open it in its compatible app. Otherwise, tap  to search again.


---

### Setting search options

---

1. Open the Google app.
2. Tap  > **Settings**, and then tap an option you want to set.
3. To get help or provide feedback, tap  > **Help & feedback**.



You can also access the settings when viewing the search results. Pull down the screen to show the hidden menu button, and then tap  > **Settings**.

## Getting instant information with Google Now

Do you want to check the weather or your morning commute time before you start your day? Google Now delivers quick and up-to-date information that matters to you—all without the search.

Depending on your location, time of day, and previous Google searches, Google Now displays information cards that include:

- The day's weather and the weather forecast for upcoming days.
- The traffic conditions on your way to work or your commute back home.
- The directions and travel time to your next appointment.
- The next train or bus arriving at your platform or bus stop.
- Your favorite team's score and stats while you enjoy the game.
- Time or location based reminders that you can set.

Open the Google app to use Google Now. To open, tap **Google** on the Apps screen. Or just swipe up from the onscreen navigation buttons.

---

## Setting up Google Now

---



Before setting up Google Now:

- Make sure that you're signed in to your Google account.
- Turn location services on and make sure that you have an Internet connection. For more information on location services, see [Turning location services on or off](#) on page 220.

1. Open the Google app.



To launch Google Now from the lock screen, drag ^ up the screen.

2. Tap **Next** on the **Get Google Now!** screen.
3. Tap **Yes, I'm in**. Google Now information cards will start to appear on the Google search screen.
4. To see all available information cards, swipe up the screen and tap **More**.



Depending on the information that you've allowed to share, more information cards will appear on the Google search screen as you use HTC One remix to search the Web, create appointments, set reminders, and more.

---


## Changing card settings

---

You can easily customize the settings of Google Now cards to suit your information needs. For example, you can change the weather units in the Weather card or your transportation mode in the Traffic card.

1. Open the Google app.
2. Do any of the following:
  - To change a card setting, such as the weather unit on the Weather card, tap , and then tap the arrow buttons when available.
  - To change specific card information such as your work address and sports teams or stocks you follow, scroll to the bottom of the screen, tap , and then tap the information you want to change.

## Dismissing and hiding cards



1. Open the Google app.
2. Do any of the following:
  - To dismiss a card, swipe it left or right.
  - To keep the card from appearing on the Google search screen, tap  on the card you want to hide, and then tap **No**.

---

## Setting reminders in Google Now


---

Creating reminders in Google Now is an easy way to keep tab of things to do. You can set time or location-based reminders. When the reminder time is up or when you've arrived at the specified location, Google Now displays the Reminder card in the Google search screen and sounds a notification to alert you.

1. Open the Google app.
2. Scroll to the bottom of the screen, and then tap  > .
3. Enter the reminder title, such as the task you want to be reminded of.
4. Select **When** to set a time-based reminder or **Where** to set a location-based reminder.
5. Set the reminder time or location details.
6. Tap **Remind me at this time** or **Remind me at this place**.

When the reminder time is due or when you've arrived at the location, the Reminder card will appear in the Google search screen. You can then dismiss or snooze the reminder.



To see a list of all your reminders, scroll to the bottom of the Google search screen, and then tap .



---

## Refreshing Google Now

---

Refresh Google Now to update the information cards or show relevant cards for information that you've just added on HTC One remix, like an upcoming event in Calendar.

1. Open the Google app.
2. Pull down the screen with your finger, and then release to refresh.

---

## Turning off Google Now

---

1. Open the Google app.
2. Scroll to the bottom of the screen, and then tap **⋮** > **Settings**.
3. Tap the **On/Off** switch next to Google Now, and then tap **Turn off**.

## Browsing the Web

Visit your favorite websites or search the Web using Google Chrome™.

1. Open the Chrome app.
2. Tap the URL box on top of the screen.
3. Enter the webpage address or your search keywords.
4. To open more browser tabs, tap **☰**.
5. To return to the previous webpage you've viewed, press **↶**.

## Bookmarking a webpage

Add your favorite webpages as bookmarks so you can access them quickly.

1. While viewing a webpage, tap **⋮** > ☆ .
2. On the Add Bookmark screen, you can edit the bookmark name and save the bookmark in a new category folder.
3. Tap **Save**.

To view and open a bookmark, tap **⋮** > **Bookmarks** . Navigate to the bookmark you want to open, and then tap it.

## Clearing your browsing history

1. While viewing a webpage, tap **⋮** > **Settings** > **Privacy**, and then tap **Clear browsing data**.
2. Choose which types of data to delete, and then tap **Clear**.

# Entertainment

## Music

---

### Listening to music

---

Enjoy your favorite songs on HTC One remix using the Music app.

**F** When you open the Music app for the first time, you'll be asked if you would like to automatically download related content, such as album covers and artist photos, to HTC One remix.

1. Open the Music app.
2. Swipe to the different tabs to browse by category.
3. Tap a song to play.
4. Tap the onscreen icons to control music playback, repeat songs, and more.



Press and drag your finger across the progress bar to jump to any part of the song.



Turn shuffle on or off. (Shuffle is off when button is gray.)



Cycle through the repeat modes: repeat all songs, repeat current song, and don't repeat.



Play your music on a DLNA® compliant TV or audio system, HTC Media Link HD, or stereo Bluetooth device.



Minimize the Now playing screen to continue browsing your music collection.



When you're listening to music and the screen display turns off, press POWER to turn the screen back on and control the music playback directly on the Lock screen.

---

## Playing music from the Lock screen

---

If you want to launch the Music app directly from the Lock screen, go to Settings, and then tap **Security > Unlock Music automatically**.

You can:

- While playing music and the screen turns off, press **POWER** to turn the screen back on, swipe down from the Music widget, and then tap on the widget.
- If you've added the Music app as a shortcut on the launch bar, drag it up to open the Music app.

---

## HTC BoomSound profile

---

With the HTC BoomSound profile turned on, you'll still enjoy enhanced audio quality even when you plug in a headset. Listen to stronger bass, clearer vocals, and finer details in songs and videos, especially when played in Music and Gallery apps.

To turn the HTC BoomSound profile on or off, go to **Settings**, and then tap the BoomSound **On/Off** switch.

---

## Music playlists

---

Personalize your music experience by creating music playlists. Make a playlist containing just your favorite songs or create one to match your mood for the day. You can make as many playlists as you like.

1. Open the Music app.
2. Swipe to the Playlists tab.

3. Tap **+**, and then enter a playlist name.
4. To add songs, tap **+** beside the title text box, browse your music collection, and then tap a song to add.  
Repeat this step to add more songs.
5. You can also:

<b>Rearrange songs</b>	Press and hold <b>≡</b> next to the song title you want to move, and then drag it to its new position.
<b>Delete songs</b>	Select the songs you want to remove from the playlist.
<b>Change playlist name</b>	Type the new name of the playlist in the title text box.

6. Tap **Save**.

You'll find newly created playlists on the Music app's Playlists tab.

To edit or delete a playlist you've created, from the Playlists tab, tap a playlist to open it, and then tap **⋮** > **Edit playlist** or **Delete**.

---

### Adding a song to the queue

---

While playing a song, you can also browse other tracks stored on HTC One remix. Add a song or an album to the queue so it plays when the current playlist has finished playing.

1. While a song is playing, browse for other tracks.

2. Do any of the following:
  - Browse for the album or playlist that you want, press and hold it, and then tap **Add to queue**.
  - Browse for an artist or song, and then tap **⋮** > **Add to queue**.

The songs you've added appear on the Queue tab.

---

## Updating album covers and artist photos

---

**F** To save on data usage, you might want to connect to a Wi-Fi network when updating your album covers and artist photos. In Music settings, select **Wi-Fi only**.

1. Open the Music app.
2. Swipe to the Artists or Albums tab.
3. Tap **⋮** > **Update artist photos** or **Update album art**.

If you want HTC One remix to automatically check and update your music collection, tap **⋮** on the Music app's main screen, and then tap **Settings**. Select **Album art** and **Artist photos**.


---

## Setting a song as a ringtone

---



Pick a song from your Music library and set it as your ringtone or as ringtone for a favorite contact.

1. Open the Music app.

2. Play the song that you want to set as a ringtone.
3. Tap  > **Set as ringtone**.
4. Tap **Phone ringtone** or **Contact ringtone**. If you select **Contact ringtone**, choose the contacts you want to associate the ringtone with.

### Trimming an MP3 ringtone

Use the Music app's ringtone trimmer if you want to set only a part of the song as ringtone.

1. When you find the song that you want, tap  > **Set as ringtone** > **Trim the ringtone**.
2. Drag the trim sliders  to the part where you want the ringtone to begin and end.  
For a more precise trimming, tap the left or right arrow buttons. Time markers indicate where you are on the song.
3. When you're done trimming, tap **Set as**.
4. Choose whether to set your trimmed song as your **Phone ringtone** or **Contact ringtone**.



You can see your new ringtone in the phone settings. Go to **Settings > Sound > Ringtone**.



---

## Viewing song lyrics

---

Love a song so much that you want to sing along? HTC One remix gives your music an extra kick with song lyrics and cool music visualizations.



To save on data usage, connect to a Wi-Fi network when downloading lyrics. In Music settings, select **Wi-Fi only**.

1. Open the Music app.
2. Browse to the song you want to play and tap it.
3. Swipe to the Visualizer tab to view the lyrics. Song lyrics appear onscreen if content has been successfully downloaded.



Want a different visual for your music? Tap **⋮** > **Scene** and select a scene. If you want the scene to change for every song, select **Random**.

4. Tap the screen to display the lyrics in full screen.
5. To jump to another part of the song, tap the screen to make the progress bar appear. Press and drag your finger across the progress bar, or press and hold **▶▶** or **◀◀**.



Not all languages are supported.

---

## Finding music videos on YouTube

---

It's easy to find music videos of the song you're listening to on YouTube. On the Now playing screen, tap **⋮** > Search > YouTube.

## YouTube

---

### Watching videos on YouTube

---

Check out the latest video sensations using the YouTube app.

1. Open the YouTube app.
2. Browse or search for a video.
3. When you find the video that you like, tap it.



Want to watch the video at a later time instead? Tap **⋮** next to the video title, and then tap **Add to** > **Watch later**. You can access the video again from your account profile's Watch Later list.

4. While watching a video, you can:
  - Turn HTC One remix sideways to watch the video in full screen.
  - Tap the video screen to pause or to resume playback, or drag the slider to jump to a different part of the video.
  - Scroll down the video information panel to see related videos and comments from other viewers.
  - Browse other videos by minimizing the video screen. Tap **✓** or drag the video screen down to minimize. To close the video thumbnail, swipe it left or right.

Minimize the video screen, and then tap  to open the slideout menu. You can view your account profile and manage your subscriptions and video lists.

---



## Creating video playlists


---

Organize your favorite videos into playlists and watch them in the YouTube app.



Make sure that you're signed in to your Google account.

1. Open the YouTube app.
2. Browse or search for a video.
3. Tap  next to the video title, and then tap **Add to > New playlist**.
4. Enter the playlist name, and then tap **OK**.  
If you don't want to share the video playlist, select **Private** before you tap **OK**.
5. To add another video to your playlist, browse or search for the video, and then tap  next to the video title.
6. Tap **Add to**, and then tap the playlist name.

To access and watch your video playlists, minimize the video screen and then tap  to open the slideout menu. Tap the playlist you want.

## Wireless media

---

### Connecting to your home entertainment system

---

Want to make your HTC One remix experience bigger and louder? By swiping up with three fingers, share your videos, music, and even streaming media to external devices.

You can share through:

- DLNA (see [HTC Connect](#) on page 159 and [Sharing your media on DLNA devices](#) on page 159)
- HTC Media Link HD (see [About HTC Media Link HD](#) on page 157)
- A2DP (Bluetooth) or other supported display connections



Some devices may need to be paired before you can share to them.

---

## About HTC Media Link HD

---

Plug in HTC Media Link HD to any TV with an HDMI port. Then swipe up with three-fingers on HTC One remix to connect and display content wirelessly to your TV.



HTC Media Link HD is sold separately.

### Multitask with dual-screen display

HTC Media Link HD gives you dual-screen display when you're:

- Viewing a video in Gallery
- Playing music in the HTC Music app

While you're playing media on the big screen, you can multitask and do other things such as take calls, browse the Web, or send email on HTC One remix.

## Turns your TV into a digital photo frame

Use the TV screen saver feature to store up to 30 photos from HTC One remix on HTC Media Link HD, and display them as a slideshow on your TV.

To find out more about setting up HTC Media Link HD and using it with HTC One remix, refer to the HTC Media Link HD user guide.

---

## HTC Connect

---

Looking for a new DLNA home entertainment system? Find one that has the HTC Connect™ logo.



Connecting your HTC phone to an HTC Connect certified device is fast and easy. You'll also be able to remotely control media playback, adjust the volume, and more.

For more information, see [www.htc-connect.com](http://www.htc-connect.com).

---

## Sharing your media on DLNA devices

---

**F** If you'll be using a DLNA compliant TV or audio system, refer to its documentation on how to connect it to your home network.

1. Connect HTC One remix to your home network via Wi-Fi.
2. Open the Gallery or Music app.
3. Locate the media stored on HTC One remix that you want to share, and then tap it.

4. Swipe up with three fingers to show the Media output screen.
5. Choose the device on your network where you want to play the media.
6. Once connected to the device on your network, tap the onscreen controls to control playback, adjust the volume, and more.



For more information about DLNA, visit [www.dlna.org](http://www.dlna.org).



# Storage

## Phone storage

---

### Types of storage

---

Want to know what types of storage you can use for your apps, data, and files?

HTC One remix has these storage types:

<b>Phone storage</b>	This storage combines both the internal storage, where apps, email, data, and text messages are stored, and the file storage, where photos, videos, and music files are kept. If you are running out of phone storage, see <a href="#">Making more storage space</a> on page 163 for some tips on how to free up space.
<b>Storage card</b>	Use a storage card for storing more files. You can also set some apps to store data or files directly to the card.

**USB storage**

When you plug in an external USB storage device (such as a USB flash drive or an SD card reader), you can view photos and videos stored on the device right from Gallery and play songs stored on the device in Music. You can also open PDFs and edit Office documents.

You need a special cable to connect HTC One remix and a USB storage device. HTC One remix supports USB storage devices (except portable hard drives) up to 64 GB.



- Moving apps to the storage card doesn't back up the apps. If you do a factory reset, your phone loses the apps. You'll need to reinstall them.
- When you remove the storage card and insert it in another phone, the apps on the storage card won't be installed automatically to the other phone. You'll need to reinstall them.

---

## Copying files to or from HTC One remix

---

You can copy your music, photos, and other files to HTC One remix.



Save and close your files before copying them from your computer to HTC One remix, or vice versa.

1. Connect HTC One remix to the computer using the supplied USB cable. You'll see options for viewing or importing files on the computer screen.

2. Choose to view files.
3. Copy the files from your computer to HTC One remix, or vice versa.
4. After copying the files, disconnect HTC One remix from the computer.

---

## Making more storage space

---

As you use HTC One remix, you'll accumulate data and fill its storage capacity over time. Here are some tips on how to increase storage space.

### Run the storage wizard

Free up space in the storage by uninstalling apps and deleting files you no longer want to keep. In Settings, tap **Storage > Make more space**.

### Manage photos and videos

- After taking continuous camera shots, keep only the best shot. Discard the rest, if you don't need them.
- After editing a photo or trimming a video, the original file is kept. Delete original files or move them elsewhere, such as to your computer.
- If you're only sending videos through MMS, use a lower resolution. Hi-res video takes up more space. In Camera settings, tap **Video Quality** to change the resolution.

## Back up data and files

Keep only the most recent data in your apps and files that you often need to use. You can back up your other data and files. For some tips, see [Ways of backing up files, data, and settings](#) on page 173.

## Disable some apps

See [Disabling an app](#) on page 267.

## Move some apps to the storage card

Some third-party apps can be moved from the phone storage to the storage card. Go to **Settings > App manager > On SD card** to see which apps can be moved. To move, tap an app, and then tap **Move**.



- Moving apps to the storage card doesn't back up the apps. If you do a factory reset, your phone loses the apps. You'll need to reinstall them.
- When you remove the storage card and insert it in another phone, the apps on the storage card won't be installed automatically to the other phone. You'll need to reinstall them.

---

## About storage encryption

---

On the phone storage, you can encrypt data such as your accounts, settings, downloaded apps and their data, media, and other files. On a storage card, you can only encrypt files.

Set a lock screen PIN or password before you start encryption. Fully charge the battery first, or keep HTC One remix connected to the power adapter during encryption. This process may take about an hour or so.

You cannot undo encryption on the phone storage. If you want to return to an unencrypted phone, you must perform a factory reset.

Once you enable storage card encryption, only new files added after encryption will be encrypted. Files already on the card will not be encrypted. Also, storage card encryption doesn't reformat or erase your card. Encrypted files on the storage card can only be opened by the phone that encrypted them.

## How to encrypt

1. Go to Settings, and then tap **Storage**.
2. Tap **Phone storage encryption**. Or, tap **Encrypt SD card content**.
3. Tap **Next**.
4. Enter the lock screen PIN or password, and tap **Next**.
5. Tap **Enable encryption**.

During phone storage encryption, the phone may restart a few times. When storage encryption is complete, enter your PIN or password.



If you turn off SD card encryption to stop encrypting new files, previously encrypted files will remain encrypted. To access these files, you must enable encryption again for your storage card.

## Google Drive

---

### Using Google Drive on HTC One remix

---

Store your photos, documents, and other files on Google Drive to access them on HTC One remix, your computer, and your other mobile devices.

On HTC One remix, just use your Google Account to sign in to your Google Drive storage. You can then:

- Use Gallery to upload your captured photos to Google Drive.
- Share a link to your Google Drive files by email.
- View and edit Office documents that are stored in Google Drive. After creating new Office documents, you can also save them to Google Drive.
- View PDFs that are stored in Google Drive. You can also export Office documents as PDFs to Google Drive.
- Check your available Google Drive storage space in Settings.
- Use the Google Drive app to manage your online storage.



Uploading files requires you have the Drive app installed on HTC One remix. If this app is not preloaded, you can download and install it from Google Play.

---

## Activating your free Google Drive storage

---

Use up to 65GB of free Google Drive storage. In addition to the default storage that you get from Google Drive, HTC One remix features an additional 50GB of online storage free for two years. Sign in to your Google Account on HTC One remix—and not from your computer or other non-HTC phones—to claim this offer.

1. If you see the promotional Google Drive offer on the Feeds panel of your Home screen, just tap the tile.  
Or open the Drive app. If this app is not preloaded on your phone, you can download it from Google Play.
2. On the screen that shows the additional storage offer, tap **Redeem**. The additional storage will then be added to your account.
3. Follow the onscreen prompts to learn the things you can do with Google Drive.



- If you don't see the screen for redeeming the offer, tap **☰ > Product Tour** in the Drive app to access it.
- View the offer details to know up to when you can redeem the offer.
- Additional terms and requirements may apply, including a subscription fee, after your two-year trial expires. For details, refer to the terms and conditions on the Google Drive support site at [support.google.com/drive/?p=drive\\_offers\\_htc](https://support.google.com/drive/?p=drive_offers_htc).
- The Drive app is owned by Google and is not provided by or associated with HTC Corporation.

---

## Checking your Google Drive storage space

---

In Settings, you can check your available Google Drive storage space.



Before your Google Drive storage info appears in Settings, you need to access your Google Drive from an HTC app first, such as signing in to Google Drive from the Mail app when sharing a file link.

Go to Settings, and then tap **Storage**. Under Online storage, you'll see your Google Drive storage space.


From time to time, check back on how much online storage space you still have before you upload more content.

---

## Uploading your photos and videos to Google Drive

---

Use Gallery to upload your photos and videos to Google Drive.

1. On the Gallery app's main screen, swipe to the Timeline, Albums, or Locations tab.
2. Tap an album or event that contains the photos and videos you want to upload.
3. Tap .
4. From the selection menu, tap **Drive**.
5. Select the photos and videos you want to upload, and then tap **Next**.
6. Choose or create a folder in Google Drive.






7. Tap **OK** to upload.

---

## Sharing links to documents or files in Google Drive

---

No more attaching large files to your email. Using the Mail app, you can easily share links to documents or other files in your Google Drive by email.

1. Open the Mail app.
2. If you have several email accounts, switch to an email account you want to use.
3. Create a new email message and fill in your recipients, or reply to an email.
4. Tap .
5. Tap **Document**, and then choose whether to share PDFs or Office documents.  
Or tap **File** to choose any file type.
6. On the HTC files screen, tap **Drive**.  
If you don't see this screen, press  first.
7. In your Google Drive storage, open the folder that contains the files that you want.
8. Select the files you want to share, and then tap **OK**.  
You'll then see the links to your selected files added to your email message.
9. Tap  to send your email.

Shared links are not accessible by your recipients automatically. Once your recipients receive the link, they can request access, and then you'll receive

an email that notifies you to give them access. Or, before sharing, you can first use the Drive app to add the recipients you will share your Google Drive link with.

---

## Giving people access through the Drive app

---

Using the Drive app, add the people you want to share your Google Drive link with. You can also set permissions, such as to let the recipients view, edit, or comment on your shared content.

1. Open the Drive app.
2. Tap ⓘ next to a file or a folder, depending on which one you will share.
3. Tap 👤.
4. Enter the first few characters of the name or email address. Matching results from your Google contacts will then be listed.
5. Select a contact name or email address, and then select the permissions. You can set permissions to allow recipients to:
  - View or edit a folder.
  - View, edit, or comment on a file.
6. Tap Add.
7. Add more people, and when done, tap ✓ or press ↵.

# Sync, backup, and reset

## Online sync

---

### Adding your social networks, email accounts, and more

---

You can sync contacts, calendars, and other information from your social networks, email accounts, and online services on HTC One remix. Depending on the account type, signing in to your online accounts lets you sync updates between HTC One remix and the Web.

1. Go to Settings, and then tap **Accounts & sync**.
2. Tap **+**.
3. Tap the account type you want to add.
4. Follow the onscreen instructions to enter your account information.



- In **Settings > Accounts & sync**, tap the **Auto sync On/Off** switch to turn automatic sync of all your accounts.
- You can add several Google Accounts.

---

### Syncing your accounts

---

1. Go to Settings, and then tap **Accounts & sync**.

2. Tap the Auto sync **On/Off** switch to turn automatic sync of all your accounts on or off.
3. To manually sync individual accounts, tap an account type, and then do one of the following:
  - Tap **⋮** next to the account you want to sync, and then tap **Sync now**.
  - Tap **⋮** > **Sync now** on the Account settings screen.



On the Account settings screen, you can also change the sync settings for an account.

---

## Removing an account

---

Remove accounts from HTC One remix if you no longer use them. Removing an account does not remove accounts and information from the online service itself.

1. Go to Settings, and then tap **Accounts & sync**.
2. Tap an account type.
3. Tap **⋮** next to the account you want to remove.  
Or if you're on the Account settings screen, tap **⋮**.
4. Tap **Remove**.



Some personal data may be retained by the third-party app after you have removed the account from HTC One remix.

## Backup

---

### Ways of backing up files, data, and settings

---

Worried that you might lose important stuff on HTC One remix? Back up HTC One remix before you erase the storage, do a factory reset, or upgrade to a new phone.

#### HTC Sync Manager

Use HTC Sync Manager to import music, photos, and videos from HTC One remix to your computer. You can also sync locally stored contacts, calendar events, bookmarks, and playlists between HTC One remix and your computer.

Likewise, HTC Sync Manager is a good alternative if you don't want to back up your accounts, settings, and other personal content to the cloud. You can use it to create backups of HTC One remix on your computer.

#### Other backup options

If you want, you can separately back up your data or files.

Some apps allow you to back up data to the phone storage or storage card so you can easily restore them after a factory reset. Just make sure not to erase the phone storage or storage card when you do a factory reset.

- F**
- Moving apps to the storage card doesn't back up the apps. If you do a factory reset, your phone loses the apps. You'll need to reinstall them.
  - When you remove the storage card and insert it in another phone, the apps on the storage card won't be installed automatically to the other phone. You'll need to reinstall them.

---

**Messages**    Back up your text messages to the phone storage or storage card, or save them as an email attachment.

---

**Contacts**

- Save contacts and other personal data to your online accounts so you can just sync them when switching to another phone.
- If you have locally stored contacts in the People app, export them to the phone storage or storage card.

---

**Files**    Manually copy and paste files by connecting HTC One remix to your computer as a disk drive.

---

**Other data**

- If you added new words to your personal dictionary in the onscreen keyboard, back up the dictionary to the storage card or save it as an email attachment.
- Check the other apps to see if they support exporting data to the storage.

---

---

## Verizon Cloud

---

Keep your digital lives connected, even when real life has you on the go. Sync and save your important photos, videos, music and documents with Verizon Cloud's storage. Go to [verizonwireless.com/cloud](http://verizonwireless.com/cloud).

---

## Backing up your data locally

---

If you want to separately back up your content such as contacts and text messages on HTC One remix, here are some tips on how to export or import your data.

### Backing up your contacts

1. Open the People app.
2. On the People tab, tap **⋮** > **Manage contacts**.
3. Tap **Import/Export contacts** > **Export to phone storage** or **Export to SD card**.
4. Select an account or type of contacts to export.
5. To help protect your data, tap **Yes**, and then set a password for this backup. Be sure to remember this password. You'll need to enter it again when importing contacts.  
If you don't need a password, tap **No**.
6. Tap **OK**.

### Restoring contacts

1. On the People tab, tap **⋮** > **Manage contacts**.

2. Tap **Import/Export contacts** > **Import from phone storage** or **Import from SD card**.
3. If you have more than one account set up, tap the type for the imported contacts.
4. If you have multiple backups available, select the backup you want to import, and then tap **OK**.
5. Enter the password you've set for this backup, and then tap **OK**.

### Backing up your text messages

Keep important text messages by backing them up to the phone storage. You can easily restore backed up text messages after you've deleted them from your message list.


1. Open the Messages app.
2. Tap **⋮** > **Back up/Restore SMS** > **Back up** > **Back up SMS**.
3. To help protect your data, set a password for your backup. Be sure to remember this password. You'll need to enter it again when restoring messages.  
If you don't need a password, select **Do not password protect this backup**.
4. Enter a name for your backup file, and then tap **OK**.



## Backing up text messages by email




You need to set up your email account in the Mail app.

1. Open the Messages app.
2. Tap  > **Back up/Restore SMS**.
3. Tap **Back up** > **Back up SMS via mail**.
4. To help protect your data, set a password for your backup. Be sure to remember this password. You'll need to enter it again when restoring messages.

If you don't need a password, select **Do not password protect this backup**.

5. Enter your email address.
6. Compose your email message, and then send it.

## Restoring text messages

1. Open the Messages app.
2. Tap  > **Back up/Restore SMS** > **Restore**.
3. Choose how you want to restore the messages, and tap **Next**.
4. Tap the backup to import.
5. Enter the password you've set for this backup. If you didn't set a password, select **This backup file is not password protected**.

## 6. Tap OK.

To restore text messages that were backed up via email, open the email message with the backup file attachment from the Mail app. Tap the attachment to download it first, and then tap it again to open the backup file to import. Enter the password you've set for this backup or select **This backup file is not password protected**.

### Backing up your personal dictionary

You can back up new words you've added to the predictive text dictionary.

1. Go to Settings, and then tap **Language & keyboard**.
2. Tap **HTC Sense Input**.
3. Tap **Personal dictionary** > **⋮** > **Back up to storage card** or **Back up to email**.
4. When prompted, tap **OK**.

### Importing your personal dictionary

- Go to **Settings** > **Language & keyboard** > **HTC Sense Input**. Tap **Personal dictionary** > **⋮** > **Restore from storage card**.
- To import your personal dictionary backed up via email, open the email message with the backup file attachment from the Mail app. Tap the attachment to download it first, and then tap it again to open the backup file to import.

### Backing up or restoring tasks

1. Go to the list that contains the tasks you want to back up.

2. Tap **⋮** > **Import/Export**.
3. Tap **Export to SD card** to back up your tasks, or tap **Import from SD card** to restore tasks on HTC One remix.

---

## Backing up settings to Google

---

You can choose to automatically back up some settings such as Wi-Fi and bookmarks to Google servers using your Google Account so you can restore them when needed.

1. Go to Settings, and then tap **Backup & reset**.
2. Tap the Backup **On/Off** switch to turn it on.

To add more backup accounts, tap your Google account and then tap **Add account**.

## HTC Sync Manager

---

### About HTC Sync Manager

---

HTC Sync Manager supports a computer running a Windows or Mac® operating system.

Here's what you can do with HTC Sync Manager.

### View and manage media on your computer and phone

- Browse and manage music, photos, and videos that are on your computer and your phone.

- Import iTunes and Windows Media® Player playlists from your computer to HTC Sync Manager.
- Play music, videos, and playlists using the built-in player.

## Transfer content

- Transfer iPhone photos, text messages, contacts, and more to your HTC phone. You can also find and install the same apps that you were using on your iPhone.
- Import all music, photos, and videos from your HTC phone to your computer.
- Copy selected music, photos, or videos from your computer to your phone.
- Import documents from your computer to your phone.

## Back up and restore

Back up your HTC phone to your computer so you can easily restore your backup to the same phone or to another HTC phone.

## Sync playlists and data

Sync music playlists and data such as contacts and calendar between your phone and your computer.

---

## Installing HTC Sync Manager on your computer

---



- You can install HTC Sync Manager on Windows XP or later versions. To install it on a Mac computer, you need Mac OS 10.6 or later versions.
- If you have problem in installing HTC Sync Manager, close all your running programs and reinstall. If the problem persists, temporarily disable your anti-virus program and try installing again.

1. Download the HTC Sync Manager installer from the HTC support site: [htc.com/hsm/](http://htc.com/hsm/).
2. Launch the installer and follow the onscreen instructions.
3. Connect your phone to your computer using the supplied USB cable. HTC Sync Manager opens.



If you disabled your anti-virus program, make sure to turn it back on after installing HTC Sync Manager.

---


## Transferring iPhone content and apps to your HTC phone

---

With HTC Sync Manager, easily transfer iPhone content such as contacts, messages, wallpaper, camera photos, and more to your HTC phone. If you're using an HTC phone that has HTC Sense 6, HTC Sync Manager also enables your phone to find and install the same apps that you were using on your iPhone.

**F** You need to use iTunes 9.0 or later to back up your iPhone content first to your computer.

1. Connect your iPhone and your HTC phone to your computer.
2. In HTC Sync Manager, click **Home** > **Transfer & Backup**.
3. Click the **Get Started** button.
4. If you haven't used iTunes to back up your iPhone content to your computer, please do so before proceeding.
5. Select your iPhone backup file, and then click **OK**.
6. Select the types of content you want to transfer to your HTC phone.  
You can choose whether to replace the content on your HTC phone with the iPhone content.
7. Click **Start**. Wait for HTC Sync Manager to finish transferring content.

8. When done, slide open the Notifications panel on your HTC phone, and then tap .

Choose which apps you were using on iPhone you want to find in Google Play and download to your HTC phone.


---

## Getting help

---

To find out more about using HTC Sync Manager, download the user guide PDF from the HTC support site ([htc.com/hsm/](http://htc.com/hsm/)). Or open the Help that comes with the software.



On Windows, click  in HTC Sync Manager, and then click **Help**.

## Reset

---

### Restarting HTC One remix (Soft reset)

---

If HTC One remix is running slower than normal, is unresponsive, or has an app that is not performing properly, try rebooting and see if that helps solve the problem.

1. If the display is off, press the POWER button to turn it back on. If you've set up a lock screen, you need to unlock it.
2. Press and hold the POWER button, and then tap **Restart**.
3. When asked to confirm, tap **Restart**.

## HTC One remix not responding?

If HTC One remix does not respond when you touch the screen or press the buttons, you can still restart it.

Press and hold the POWER and VOLUME UP buttons for at least 10 seconds. HTC One remix then restarts.

---

### Resetting HTC One remix (Hard reset)

---

If HTC One remix has a persistent problem that cannot be solved, you can perform a factory reset (also called a hard reset or master reset). A factory reset reverts the phone back to its initial state — the state before you turned on the phone for the first time.

The following will be removed from the phone when you do a factory reset:

- Your Google Account
- All accounts you've added in **Settings > Accounts & sync** and the data associated with these accounts
- Personal data that you've created or synced to the phone such as your profile, contacts, messages, email, calendar events, and more
- System and application data and settings
- Downloaded apps



Files such as your music, photos, videos, and documents can also be deleted from the storage, if you chose to do so.

Be sure to back up any data and files you want to keep before you do a factory reset.



A factory reset may not permanently erase all data from your phone, including personal information.

### Performing a factory reset from settings

1. Go to Settings, and then tap **Backup & reset**.
2. Tap **Reset phone**.
3. If you want to delete media, documents, and other data from the phone storage, select **Erase all data**.  
To also delete media and other data from your storage card, select **Erase SD card**.
4. Tap **OK**.

### Performing a factory reset using hardware buttons

If you can't turn HTC One remix on or access settings, you can still perform a factory reset by using the hardware buttons on HTC One remix.



The **Fast boot** option in **Settings > Power** must not be selected.

1. Press and hold the **VOLUME DOWN** button, and then press and hold the **POWER** button.


- 
2. Wait for the screen with the three Android images to appear, and then release the POWER and VOLUME DOWN buttons.
3. Press VOLUME DOWN to select **FACTORY RESET**, and then press the POWER button.

# People

## Your contacts list

The People app lists all contacts you've stored on HTC One remix and from online accounts you're logged in to. Use the People app to easily manage communications with people that matter to you.

1. Open the People app.



2. On your contacts list, you can:
  - View your profile and edit your contact information.

- Create, edit, find, or send contacts.
- Tap a contact photo to find ways to quickly connect with the contact.
- See when a contact has sent you new messages.



To sort your contacts by their first or last name, tap **☰** > **Settings** > **Sort contacts by**.

---

## Filtering your contacts list

---

When your contacts list gets long, you can choose which contact accounts to show.

1. On the People tab, tap ▼.
2. Choose the accounts that contain the contacts you want to display.
3. Press ↵.

---

## Finding people

---

Search for contacts stored on HTC One remix, your company directory if you have an Exchange ActiveSync account, or social networks you've signed into.

1. Open the People app.
2. On the People tab, you can:
  - Find people in your contacts list. Tap **🔍**, and then enter the first few letters of the contact name in the Search people box.

- Find people on your company directory. Tap **Q**, enter the first few letters of the contact name in the Search people box, and then tap **Search contacts in your Company Directory**.
- Search for people you know on your social networks. Tap **:** > **Settings** > **Find people you know on**, and then select the social networks you're signed in to. The People app then uploads your contacts to the selected social networks to help you find friends.



Aside from searching for a contact by name, you can search using a contact's email address or company name. On the People tab, tap **:** > **Settings** > **Search contacts by**, and then choose a search criteria.


## Setting up your profile

Store your personal contact information to easily send it to other people.

1. Open the People app.
2. Tap **My profile**.
3. Tap **Edit my contact card**.
4. Enter or edit your name and contact details.
5. Tap **📷** or the current photo to change your contact photo.
6. Tap **Save**.

Aside from your contact details, your profile also shows updates you've posted on your social networks and your online photo albums.

## Adding a new contact

1. On the People tab, tap **+**.
2. Tap the **Name** field, and then enter the contact name. Tap  to separately enter the contact's given, middle, or family name and name suffix, such as Jr.
3. Select the Contact type. This determines which account the contact will sync with.
4. Enter the contact information in the fields provided.
5. Tap **Save**.

When you tap the added contact on your contacts list, you'll see the contact information and your exchange of messages and calls. Depending on the information that you've added to the contact (such as an email address), you'll also be able to see the contact's social network updates, events, and photos.

## How do I add an extension number to a contact number?

While creating a new contact in People, you can add an extension number to their number so you can skip the voice prompts when calling.

1. After entering the number of the main line, do one of the following:
  - Tap **P(,)** to insert a pause before the extension number is dialed automatically. To make the pause longer, tap **P(,)** again.
  - Tap **W(;)** to be prompted to confirm the extension number.
2. Enter the extension number.

## Editing a contact's information




Social network contacts cannot be edited.

1. On the People tab, press and hold the contact, and then tap **Edit contact**.
2. Enter the new information.
3. Tap **Save**.

## Getting in touch with a contact

1. Open the People app.
2. Tap a contact's photo (not the name), and then choose how you want to get in touch with that contact.





For more ways of getting in touch with your contact, tap an icon below the contact photo.

## Importing or copying contacts

---

### Importing contacts from your nano SIM card

---

1. On the People tab, tap **⋮** > **Manage contacts**.
2. Tap **Import/Export contacts** > **Import from SIM card**.
3. If you have a Google or Exchange ActiveSync account, tap the type for the imported contacts.
4. Select the contacts you want to import.

5. Tap **Save**.

---

### Importing a contact from an Exchange ActiveSync account

---

1. On the People tab, tap **Q** and enter the contact's name or email address in the search box.
2. Tap **Search contacts in your Company Directory**.
3. Tap the name of the contact you want copied to HTC One remix.
4. Tap **+** to import the contact.

---

### Copying contacts from one account to another

---



Contacts from your social network accounts may not be copied.

1. On the People tab, tap **☰** > **Manage contacts**.
2. Tap **Copy contacts**, and then choose a contact type or online account to copy from.
3. Select a contact type or account you want to save to.

## Merging contact information



Avoid duplicate entries by merging contact information from different sources, such as your social network accounts, into one contact.

---


### Accepting contact link suggestions

---

When HTC One remix finds contacts that can be merged, you'll see a link notification when you open the People app.

1. On the People tab, tap the Contact link suggestion notification when available. You'll see a list of suggested contacts to merge.
2. Tap  next to the contact you want to merge. Otherwise, tap  to dismiss the link suggestion.




If you don't want to receive contact link suggestions, on the People tab, tap  > **Settings**. Clear the **Suggest contact link** option.

---

### Manually merging contact information



---

1. On the People tab, tap the name of the contact (not the icon or photo) you want to link.
2. Tap  > **Link**.
3. You can:
  - Under **Suggest links**, link the contact to an account.
  - Under **Add contact**, tap one of the options to link to another contact.

---

## Breaking the link

---

1. On the People tab, tap the name of the contact (not the icon or photo) whose link you want to break.
2. Tap  > **Link**.
3. Under the **Linked contacts** section, tap  beside an account to break the link.

## Sending contact information

1. On the People tab, do one of the following:


To send	Do this
Someone's contact information	Press and hold the name of the contact (not the icon or photo), and then tap <b>Send contact as vCard</b> .
Your contact information	Press and hold <b>My profile</b> , and then tap <b>Send my profile</b> .

2. Choose how you want to send the vCard.
3. Select the type of information you want to send.
4. Tap **Send**.

---

## Sending multiple contact cards

---

1. On the People tab, tap  > **Send contacts**.
2. Select the contacts whose contact information you want to share
3. Tap **Send**.
4. Choose how you want to send the contact cards.

## Contact groups



Organize your friends, family, and colleagues into groups so you can quickly send a message or email to everyone in the group. We've also set up the Frequent group to automatically add the contacts you dial or get calls from the most.

HTC One remix also syncs with groups you've created in your Google Account.

---

## Creating a group

---

1. On the Groups tab, tap .
2. Enter a name for the group, and then tap  > **Add contact to group**.
3. Select the contacts you want to add, and then tap **Save**.
4. When your group is complete, tap **Save**.

---

## Sending a message or email to a group

---



If you send a text message to a group of five people, it will count as five messages towards your monthly text message allowance.

1. On the Groups tab, tap the group you want to send a message or email to.
2. Go to the Group action tab.
3. Choose if you want to send a group message or group email.

---

## Editing a group

---

1. On the Groups tab, press and hold the group, and then tap **Edit group**.
2. You can:
  - Change the group name. You can only change the name for groups that you have created.
  - Add more contacts to the group. Tap **⋮ > Add contact to group**.



Contact not in your list? On the Groups tab, tap the name of the group where you want to add the contact, and then tap **+** > **Create a new contact**.

- Rearrange the group members. Drag **≡** at the end of the contact's name and move it to its new position.

- Select the contacts you want to remove from the group.
3. Tap **Save**.

---

## Managing your contact groups

---

1. On the Groups tab, tap **⋮** > **Edit groups**.
2. You can:
  - Rearrange the contact groups. Drag **≡** at the end of the group name to its new position.
  - Select the contact groups you want to remove.
3. Tap **Save**.

## Private contacts

If you don't want to show a contact's name and photo on the lock screen when you have an incoming call, add the contact to your private contacts list.

---

## Adding a contact to the private contacts list

---

On the People tab, press and hold the contact, and then tap **Add to private contacts**.

To view your private contacts list, on the People tab, tap **⋮** > **Manage contacts** > **Private contacts**.

## Organizing your private contacts

---

1. On the People tab, tap **⋮** > **Manage contacts** > **Private contacts**.
2. To add contacts to the private contacts list, tap **+**, select the contacts you want to add, and then tap **Save**.
3. To remove private contacts from the list, tap **⋮** > **Remove private contact**, select the contacts you want to remove, and then tap **Remove**.



# Email

## Gmail

---


### Viewing your Gmail Inbox

---

All your received email messages are delivered to your Inbox.

1. Open the Gmail app.
2. Do any of the following from your Inbox.
  - Tap an email message preview to read, forward, or reply to the message.
  - Open the slideout menu to change an inbox category such as **Primary**, switch to other Gmail™ accounts, or display by different email labels.

- Tap the sender image or letter tile to select one or more messages or conversations. You can then tap the onscreen buttons at the top bar to archive, delete, or mark the selected messages or conversations.



Get help in using Gmail by tapping **⋮** > **Help**.


---



## Sending an email message in Gmail

---

1. In the inbox of the Gmail account you want to use, tap **✉**, (or tap **> Compose**).
2. Fill in one or more recipients.





Want to loop in more recipients in a carbon copy (Cc) or blind carbon copy (Bcc) of the email message? Tap  > **Add Cc/Bcc**.

3. Enter the email subject, and then compose your message.
4. If you want to attach a photo, video or file, tap  > **Attach file**, tap the attachment source, and then select the files you want.
5. Tap  to send.

---

## Replying to or forwarding email messages in Gmail

---

1. In the Gmail inbox, tap the email message or conversation.
2. To reply to the sender, tap . Or, tap  and choose whether to **Reply all** or **Forward**.
3. Do one of the following:
  - If you're replying to the sender or you selected **Reply all**, enter your reply message.
  - If you selected **Forward**, specify the message recipients.



Tap **Respond inline** if you want to interleave your new message with the received email. But this removes any attachments or formatting in the original email message.

4. Tap  to send.

## Mail


---


### Checking your mail

---

The Mail app is where you read, send, and organize email messages from one or more email accounts that you've set up on HTC One remix.



1. Open the Mail app. The inbox of one of your email accounts appears.
2. Do any of the following:
  - Tap an email message to read.
  - To display email messages in another mail folder, tap **>** **Folder**, and then tap the folder you want to view.
  - To switch between email accounts or view email messages from all your accounts, tap **≡**.



- To change an email account's settings, select the account first and then tap  > **Settings**.

## Organizing your inbox


Do you have a big pile of email messages in your inbox? Organize your email messages into tabs and quickly find the messages you want.

1. Switch to the email account that you want to use.
2. In the inbox, tap  > **Edit tabs**.
3. Select the tabs you want to add to the inbox.
4. To arrange the tabs, drag , and then move the tab to its new location.
5. Tap **Done**.
6. Swipe to the added tab to check your email messages.


---




## Sending an email message

---



1. Open the Mail app.
2. Switch to the email account that you want to use.
3. Tap .
4. Fill in one or more recipients.





Want to loop in more recipients in a carbon copy (Cc) or blind carbon copy (Bcc) of the email message? Tap  > **Show Cc/Bcc**.

5. Enter the subject, and then compose your message.
6. Do any of the following:
  - Add an attachment. Tap  and then choose what you want to attach.
  - Set the priority for an important message. Tap  > **Set priority**.
7. Tap .



To save the email as draft and send it later, tap  > **Save**. Or press .

### Resuming a draft email message

1. In an email account inbox, tap  > **Folder** > **Drafts**.
2. Tap the message.
3. When you finish editing the message, tap .


---

### Reading and replying to an email message

---


1. Open the Mail app.
2. Switch to the email account you want to use.
3. In the email account inbox, tap the email message or conversation you want to read.



If you want to read a particular message inside an email conversation, tap  to expand the conversation, and then tap the email message.


4. Tap **Reply** or **Reply All**.



Tap  for more actions for the email.

### Quickly replying to an email message

You can quickly respond to a new email message from the Home screen or lock screen.

1. When you receive a new email message notification, slide the Notifications panel down.
2. On the email preview, tap **Reply all**.  
If you have several notifications and you don't see the email options, expand the email preview by sliding two fingers apart on the notification.
3. Compose your reply message and tap .

### Saving an image in an email message



Depending on your mail size limit settings, you may need to tap **Display images** to see images that are embedded in an email.

While viewing an email message, press and hold an embedded image, and then tap **Save image**. You'll find the saved image under the Downloads folder.

You can also copy the image to the clipboard or set it as your wallpaper.

### Saving an email message in the Tasks app

Save an email message in your Tasks list so you can remind yourself when to reply.

1. In an email account inbox, press and hold the email message, and then tap **Save as task**.
2. Enter the task details, and then tap **Save**.

---

## Managing email messages

---

The Mail app provides easy ways to sort, move, or delete your email messages.

### Sorting email messages

Customize how you sort your email messages.

In an email account inbox, tap **☰ > Sort**, and select from the sorting options.

### Moving email messages to another folder

1. Switch to the email account you want to use.
2. Select the email messages you want to move.



To select all, select one email message first, and then tap **☰ > Select all**.

3. Tap **Move to**, and then select a folder.



## Deleting email messages

1. Switch to the email account you want to use.
2. Select the email messages you want to delete.



To select all, select one email message first, and then tap **⋮** > **Select all**.

3. Tap **Delete**.

---

## Searching email messages

---

1. Tap **Q**.
2. If you want to refine or filter your search, tap **⊗**, check the search options, and then tap **OK**. For example, you can focus the search on a part of an email or filter email messages that have attachments or tagged as high priority.
3. In the search box, enter the words you want to search for.
4. Tap a result to open the email message.

## Searching for emails from a contact

Do you remember the sender, but can't find a particular email from him or her?

1. Switch to the email account you want to use.
2. Press and hold an email message from a contact.

3. Tap **Show all mail from sender**. A list of email messages from that contact appears.

---

## Working with Exchange ActiveSync email


---

Enjoy the powerful email features of Microsoft Exchange ActiveSync right on HTC One remix. Flag important email messages, set your out of the office reply, or send invites to your next team meeting while you're on the go.


### Flagging an email

1. Switch to your Exchange ActiveSync account.
2. While viewing the inbox, tap the flag icon that appears beside an email message or conversation.




To flag an email message inside a conversation, tap  to expand the conversation, and then tap the flag icon of the email message.

### Setting your Out of the office status

1. Switch to your Exchange ActiveSync account.
2. Tap  > **Out of the office**.
3. Tap your current office status, and then select **Out of the office**.
4. Set the dates and times.
5. Enter the auto-reply message.

6. If you want a different auto-reply message for recipients outside your organization, tap the **Send replies to external senders** option, and then enter the auto-reply message in the box.
7. Tap **Save**.

### Sending a meeting request


1. Switch to your Exchange ActiveSync account.
2. Tap  > **New meeting invitation**.
3. Enter the meeting details.
4. Tap **Save**. Or tap **Send** if you've invited people to the meeting.

---

### Adding an email account

---

Set up additional email accounts such as another Microsoft Exchange ActiveSync account or an account from a Web-based email service or email provider.

 If you're adding a Microsoft Exchange ActiveSync or a POP3/IMAP email account, ask your network administrator or email service provider for additional email settings that you may need.

1. Open the Mail app.
2. Tap  > **Add account**.
3. Select an email account type from the list of email providers. Otherwise, tap **Other (POP3/IMAP)**.

4. Enter the email address and password for your email account, and then tap **Next**.



Some email accounts allow you to set the sync schedule. You can use Smart Sync to save battery power. See [What is Smart Sync?](#) on page 212.

5. Enter a name for your email account, and then tap **Finish setup**.

---

### What is Smart Sync?

---

Smart Sync automatically extends the sync time the longer the Mail app is inactive. Set your email account to Smart Sync when you don't need to check new email messages frequently. Smart Sync helps save battery power.

If you want to receive email messages as they arrive, select another **Peak time sync** and **Off-peak sync** schedule in the email account's **Sync, Send & Receive** settings.


# Calendar

## Viewing the Calendar

Use the Calendar app to view your events, meetings, and appointments. If you've signed into your online accounts, related events will also appear in Calendar.

1. Open the Calendar app.
2. Tap ▼ , and then choose a calendar view.



In any calendar view, return to the current date by tapping .

---

### Month view

---

In month view, you will see markers on days that have events. Upcoming events for the day are also shown at the bottom of the screen.

- Swipe left or right across the screen to view succeeding or previous months.
- Tap a day to view the events for that day.
- Press and hold a day to see more options.

---

## Day and agenda views

---

Day view shows your day's schedule and weather forecast for the next few days, while agenda view gives a quick glance of all your day's events.

- Swipe left or right across the screen to view succeeding or previous days.
- Tap an event to view its details.
- If the event is a contact's birthday or anniversary, tap it to send a greeting.



Need to see the event time in another time zone? In Day view, tap **☰** > **Select 2nd time zone** > **Choose location**, and then enter the city name.

---

## Week view

---

Week view displays a chart of the events of one week.

- Swipe left or right across the screen to view succeeding or previous weeks.
- Tap an event (shown as colored blocks) to view its details.

## Scheduling or editing an event


You can create or edit events on HTC One remix, and also sync events with your Exchange ActiveSync calendar. You can also create, modify, and sync events with your Google calendar.




Editing events is not supported for all accounts.

1. Open the Calendar app.
2. On any Calendar view, do one of the following:

**Create an event** Tap **+**. Tap **▼**, and then select the calendar you will add the event to.

**Edit an event** View an event, and then tap .

3. Enter and set the event details.
4. To invite contacts from your Exchange ActiveSync account, tap . You can also invite contacts from your Google account.
5. Tap **Save**.  
If you've invited people to the event, tap **Send** or **Send update**.

---



## Checking your schedule for an event

---

Avoid juggling multiple meetings at the same time. In Calendar, you can check your appointments to see if a new event would conflict with your schedule.

1. When creating or editing an event, tap **Check calendar**.
2. Press and hold the event box, and then drag it to an available time slot.
3. Drag the top and bottom nodes to adjust the event's time duration. You'll see a message if there are conflicts with other scheduled events.
4. Tap **Done** to return to the event screen, and then save your event.

## Choosing which calendars to show

1. In any calendar view, tap  > **Accounts (All calendars)** or **Accounts (Multi-calendar)**.
2. Select or clear an account you wish to show or hide.  
If you have multiple calendars under an online account, tap  to select the items to include.




- Calendars are synced on HTC One remix, even if they are hidden.
- You can also show or hide tasks that you've created on HTC One remix.




## Sharing an event

You can share a calendar event as a vCalendar using Bluetooth or by sending it as a file attachment with your email or message.

1. Do one of the following:
  - While viewing an event, tap  > **Share via**.
  - In day, agenda or week view, press and hold an event and then tap **Share via**.
2. Choose how you want to send the event.




You can also forward accepted meeting invitations from your Exchange ActiveSync calendar. While viewing an event, tap  > **Forward**. Compose your email message, and then send it.

## Accepting or declining a meeting invitation


Switch to Invites view to see meeting invitations which you have not yet accepted or declined.



You must set up an Exchange ActiveSync account to receive meeting invitations in Calendar.


1. Open the Calendar app.
2. Tap  > **Invites**, and then tap a meeting invitation.
3. Accept, decline, or tentatively accept the invitation, or propose a new time.



Tap  to choose from more options, such as moving the invitation to a folder.

If you need to cancel an accepted meeting invitation or propose a new time, view the event details in Calendar, and then tap **Response**.


## Dismissing or snoozing event reminders

If you have set at least one reminder for an event, the upcoming event icon  will appear in the notifications area of the status bar to remind you.

1. Slide the Notifications panel open.
2. If the notification shows that there are multiple reminders, tap it to see all the reminders. You can then choose to snooze or dismiss them.
3. If you see a single event notification, spread your two fingers on the notification to expand it. You can then:
  - Tap **Snooze** or **Dismiss**. Or drag the notification left or right to dismiss it.
  - Tap **Send mail** to send a quick response to the meeting attendees.



To edit the preset quick responses or add your own, open Calendar, and then tap  > **Settings** > **Quick response**.

If you don't want to dismiss or snooze the calendar reminders, press  from the Notifications panel to keep them pending in the notifications area of the status bar.

# Travel and maps

## Location settings

---

### Turning location services on or off

---

In order to find your location on HTC One remix, you need to enable location sources.

1. Go to Settings, and then tap **Location**.
2. Tap the **On/Off** switch to turn location services on and off.
3. Under Location sources, select the location mode you want. For example, for a better estimate of your location, choose **High accuracy**. To save battery power, choose **Battery saving**.

Turning off a location source (for example GPS) means no applications on HTC One remix will collect your location data through that location source. However, third party applications may collect — and HTC One remix may continue to provide — location data through other sources, including through Wi-Fi and signal triangulation.

## Google Maps

---

### About Google Maps

---

Google Maps™ lets you track your current location, view real-time traffic situations, and receive detailed directions to your destination.

It also provides a search tool where you can locate places of interest or an address on a map, or view locations at street level.









- To find your location with Google Maps, you need to enable location sources.
- The Google Maps app does not cover every country or city.

---

### Getting around maps

---

When you open Google Maps, you can easily find your location on the map or check out nearby places by panning and zooming in and out on the map.

1. Open the Maps app.
2. Tap  to show your current location. The blue marker  or  shows your current location on the map.
3. Tap  to turn Compass mode on. In Compass mode, the map orients itself depending on the direction you're facing. To exit Compass mode, tap .
4. If you want to see more information overlaid on the map, tap , and then tap a map view such as **Traffic** or **Public transit** to toggle the view on and off.

## Navigating the map

You can navigate the map using finger gestures.

- Slide your finger in any direction to pan.
- Double-tap the map or slide two fingers apart over an area to zoom in.  
To zoom in while holding the phone with one hand, double-tap with your thumb and hold the second tap, and then drag your thumb down.
- Double-tap the map with two fingers or slide two fingers together over an area to zoom out.  
To zoom out while holding the phone with one hand, double-tap with your thumb and hold the second tap, and then drag your thumb up.
- Press and hold an area with two fingers and then drag your fingers in a circular motion to rotate the map.
- Press and hold an area with two fingers and then swipe up to see an angled view of the map. Swipe down to return to overhead view.


---

## Searching for a location


---


Use Google Maps to search for a location, such as an address or a type of business or establishment (for example, museums).

1. Open the Maps app.
2. Tap the search box and then enter the place you want to search for.

3. Tap the **Enter** key on the keyboard or tap a suggested search item. The first location on the search appears with a place marker  and its info sheet displays at the bottom of the screen. All other search results are indicated by a red dot or a smart map icon.



4. If there is more than one search result, tap  to view the search results list.
5. Tap the info sheet to check the address, get directions, see the location in Street View (if available), and more.
6. To check the next or previous location on the search, swipe the info sheet left or right.


To clear the map and search for another location, swipe the info sheet down (if it's expanded), and then tap .

---


## Getting directions

---


Get detailed directions to your destination. Google Maps provides travel directions by car, public transit, bike, or foot.

1. Open the Maps app.
2. Tap .
3. Choose how you want to get to your destination.
4. Use your current location as starting point, or tap **My location** to enter your starting point or select a location from your search history.
5. Tap **Choose destination**, and then enter or select your destination.



If you're taking public transit, tap  to set the date and time of travel, or tap **Options** to set your route preferences.

6. Tap a route or transit option to view the directions on the map. You'll also see the travel duration on the info sheet at the bottom of the screen.
7. Tap the info sheet to view the directions in a list.

When you're finished viewing or following the directions, tap  to reset the map. Your destination is automatically saved in the Google Maps history.



## HTC Car

---

### On the road with HTC Car

---

Now when you drive, you can easily use HTC One remix to reach your destination, keep you entertained, and help you stay in touch with the people that matter to you. Access music, phone calls, maps, and more with HTC Car.


1. Open the Car app.



The first time you open HTC Car, you'll be asked to accept the terms and conditions.

2. Swipe up or down to see what you can do in HTC Car.



When using HTC Car, return to the main screen from any other screen by pressing .

Close HTC Car by pressing  from the main screen.

---

### Using voice commands in HTC Car

---

Use your voice to control HTC Car.

1. In HTC Car, tap the screen with three fingers to activate voice command mode.

2. Do one of the following:

Call someone	Say "Call [person's name in phonebook]"
Play music	Say "Play [song title, album, artist name, or genre]"
Find something on the map	Say "Find [name of place, address, type of place]"



You can also activate speak by:

- Tapping **Speak** on the main screen in HTC Car.
- Pressing the answer button on supported Bluetooth headsets.

---

## Finding places in HTC Car

---

1. In HTC Car, tap **Navigation**.
2. To search for a place, tap **Q** and enter a location in the search box.
3. To look up a previously searched for place, tap **Previous**.
4. To get directions for an upcoming event in Calendar, tap **Appointments** and then tap an upcoming appointment.

---

## Exploring what's around you

---

Feeling adventurous? With just a few taps, you can find interesting places around you quickly.

1. In HTC Car, tap **Navigation**.
2. Tap a category, for example **Restaurant** or **Parking** to see what's available near you.
3. Tap **Q** to enter your own search keywords.

---

## Playing music in HTC Car

---

1. In HTC Car, tap **Music**.
2. Swipe left or right to browse by category.
3. Tap **Q** to search your collection.
4. Tap an album, song, or playlist to listen to it.

---

## Making phone calls in HTC Car

---

- Tap **Dialer** to open the dialpad.
- Tap **People** and then browse a category or search by entering a name.
- Tap **Speak** and say "Call" and the person's name. For example, say "Call Jennifer Singer".

---

## Handling incoming calls in HTC Car

---

When you receive an incoming call, you can easily answer or decline.

- If you hear a voice prompt, say “yes” or “no” to answer or decline a call.
- Tap **Answer** or **Decline**.

---

## Customizing HTC Car

---

- To change the default behavior of HTC Car, tap **Settings**.
- To add more apps to HTC Car, tap **+** and select an app.

## VZ Navigator

---

### Using VZ Navigator

---

Get premium GPS voice navigations and 3D maps with spoken real-time traffic alerts. Find movie times, event info and gas stations. For more information about VZ Navigator, visit: [www.verizonwireless.com/vznavigator](http://www.verizonwireless.com/vznavigator).

1. Open the VZ Navigator app.
2. Tap **Accept** on the message box.
3. Select the options you want on the VZ Navigator setup screen, and then tap **Accept**.

4. Do any of the following:

- To use VZ Navigator, tap **Go To**. VZ Navigator provides maps, turn-by-turn 3D navigation, speech input and more so you can get to your destination on time. This is a subscribed service.
- To use VZ Navigator Maps, tap **Map**. VZ Navigator Maps lets you access free maps with traffic and satellite views and more. You can do a search for local gas prices and points of interest and share your location by phone, email, or social network.

## Other apps

### Using Scribble

Want to make a page for your digital scrapbook? Use the Scribble app to get artistic and combine photos, text, and illustrations in a note.

With several templates to choose from, you can even create lists or track your budget. Have a greeting card ready and link it to your friend's birthday in Calendar to send in a few taps.

---

#### Composing a note

---

1. Open the Scribble app.
2. Choose a template when you're prompted. Or, tap **+**.
3. In the box that says **Title text here**, type in your note title.
4. Use the editing tools to enter text, draw figures, record audio, and more.
5. Insert images such as photos and illustrations. To find out how, see [Inserting images and illustrations in a note](#) on page 231.
6. Press and hold an image to move, resize, or delete it. You can also use two fingers to rotate an image.
7. Tap **⋮** for other options, such as changing the template, linking the note to an event, and more.





8. Press  to save the note.

---

## Inserting images and illustrations in a note

---



While composing a note, you can:

- Tap  to take a photo, or tap  > **Insert** to select an image from Gallery.
- Tap  to draw, or tap  to write text. You can change the pen characteristics.



- Tap  to insert a sticker.




- To insert a web page thumbnail, tap  > **Web content**. On the Chrome app, go to the web page, and then tap  > **Share** > **Scribble**.

## Creating a photo blog note

Think photos can best convey your story? Group photos into a note, and make it more entertaining by including photo collages, stickers, and more.



If inserting a collage, first group the photos in the same event or album in Gallery.

1. Open the Scribble app.
2. Tap **+** and choose the photo blog template.
3. Tap  to take a photo or select photos in Gallery to group them in a collage.



4. When inserting a collage, press and hold it, and then select a layout. You can also:
  - Press and hold, and then drag around a photo within the frame to put the subject in the center of the frame.
  - Press and hold, and then drag a photo over another to re-arrange them.
  - Slide two fingers apart to zoom in on a photo, or slide two fingers together to zoom out.



- Tap another layout to change the current layout.
5. Tap the area above the date, and then use the editing tools to insert text and illustrations.
  6. To add another page, tap **+**.
  7. Press **↶** to save the note.

---

### Grouping notes into a notebook

---

- To group notes into a new notebook, tap **⋮** > **Group**.
- To group notes into an existing notebook, tap **⋮** > **Move to**.
- To create a new notebook, swipe to the Notebooks tab, and then tap **+**.

---

### Publishing and sharing a note

---

Upload and share your creative work on the Web and get your own Scribble home page.

1. With a note opened, tap **🌐**.
2. Tap **Share article**.
3. Type a description or tag your note.
4. Make sure that **Share your post** is selected.
5. Under **Share to**, tap where you also want to share the link that will be created. You'll be prompted to complete the action in the apps you selected.

## 6. Tap Done.

To view notes you've shared, swipe to the Share tab on the Scribble main screen.


## Using the Clock

Get more from the Clock app than just the regular date and time. Use HTC One remix as a world clock to see the date and time in cities across the globe. You can also set alarms or track your time using the stopwatch or timer.

---

### Setting the date and time manually

---

1. Open the Clock app.
2. On the World Clock tab, tap  > **Local time settings**.
3. Clear **Automatic date & time** and **Automatic time zone**, and then set the time zone, date, and time as required.



To display military time, choose the **Use 24-hour format** option.

---

### Setting an alarm

---

You can set up one or more alarms.

1. Open the Clock app.
2. On the Alarms tab, select the check box of an alarm and then tap that alarm.

3. Under Set alarm, use the scroll wheels to set the alarm time.
4. If you want the alarm for multiple days, tap **Repeat**.
5. Tap **Done**.



- To turn off an alarm, clear the check box of that alarm.
- If you need to set more than three alarms, tap **+**.

## Checking Weather

Use the Weather app and widget to check the current weather and weather forecasts for the next few days. In addition to your current location, you can view weather forecasts for other cities around the globe.

1. Tap the Weather Clock widget on your Home screen to open the Weather app. You'll see the weather for different cities, including where you are.
2. Tap a city to view weather information.
3. Swipe to the Hourly and Forecast tabs to view the forecast in your selected location.
4. To check the weather in other cities, tap **▼**, and then select the city you want.
5. To add more cities, tap **+** and then enter the location.

Your settings in the Weather app also control the weather information that is shown in the Clock and Calendar.

## Keeping track of your tasks



Use the Tasks app to organize and track to do and task lists. Create tasks on your phone or sync them with your Microsoft Exchange ActiveSync account. You can also sync tasks with your Google account.

You can even choose to see your tasks in the Calendar app .



---

### Creating a task

---

1. Open the Tasks app.
2. To select the task account where you want to create the task, tap .
3. Tap , and then enter the task details.




Tasks created under My tasks can be linked to a contact (tap ) or to a location (tap ).

4. Tap **Save**.

---

### Managing tasks


---

1. Go to the list that contains the task.
2. In the list of tasks, you can:
  - Tap the check box next to the task to mark a task complete.
  - Press and hold a task to delete, postpone, or move it to another list.
  - Tap  to view completed tasks, sort them, and more.

---

## Managing task lists

---

1. In the Tasks app, tap  > **Manage lists**.
2. From here, you can:
  - Tap a list to show all tasks under that list.
  - Tap **+** and choose an account to create a list.



You can't create lists for Microsoft Exchange ActiveSync accounts.

- Tap **⋮** to rename or delete a list.



Some lists can't be deleted.

## Kid Mode

Worried that your kids might wander off to inappropriate web sites or mess with your important work files while using HTC One remix? Use Kid Mode® to let your children enjoy fun and age-appropriate games and more, while helping to protect your important data from accidental deletion. To learn more about Kid Mode, visit [www.zoodles.com](http://www.zoodles.com).

---

## Creating a child profile

---

1. Open **Parent Dashboard** from the All Apps screen. The first time you use Kid Mode, you need to create or sign in to your account.

2. Tap the default name at the top of the screen, and then tap **Add Child**.
3. Fill out the information on the screen and then tap **Save**.

---

## Switching to Kid Mode

---

1. Open the Kid Mode app.
2. If prompted, follow the instructions on the screen to set a child lock.
3. On the Zoodles® main screen, tap the profile that you created for your child.
4. Tap the icons to access games and apps, play recorded storybook readings, and more.

---


## Setting child-accessible apps in Kid Mode

---

When in Kid Mode, you can choose which apps on HTC One remix your child will have access to.

1. Open **Parent Dashboard** from the All Apps screen. You can also go to Parent Dashboard from **Settings > Security > Kid Mode**.
2. Confirm your action by entering the required information.
3. Under Basic Features, tap **Apps**. You'll see a list of apps installed on HTC One remix.
4. Tap the check option beside the app that you want your child to be able to use in Zoodles.



Want to receive or block incoming calls while in Kid Mode? Tap  > **Device Options**, and then select or clear the **Allow Incoming Calls** option.

---

## Closing Kid Mode

---

On the Zoodles main screen, tap  and then confirm your action by entering the required information.

# Internet connections

## Data connection

When you turn on HTC One remix for the first time, it will be automatically set up to use the mobile network of Verizon Wireless (if the nano SIM card is inserted).

---

### Turning the data connection on or off

---

Turning your data connection off saves battery life and money on data charges.



You need a data plan to use the Verizon Wireless network for data services. Check with Verizon Wireless for details.

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap the **Mobile data** tile to turn the data connection on and off.



If you don't have the data connection turned on and you're also not connected to a Wi-Fi network, you won't receive automatic updates to your email, social network accounts, and other synced information.



---

## Turning data roaming on or off

---

Connect to Verizon Wireless partner networks and access data services when you're out of Verizon Wireless coverage area.



Using data services while roaming is not part of your subscribed monthly data access allowance. Check with Verizon Wireless for data roaming rates before you enable data roaming.

1. Go to Settings.
2. Tap **Mobile data** > **Data roaming**, and then select a data roaming option.

Select the **Data roaming sound** option if you'd like HTC One remix to play a sound so you'll know when it's connecting to a roaming network.

## Managing your data usage

If you're on a limited data allowance, it's important to keep track of the activities and apps that usually send and receive data, such as browsing the web, syncing online accounts, and sending email or sharing status updates.

Here are some other examples:

- Streaming web videos and music
- Playing online games
- Downloading apps, maps, and files
- Refreshing apps to update info and feeds

- Uploading and backing up your files to your online storage account
- Using HTC One remix as a Wi-Fi hotspot
- Sharing your mobile data connection by USB tethering

To help you save on data usage, connect to a Wi-Fi network whenever possible and set your online accounts and emails to sync less frequently.

---

### Keeping track of your data usage

---

Monitor your data usage to help prevent going over your monthly data allowance.



Data usage measured by HTC One remix may differ from, and be less than, your actual data usage.

1. Go to Settings, and then tap **Data usage**.
2. On the Mobile tab, select **Limit mobile data usage** and tap **OK** to automatically disable your data connection when you reach the set limit.
3. Drag the upper **LIMIT** line to set your monthly data limit.
4. Select **Alert me about data usage**, and then drag the lower **ALERT** line to set an alert before you reach your monthly data limit.
5. Tap **Reset data usage**, and then set the day of the month when your usage cycle resets. This date is usually the start of your monthly billing cycle.
6. Drag the vertical line markers to see how much data you've used during a particular time interval.



If you're connecting HTC One remix to another portable Wi-Fi hotspot, tap **☰** > **Mobile hotspots** to restrict background data from downloading that may incur extra data fees.

---

## Viewing the data usage of apps

---

1. Go to Settings, and then tap **Data usage**.
2. Drag the vertical line markers to see how much data you've used during a particular time interval.
3. Scroll down the screen to see a list of apps and their data usage info.
4. Tap an app to see more details.

## Wi-Fi

To use Wi-Fi, you need access to a wireless access point or “hotspot”.



The availability and strength of a Wi-Fi signal varies depending on objects the Wi-Fi signal has to pass through (such as buildings or a wall between rooms).

---

## Turning Wi-Fi on

---

1. With two fingers, swipe down from the status bar to open Quick Settings.

2. Tap the **Wi-Fi** tile to turn Wi-Fi on.
3. Tap **⋮** to see a list of detected wireless networks.




- To manually scan for Wi-Fi networks, tap **⋮** > **Scan**.
- If the wireless network that you want is not listed, tap **⋮** > **Add network** to manually add it.

---

## Connecting to a Wi-Fi network

---

1. Turn Wi-Fi on, and check the list of detected Wi-Fi networks. See [Turning Wi-Fi on](#) on page 243.
2. Tap a Wi-Fi network you want to connect to.
3. If you selected a secured network, enter the network key or password.
4. Tap **Connect**. You'll see the Wi-Fi icon  in the status bar when connected.

---

## Disconnecting from the current wireless network

---

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. If Wi-Fi connection is off, tap the **Wi-Fi** tile to turn it on.
3. Tap **⋮**. Detected Wi-Fi networks will be listed.

4. Tap the wireless network that HTC One remix is connected to, and then tap **Disconnect**.

If you want to remove the settings for this network, press and hold the network name, and then tap **Forget network**.

---

## Connecting to a different Wi-Fi network

---

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. If Wi-Fi connection is off, tap the **Wi-Fi** tile to turn it on.
3. Tap **⋮**. Detected Wi-Fi networks will be listed.



To manually scan for available Wi-Fi networks, tap **⋮** > **Scan**.

4. Tap a Wi-Fi network to connect to it.

## Wi-Fi Enhanced Connectivity

When you open an app that needs Internet connection, HTC One remix automatically scans for available Wi-Fi networks when Wi-Fi is on.



Connecting to the Internet using Wi-Fi helps prevent you from going over your subscribed monthly data allowance while using data applications.

- When prompted, tap a Wi-Fi network to connect to, and then tap **Connect**. If you selected a secured network, you'll be asked to enter the network key or password.

- If you don't want to connect to a Wi-Fi network, tap **Not now**.

---

## Turning off Wi-Fi Enhanced Connectivity

---

1. Go to Settings, and then tap **Wi-Fi**.
2. Tap **⋮** > **Advanced**, and then clear the **Show Wi-Fi pop-up** option.

## Connecting to VPN

Add virtual private networks (VPNs) so you can connect and access resources inside a local network, such as your corporate network.

Before you can connect to your organization's local network, you may be asked to:

- Install security certificates
- Enter your login credentials
- Download and install a required VPN app on HTC One remix

Contact your network administrator for details. Also, HTC One remix must first establish a Wi-Fi or data connection before you can start a VPN connection.


---

## Adding a VPN connection

---




You must first set a lock screen PIN or password before you can use credential storage and set up the VPN.

1. Go to Settings, and then under Wireless & networks, tap **More**.
2. Tap **VPN >  > Add VPN profile**.
3. Enter the VPN settings and set them up according to the security details your network administrator gave you.
4. Tap **Save**.

---

## Connecting to a VPN

---

1. Go to Settings, and then under Wireless & networks, tap **More**.
2. Tap **VPN**.
3. Tap the VPN that you want to connect to.
4. Enter your log in credentials, and then tap **Connect**. When you're connected, the VPN connected icon  appears in the notification area of the status bar.

You can then open the web browser to access resources such as your corporate network intranet.

---

## Disconnecting from a VPN

---

1. Slide the Notifications panel open.
2. Tap the VPN notification, and then tap **Disconnect**.

## Using HTC One remix as Mobile Hotspot

Share your data connection with other devices using Mobile Hotspot.



- Make sure the data connection is turned on.
- Mobile Hotspot is included with Share Everything plans. If you don't have a Share Everything plan and want to add Mobile Hotspot subscription, contact Verizon Wireless for details.

1. Go to Settings, and then under Wireless & networks, tap **More**.
2. Tap **Mobile network sharing > Mobile hotspot**.  
The first time you turn on the mobile hotspot, you'll need to set it up.
3. Enter a hotspot name or use the default.
4. Enter a password or use the default.





- The password is the key other people need to enter on their device so they can connect and use HTC One remix as a wireless router.
- To help minimize security risks, use the default security settings.

5. Tap the Mobile Hotspot **On/Off** switch to turn it on.

HTC One remix is ready to be used as Mobile Hotspot when you see  on the status bar.



Devices connected to your Mobile Hotspot use data from your subscribed data plan.

## Sharing your mobile data connection by USB tethering

No Internet connection available for your computer? No problem. Use the data connection of HTC One remix to connect to the Internet.



- To make sure that the USB drivers for HTC One remix are up-to-date, install the latest version of HTC Sync Manager on your computer.
- Mobile Broadband Connect is a subscribed service. Contact Verizon Wireless for details.
- Make sure that mobile data is turned on.

1. Go to Settings, and then under Wireless & networks, tap **More**.

2. Tap **Mobile network sharing**.
3. Tap **USB network setting**, and then select **Mobile Broadband Connect**.
4. Connect HTC One remix to your computer using the provided USB cable. The next time HTC One remix connects to a computer, it will remember your settings.



If you often switch between Mobile Broadband Connect and Internet pass-through, select **Smart network sharing** to automatically turn on the connection type you need whenever you connect HTC One remix with your computer.

# Wireless sharing

## Turning Bluetooth on or off

1. With two fingers, swipe down from the status bar to open Quick Settings.
2. Tap the **Bluetooth** tile to turn Bluetooth on or off.
3. Tap **⋮** to see a list of available devices.



Turn off Bluetooth when not in use to save battery power, or in places where using a wireless device is prohibited, such as on board an aircraft and in hospitals.

## Connecting a Bluetooth headset

You can listen to music over a Bluetooth A2DP stereo headset, or have hands-free conversations using a compatible Bluetooth headset.



Before you connect your headset, make it discoverable so HTC One remix can find it. Refer to your headset manual for details.

1. Turn Bluetooth on and check the list of available devices.  
See [Turning Bluetooth on or off](#) on page 251.

2. If you don't see your headset listed, tap **Scan for devices** to refresh the list.
3. Tap the name of your headset in the Available Devices section. HTC One remix pairs with the headset and the headset connection status is displayed in the Paired Devices section.
4. If prompted to enter a passcode, try 0000 or 1234, or consult the headset documentation to find the passcode.

When the Bluetooth headset is connected, you'll see  in the status bar.

---

### Reconnecting a Bluetooth headset

---


Normally, you can easily reconnect your headset by switching on Bluetooth on HTC One remix, and then turning on the headset.

However, you might have to connect manually if your headset has been used with another Bluetooth device.

1. Turn Bluetooth on and check the list of paired devices.  
See [Turning Bluetooth on or off](#) on page 251.
2. Tap the headset's name in the Paired Devices section.
3. If prompted to enter a passcode, try 0000 or 1234, or consult the headset documentation to find the passcode.


If you still cannot reconnect to the headset, follow the instructions in [Unpairing from a Bluetooth device](#) on page 253, and then follow the steps under [Connecting a Bluetooth headset](#) on page 251.

## Unpairing from a Bluetooth device

1. Turn Bluetooth on and check the list of paired devices.  
See [Turning Bluetooth on or off](#) on page 251.
2. In the Paired devices section, tap  next to the device to unpair.
3. Tap Unpair.

## Receiving files using Bluetooth

HTC One remix lets you receive various files with Bluetooth, including photos, music tracks, contact info, calendar events, and documents such as PDFs.

 Refer to the device's documentation for instructions on sending information over Bluetooth.

1. Turn Bluetooth on.  
See [Turning Bluetooth on or off](#) on page 251.
2. On the sending device, send one or more files to HTC One remix.
3. If asked, accept the pairing request on HTC One remix and on the sending device. You may also be prompted to enter the same passcode or confirm the auto-generated passcode on both devices.

You'll then get a Bluetooth authorization request.

4. Tap Pair.

5. When HTC One remix receives a file transfer request notification, slide the Notifications panel down, tap the incoming file notification, and then tap **Accept**.
6. When a file is transferred, a notification is displayed. Slide the Notifications panel down, and then tap the relevant notification to view the file.
7. You can also tap **☰** > **Show received files** to view files received via Bluetooth.


## Using NFC

With built-in NFC (near field communication) on HTC One remix, you can share content to another NFC-capable mobile device in an instant.



NFC may not be available in some phones.

Beam webpages, photos, contact information, and more by holding HTC One remix and the other device back to back.



You can also use NFC for contactless payment. Contact Verizon Wireless to find out about the availability of NFC payment services.

---

### Turning NFC on or off

---

1. Go to Settings, and then under Wireless & networks, tap **More**.
2. Tap **NFC**.
3. Tap the **NFC On/Off** switch to turn it on and off.



---

## Beaming content

---

**F** Make sure that both devices are unlocked and have NFC turned on. If the other device has an Android Beam™ option, make sure it is also turned on.

1. While viewing the content that you want to share, hold HTC One remix and the other phone back to back.



Make sure that the NFC area (shaded part) of HTC One remix and the other phone's NFC area are close to one another. Experiment by slightly moving the phones until a connection is made.

2. Tap the screen.

The shared content appears on the other screen. For some items that you've shared (such as contact information), additional instructions on how to save the item will appear on the receiving device.

# Settings and security

## Airplane mode

When you enable Airplane (Flight) mode, all wireless radios on HTC One remix are turned off, including the call function, data services, Bluetooth, and Wi-Fi.

When you disable Airplane mode, the call function is turned back on and the previous state of Bluetooth and Wi-Fi is restored.



- You can manually turn Bluetooth and Wi-Fi back on after enabling Airplane mode.
- If USB tethering is turned on, enabling Airplane mode turns it off. You need to manually turn USB tethering on after you disable Airplane mode.

Do any of the following to turn Airplane mode on or off:


- Press and hold **POWER**, and then tap **Airplane mode**.
- With two fingers, swipe down from the status bar to open the Quick Settings panel. Tap the **Airplane mode** tile to turn airplane mode on or off.

When enabled, the Airplane mode icon  is displayed in the status bar.

## Do not disturb mode

Use Do not disturb mode to reject calls, and silence audible alerts and notifications, but still want to have a data connection available.

1. Go to Settings, and then tap **Sound**.
2. Tap the Do not disturb **On/Off** switch to turn it on and off.
3. Tap **Do not disturb** to set when you want Do not disturb to turn off, or to allow the Clock app alarm and timer sounds to play when Do not disturb is on.

The Do not disturb icon  will appear in the notifications area of the status bar. Even when Do not disturb mode is on, you'll still see notification icons in the status bar to alert you of missed calls, new messages, calendar events, alarms, and other notifications.

---

### Allowing incoming calls to bypass Do not disturb mode

---

Add important contacts to an exceptions list so that you can still receive their calls even when Do not disturb mode is on.

1. Go to Settings, and then tap **Sound**.
2. Tap **Do not disturb**.
3. Tap **Do not disturb exceptions** and then tap **+**.
4. Choose whether to select contacts or groups to add to the exceptions list.
5. Select the checkbox to allow incoming calls from contacts on the exceptions list.

To remove contacts or numbers from the exceptions list, tap **⋮** > **Remove contact**.

---


### Setting a Do not disturb schedule

---

You can schedule when you want Do not disturb to turn on. For example, if you can set it to turn on during a weekly meeting.

1. Go to Settings, and then tap **Sound**.
2. Tap **Do not disturb**.
3. Tap **Do not disturb schedule** and then tap **+**.
4. Set the start and end times for the schedule.
5. To have the schedule repeat on specific days, tap **Repeat** and select which days you want it to occur.
6. To select which contacts will be allowed to reach you when the Do not disturb schedule is active, tap **Contacts to allow calls**.
7. Tap **Done**.

The schedule will be listed on the Do not disturb schedule screen.



Calendar events that have Do not disturb enabled will also be listed on the Do not disturb schedule screen.

## Scheduling when to turn data connection off

To help conserve power and data usage, you can set a time period when the data connection will automatically turn off during low peak times. This takes effect after the screen has been off for 15 minutes and there's no network activity (no downloads, streaming, or data usage).

1. Go to Settings, and then tap **Power**.
2. Tap **Sleep mode**.
3. To manually change the settings, clear **Learn sleep time automatically** if it's selected.
4. Under Sleep time, choose the start and end time when data connection is disabled.
5. Tap the Sleep mode **On/Off** switch to turn it on.

The data connection resumes when you switch the screen back on.

## Automatic screen rotation



Automatic rotation is not supported in all applications.

1. Go to Settings, and then tap **Display & gestures** or **Display, gestures & buttons**.
2. Select or clear the **Auto-rotate screen** option to turn it on or off.

## Setting when to turn off the screen

After a period of inactivity, the screen turns off to conserve battery power. You can set the idle time before the screen turns off.

1. Go to Settings, and then tap **Display & gestures** or **Display, gestures & buttons**.
2. Tap **Screen timeout**, and then tap the time before the screen turns off.

## Screen brightness

1. Go to Settings, and then tap **Display & gestures** or **Display, gestures & buttons**.
2. Tap **Brightness**.

3. With the **Automatic brightness** option selected, drag the slider to set the maximum brightness level. This sets a limit on how bright the screen will be when **Automatic brightness** is selected.
4. To set the brightness manually, clear the **Automatic brightness** option, and then drag the brightness slider to the left to decrease or to the right to increase the screen brightness.

## Changing the display font

You can change the font style and size of the display font.

1. Go to Settings, and then tap **Display & gestures** or **Display, gestures & buttons**.
2. Tap **Font style** and choose one of the built-in fonts or tap **Get fonts online** to go online and download new fonts.
3. Tap **Font size** to choose the size of the font.

## Touch sounds and vibration

Some people like the sound or vibration feedback they get when touching the screen, and some don't. You can turn on or off various types of touch sounds and vibration on HTC One remix.

- Touch tones when tapping the phone dial pad
- Touch sounds when tapping onscreen items
- Screen lock sounds
- Pull-to-refresh sounds



- Vibration when pressing hardware buttons
- Touch sound and vibration when tapping the HTC Sense keyboard

---

### Turning touch sounds and vibration on and off

---

1. Go to Settings, and then tap **Sound**.
2. Under System, select the option you want to turn on or off.

---

### Turning off keyboard sounds and vibration

---

1. Go to Settings, and then tap **Language & keyboard**.
2. Tap **HTC Sense Input**.
3. Tap **Sound feedback** and then select **None** to turn off keyboard sounds.
4. Clear the **Vibration feedback** option to turn off keyboard vibration.

## Changing the display language

Changing the language adjusts the keyboard layout, date and time formatting, and more.

1. Go to Settings, and then tap **Language & keyboard**.
2. Tap **Language**, and then choose the language you want to use.

## Accessibility settings

Use these settings when you've downloaded and installed an accessibility tool, such as a screen reader that provides voice feedback. You can turn accessibility functions or services on or off.

1. Go to Settings, and then tap **Accessibility**.
2. Choose the settings you want.

## Turning Magnification gestures on or off

If you're visually impaired or would just like to get a closer view of what's on the screen, use Magnification gestures to enlarge portions of your phone's screen.

1. Go to Settings, and then tap **Accessibility**.
2. Tap **Magnification gestures**, and then tap the **On/Off** switch to turn it on or off.

Follow the onscreen instructions to learn how to use Magnification gestures.

## Installing a digital certificate

Use client and Certificate Authority (CA) digital certificates to enable HTC One remix to access VPN or secured Wi-Fi networks, and also to provide authentication to online secure servers. You can get a certificate from your system administrator or download it from sites that require authentication.



- You must set a lock screen PIN or password before installing a digital certificate.
- Some apps such as your browser or email client let you install certificates directly in the app. See the app's help for details.

1. Save the certificate file in the root folder on HTC One remix.
2. Go to Settings, and then tap **Security**.
3. Tap **Install from storage**.
4. If you have more than one certificate in the root folder, select the certificate you want to install.
5. Enter a name for the certificate and tap **OK**.

## Disabling an app

Apps, even if not used often, may be running in the background and downloading data. If an app cannot be uninstalled, you can disable it.

1. Go to Settings, and then tap **App manager**.

2. Swipe to the All tab.
3. Tap the app, and then tap **Disable**.

## Lock screen notifications

Choose the types of notifications to show or hide on the lock screen.

1. Go to Settings, and then tap **Security**.
2. Under Lock screen, tap **Notification settings**.
3. Choose whether to show or hide notifications such as missed calls and text messages.

## Hiding the caller from the lock screen

You can prevent the names and photos of incoming callers from appearing on the lock or security screens.



The caller must be in your private contacts list.

1. Go to Settings, and then tap **Security**.
2. Under Lock screen, select **Incoming phone calls**.

## Setting a screen lock

Help protect your personal information and help prevent others from using HTC One remix without your permission.

Choose to set a screen lock pattern, numeric PIN, or other means of securing your phone. You'll be asked to unlock the screen every time HTC One remix is turned on or when it's idle for a certain period of time.

1. Go to Settings, and then tap **Security**.
2. Tap **Screen lock**.
3. Select a screen lock option and set up the screen lock.
4. Tap **Lock phone after**, then specify the idle time before the screen is locked.



You can also clear **Make pattern visible** or **Make passwords visible** if you don't want your screen lock to display as you enter it onscreen.

## Setting up face unlock

Set up face unlock if you want to unlock HTC One remix using the front camera.

1. Go to Settings, and then tap **Security**.
2. Tap **Screen lock > Face Unlock**.
3. Tap **Set it up** and follow the onscreen instructions.
4. Choose a backup unlock method to use in case the phone doesn't recognize you.

5. Tap **Lock phone after**, and then specify the idle time before the screen is locked.

To help make face unlock more reliable and more secure, you can:

- Tap **Improve face matching** to train HTC One remix to recognize your face in different situations, such as when you're wearing glasses or sporting a beard.
- Select the **Liveness check** option and you will be asked to blink to unlock the screen.

## Bypassing the lock screen

If you've set a screen lock for HTC One remix, you can just skip the lock screen and go straight to the security screen for unlocking HTC One remix.

1. Go to Settings, and then tap **Security**.
2. Select the **Bypass lock screen on wake** option.

## Navigating HTC One remix with TalkBack

Use TalkBack if you need to navigate HTC One remix by spoken feedback. When you touch the screen, HTC One remix vibrates and gives you an audible response so you know what you are touching.



Not all languages are supported.

---

### Turning TalkBack on

---

1. Go to Settings, and then tap **Accessibility**.
2. Tap **TalkBack**, and then tap the **On/Off** switch.
3. Read the TalkBack disclaimer and then tap **OK**. You'll be prompted to enable Explore by touch, which provides an audible description of what you're touching on the screen.

A short tutorial explaining how to use TalkBack will begin playing after you turn on TalkBack.



TalkBack works best if you turn off auto-rotate and turn on Explore by touch.

## Using TalkBack gestures

When TalkBack is turned on and the Explore by touch setting is selected, the regular touch gestures are replaced by the TalkBack gestures.



Media gestures such as 3-finger swiping may not be available when TalkBack gestures are enabled.

Do one of the following:

<b>Open an item</b>	<ol style="list-style-type: none"><li>1. Drag your finger on the screen to find and select the item.</li><li>2. Double-tap anywhere on the screen to open the item.</li></ol>
<b>Move an item</b>	<ol style="list-style-type: none"><li>1. Drag your finger on the screen to find the item.</li><li>2. Double-tap anywhere on the screen, but don't lift your finger on the second tap.</li><li>3. Drag the item to a new spot and then lift your finger.</li></ol>
<b>Scroll through a screen</b>	Use two fingers to swipe up, down, left or right.
<b>Unlock the lock screen</b>	Use two fingers to swipe up from the bottom of the screen.
<b>Open the Notifications panel</b>	Use two fingers to swipe down from the top of the screen.



## Assigning TalkBack shortcuts

TalkBack has customizable gestures that can be used to open the Notifications panel, view recent apps, access TalkBack controls, and more.

**F** The steps below are described using the regular gestures. Use the corresponding TalkBack gestures if you already have TalkBack turned on.

1. Go to Settings, and then tap **Accessibility**.
2. Tap **TalkBack**, and then tap **⋮** > **Settings** > **Manage gestures**.
3. Tap any of the shortcut gestures, and then select an action.

---

## Using TalkBack context menus

---

TalkBack has context menus for controlling continuous reading and global TalkBack controls. These menus can be accessed using TalkBack shortcut gestures.

1. Turn TalkBack on.
2. Do one of the following:
  - To open the continuous reading menu, use one finger to swipe up and right in one continuous movement.
  - To open the global context menu, use one finger to swipe down and right in one continuous movement.



If you already changed the TalkBack shortcut gestures, check your TalkBack settings for the appropriate gesture.

3. Press and hold anywhere on the screen.
4. Drag your finger around the screen to explore the options.



To cancel an action, drag your finger to your starting position.

---

## Changing the TalkBack reading speed

---



The steps below are described using the regular gestures. Use the corresponding TalkBack gestures if you already have TalkBack turned on.

1. Go to Settings, and then tap **Accessibility**.
2. Tap **Text-to-speech output** > **Speech rate**.
3. Select a speech rate.



You can test the speech rate by tapping **Listen to an example**.

---

## TalkBack language settings

---

1. Go to Settings, and then tap **Accessibility**.

2. Tap **Text-to-speech output** > **Google Text-to-speech Engine**, and do one of the following:

**Select a different language** Tap **Language**.

**Install a voice** Tap **Install voice data**, and then tap the language. Tap **↓** next to the voice data you want to install. When installation is completed, press **↶** twice and tap **Language**.

3. Select the language you want to use.



Not all languages are supported.

## Trademarks and copyrights

©2014 HTC Corporation. All Rights Reserved.

HTC, the HTC logo, HTC One, the HTC One logo, HTC BlinkFeed, HTC BoomSound, HTC Connect, HTC Sense, VideoPic, Zoe and all other HTC product and service names referenced herein are the trademarks or registered trademarks of HTC Corporation and its affiliates in the U.S. and other countries.

Google, Android, Android Beam, Android Market, Gmail, Google Chrome, Google Drive, Google Maps, Google Now, Google Play, Google Voice Search, Google Wallet, and YouTube are trademarks of Google Inc.

Microsoft, Windows, ActiveSync, Windows Media, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

The *Bluetooth*<sup>®</sup> word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Wi-Fi<sup>®</sup> is a registered trademark of the Wireless Fidelity Alliance, Inc.

LTE is a trademark of European Telecommunications Standards Institute (ETSI).

Facebook is a trademark of Facebook, Inc.

DLNA and the DLNA disc logo are trademarks or registered trademarks of Digital Living Network Alliance. All rights reserved. Unauthorized use is strictly prohibited.

iPhone, iTunes, Mac, and Mac OS are trademarks of Apple Inc. registered in the U.S. and other countries.

Polaris Office is a trademark of Infracore, Inc.

microSD is a trademark of SD-3C LLC.

Kid Mode and Zoodles are trademarks of Inquisitive Minds, Inc.

Motorola is a trademark of Motorola Trademark Holdings.

BlackBerry® is a property of Research In Motion Limited and is registered and/or used in the U.S. and countries around the world.

All other trademarks and service marks mentioned herein, including company names, product names, service names and logos, are the property of their respective owners and their use herein does not indicate an affiliation with, association with, or endorsement of or by HTC Corporation. Not all marks listed necessarily appear in this User Guide.

The HTC Sync Manager software can be used with materials that you own or are lawfully authorized to use and/or duplicate. Unauthorized use and/or duplication of copyrighted material may be a violation of copyright law in the United States and/or other countries/regions. Violation of U.S. and international copyright laws may subject you to significant civil and/or criminal penalties. HTC Corporation shall not be held responsible for any damages or losses (direct or indirect) that you may incur as a result of using this software.

Screen images contained herein are simulated. HTC shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from furnishing this material. The information is provided “as is” without warranty of any kind and is subject to change without notice. HTC also reserves the right to revise the content of this document at any time without prior notice.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or storing in a retrieval system, or translated into any language in any form without prior written permission of HTC.

# Index

## A

### Accounts

- syncing *171*

### Airplane mode *259*

### Alarms

- setting *234*

### Android Beam

- See NFC

### Apps

- arranging *88*
- grouping into a folder *87, 89*
- hiding or unhiding *89*
- icons on Home screen *83*
- installing *37*
- installing from Google Play *35*
- installing from the web *37*
- on Home screen *83*
- restoring *36*
- uninstalling *38*
- updating *34*

## B

### Backup

- about *173*
- HTC Sync Manager *179*
- options *173*
- restoring backed up apps *36*

### Battery

- charging *22*

- checking usage *73*
- saving battery power *74*

### BlinkFeed

- See HTC BlinkFeed

### Bluetooth

- connecting a Bluetooth headset *257*
- receiving information *253*

### Browser

- bookmarks *146*
- using *145*

### Burst mode *99*

## C

### Calendar

- creating an event *215*
- dual time zone *214*
- meeting conflicts *216*
- meeting invitations *217*
- reminders *218*
- sending quick response *218*
- views *213*

### Call history *125*

### Camera

- basics *92, 95, 98*
- capture modes *93*
- continuous shooting *99*
- filters *93*
- flash *94*
- HDR *101*
- manual settings *102*
- recording a video *98*

- selfie 99
  - slow motion 102
  - standby 92
  - sweep panorama 100
  - taking a photo 95
  - taking photo while recording 98
  - using volume buttons as controls 94
  - video resolution 98
  - zooming 93
- Capture modes
- modifying and saving 103
  - switching to 93
- Capture screen 56
- Car
- about 225
  - handling calls 228
  - HTC Car Kit 225
  - navigation 226
  - playing music 227
  - voice commands 225
- Change phone language 265
- Clock
- alarm 234
  - setting date and time 234
- Conference call 125
- Contacts
- adding 190
  - copying contacts 29, 193
  - importing contacts 29, 193, 194
  - transferring contacts 29, 193
- Continuous shooting 99
- Copy
- files 162
- Copying
- text 64

---

## D

---

- Data connection
- turning on or off 240
- Data transfer
- from Android phone 26
  - from iPhone and other phones 28
  - transferring contacts 29
- Display
- changing the time before the screen turns off 263
  - screen brightness 263
  - screen rotation 263
  - Sleep mode 42
- DLNA 159
- Do not disturb mode 260
- Driving
- See Car

---

## E

---

- Email
- See Mail
- Exchange ActiveSync
- flagging an email 210
  - meeting request 211
  - Out of office 210
  - sending a meeting request 211
- expanded storage 161

---

## F

---

- Face unlock 269
- Factory reset 184
- Files
- copying 162

Finger gestures *47*

Firmware

See Software update

Folder

- grouping apps *87*

- grouping bookmarks *146*

- removing items *87, 89*

FOTA

See Software update

---

## G

---

Gallery

- creating animated gif *113*

- creating sequence shots *114*

- custom effects *112*

- editing group shots *114*

- editing photos *110*

- removing objects in photo *115*

- Video Highlights

See Zoe

- video trimming *116*

- viewing photos and videos *105*

- viewing photos and videos by  
event *105*

- viewing photos by location *108*

- watching videos *116*

Geotag *105*

Gestures

- motion gestures *44*

- touch gestures *47*

Gmail *201*

Google Drive

- about *166*

- storage space *168*

- uploading photos and videos *168*

Google Maps *221*

Google Now

- setting up *142*

- turning off *145*

Google Play

- installing apps *35*

- refund *38*

Google Voice Search *140*

GPS (Global Positioning System)

See Location settings

Group messaging *134*

---

## H

---

Hands free *251*

Hard reset

See Factory reset

HDMI *157*

HDR *101*

Headphones

See Bluetooth

Home screen

- widgets *81*

- adding or removing widget panel *84*

- apps *83*

- arranging widget panels *84*

- changing your main Home screen *86*

- feeds *57*

- folder *87*

- launch bar *80*

- rearranging widgets and icons *84*

- removing widgets and icons *84*

- shortcuts *83*

- wallpaper *79*

- widget panel *30*

HTC BlinkFeed

- about *57*

- adding regional editions *59*



- deleting items *61*
- posting to social networks *61*
- saving articles for later *60*
- selecting feeds *58*
- setting up custom topics *59*
- turning on or off *58*

## HTC Car

See Car

## HTC Clock

- setting an alarm *234*

## HTC Media Link HD *157*

## HTC Sense version *33*

## HTC Sync Manager *179*

## I

### Idle screen

See Lock screen

### Internet

- browser *145*

### Internet connection

- data connection *240*
- VPN *246*
- Wi-Fi *243*

## K

### Keyboard

- dictionary *70*
- entering text *67*
- entering text by speaking *72*
- HTC Sense keyboard *66*
- layout *67*
- multi-language keyboard *68*
- predictive text *69*
- shortcuts *70*
- speech recognition *72*

### Kid mode

- about *238*
- choosing apps *238*
- closing *239*

## L

### Language

- system language *265*

### Location settings *220*

### Lock screen

- answering a call *123*
- dismissing an alarm *42*
- opening an app *54*
- rejecting a call *123*
- unlocking *42*
- widgets *90*

### Low battery *74*

### Low storage *163*

## M

### Mail

- attachments *205*
- carbon copy, blind copy (cc, bcc) *205*
- deleting *209*
- draft *205*
- replying *206*
- searching *209*
- sending *205*
- sorting *208*

### Mail folders

- moving email messages *208*

### Making calls

- calling *119*

### Maps

- Google Maps *221*

## Master reset

See Factory reset

Meeting request *211*

## Messages

- copying to the SIM card *137*
- deleting a conversation *137*
- draft message *133, 135*
- forwarding *137*
- group SMS *134*
- locking *138*
- replying *136*
- saving as task *136*
- sending *133*

microSD card *19*

## MMS

See Multimedia message

## Multimedia message

- attachment *133*
- group MMS *134*
- sending *133*

## Music

- adding a song to a queue *150*
- album covers *151*
- artist photos *151*
- BoomSound profile *149*
- listening *147*
- lyrics *153*
- playing music from the Lock screen *147*
- playlist *149*
- setting a song as ringtone *151*
- transferring from iPhone *182*

---

**N**


---

## Navigation

See Car

NFC (Near Field Communication) *255*

## Notifications

- panel *62*

---

**O**


---

## Online accounts

- adding accounts *171*
- removing accounts *172*
- syncing manually *171*
- what can you sync with *171*

## Online storage

- Google Drive *166*

---

**P**


---

Pair a Bluetooth headset *251*

## People

- adding a new contact *190*
- contact groups *197*
- contact link suggestions *195*
- copying contacts *29, 193, 194*
- editing contacts *192*
- filtering your contacts *188*
- groups *197*
- importing contacts *29, 193*
- merging contact information *195*
- personal profile *189*
- sending contact information *196*
- transferring contacts *29, 193*

## Phone calls

- blocking a call *126*
- call history *125*
- calling *119*
- conference call *125*
- emergency call *122*
- extension number *120*

- missed calls *120*
- muting the microphone *124*
- receiving calls *123*
- Smart Dial *119*
- speakerphone *124*
- speed dial *121*

Phone information *33*

Phone settings

See Settings

Phone updates *33*

Photos

- custom effects *112*
- location *108*
- transferring from computer *30*
- transferring from iPhone *182*
- viewing photos and videos *105*
- viewing photos and videos by event *105*
- viewing photos by location *108*

Power

- charging the battery *22*
- checking battery usage *73*
- saving power *74*
- sleep mode *42*

Print screen

See Capture screen

## Q

Quick settings *31*

## R

Recent apps *54*

Reset *183, 184*

Ring volume

- lowering ring volume automatically *127*
- making your phone ring louder *127*
- Pocket mode *127*

Ringtone

- editing *152*
- setting song as ringtone *151*

## S

Screen

- adjusting brightness *263*
- capture *56*
- changing the time before the screen turns off *263*
- idle screen *42*
- rotation *263*
- Sleep mode settings *263*

Screen lock *269*

Screen shot

See Capture screen

Scribble

- about *230*
- composing a note *230*
- grouping notes *233*
- inserting images *231*
- photo blog template *232*
- templates *230*

SD card *19*

Search

- searching phone and Web *139*
- voice search *140*

Security

- protecting phone with screen lock *269*
- storage encryption *164*

Settings

- About 33
- Accessibility 266
- display language 265
- Storage 161

Setup

- contacts from old phone 29
- initial setup 25
- photos, music, videos from old phone 30

Sharing

- events 217
- Google Drive 169
- text 65
- TV 156

Shortcuts 54

SIM card

- copying messages to 137

Sleep mode 42

Slideshow

- highlight video 117

Slow motion video 102

SMS

- See Messages

Soft reset 183

Software update 33

Sound

- lowering ring volume automatically 127
- Pocket mode 127
- ringtone, notifications, and alarm 78
- switching profiles 127

Speakerphone 124

Speed dial 121

Storage 161

Sweep panorama 100

Sync

- HTC Sync Manager 179

---

T

---

Tasks

- about 236
- creating a task 236
- managing 236
- managing lists 237

Text message 133

---

U

---

Upgrade

- See Software update

Upload

- Google Drive 168
- 

V

---

Video Highlights

- See Zoe

VideoPic 98

Videos

- editing 116
- recording 98
- taking photo while recording 98
- transferring from computer 30
- watching 116

Voice input 72

Voice search 140

VPN

- adding a connection 247
- connecting 247

---

## W

---

Waking up phone

- through power button *42*

Wallpaper

- changing *79*

Weather

- checking weather *235*

Wi-Fi

- connecting to another network *245*
- disconnecting from network *244*
- turning on *244*

Widgets

- adding *81*
- changing settings *82*
- lock screen widgets *90*
- rearranging *84*
- removing *84, 86*
- resizing *82*

Wireless display *156*

Word prediction

- bilingual prediction *69*
- 

## Y

---

YouTube

- finding videos of songs *154*
  - watching *154*
- 

## Z

---

Zoe *117*