

Table of Contents

Chapter 1 Routine Maintenance Instructions	1-1
1.1 Overview.....	1-1
1.1.1 Purposes of Routine Maintenance.....	1-1
1.1.2 Classification of Routine Maintenance Operations	1-1
1.1.3 Usage of Routine Maintenance Records	1-2
1.2 Monthly Maintenance Instructions	1-7
1.3 Quarterly Maintenance Instructions	1-7
1.4 Yearly Maintenance Instructions	1-7
Chapter 2 Fault Analysis and Locating.....	2-1
2.1 Conventional Fault Handling Process and Method	2-1
2.1.1 Classification of Faults.....	2-1
2.1.2 General Handling Procedure.....	2-1
2.1.3 Conventional Methods for Fault Judgment and Location	2-1
2.2 Typical Case Analysis	2-4
2.2.1 Software Download Fault.....	2-5
2.2.2 Initialization Failure	2-5
2.2.3 Coverage Fault	2-6
2.2.4 Module Fault.....	2-7
Chapter 3 Part Replacement.....	3-1
3.1 General Replacement Procedure.....	3-1
3.1.1 Note	3-1
3.1.2 Module Removal.....	3-1
3.1.3 Module Installation	3-2
3.1.4 Replacement Completed	3-3
3.2 Part Replacement.....	3-3
3.2.1 Module Replacement	3-3
3.2.2 Optical Fiber Replacement	3-4
Appendix A Module Maintenance Window	A-1
A.1 MTRM	A-1
A.2 MPAM.....	A-2
A.3 MFEM	A-2
A.4 MAPM	A-2
Appendix B Return Loss, VSWR and Reflection Coefficient	B-1