Wonderful Communication, Mobile Life

Welcome to U1315 Mobile Phone from Huawei Technologies Co., Ltd.

HUAWEI U1315 Mobile Phone User Guide

Notice

Copyright © 2008 Huawei Technologies Co., Ltd.

All Rights Reserved

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks

and HUAWEI are trademarks of Huawei Technologies Co., Ltd. All other trademarks mentioned in this manual are the properties of their respective holders.

Notice

The information in this manual is subject to change without notice. Every effort has been made in the preparation of this manual to ensure accuracy of the contents, but all statements, information, and recommendations in this manual do not constitute a warranty of any kind, expressed or implied. Please read the safety precautions carefully to ensure the correct and safe use of your wireless device. For detailed information, refer to the section "Warnings and Precautions".

Huawei Technologies Co., Ltd. Address:


Administration Building, Huawei Technologies Co., Ltd., Bantian, Longgang District, Shenzhen, P. R. China **Postal Code:** 518129 **Website:** <u>http://www.huawei.com</u>

Safety Precautions

Please read the safety precautions carefully to ensure the correct and safe use of your wireless device. For detailed information, refer to the section "Warnings and Precautions".



Do not switch on your phone when it is prohibited to use mobile phones or when the phone may cause interference or danger.





Follow any rules or regulations in hospitals and health care facilities. Switch off your phone near medical apparatus.



Switch off your phone in aircraft. The phone may cause interference to control signals of the aircraft.



Switch off your phone near high-precision electronic devices. The phone may affect the performance of these devices.



Do not attempt to disassemble your phone or its accessories. Only qualified personnel are allowed to service or repair the phone.



Do not place your phone or its accessories in containers with strong electromagnetic field.



Do not place magnetic storage media near your phone. Radiation from the phone may erase the information stored on them.



Do not put your phone in a hightemperature place or use it in a place with flammable gas such as a gas station.



Keep your phone and its accessories away from children. Do not allow children to use your phone without guidance.



Use only approved batteries and chargers to avoid the risk of explosions.



Observe any laws or regulations on the use of wireless device. Respect others' privacy and legal rights when using your wireless device.



Strictly follow the relevant instructions on 58 of this manual while using the USB cable. Otherwise your phone or PC may be damaged.

Table of Contents

Table of Contents 1 Getting to Know Your Phone 1

Packing List	1
Your Phone	2

Getting Started 6

Loading the SIM Card	6
Unloading the SIM Card	
Charging the Battery	
Loading/Removing a Memory Card	
Powering On/Off	
II Comdon 44	

Call Service 11

Making or Answering Calls	1′
Operations During a Voice Call	12
Operations During a Video Call	13
Calls	14

Text Input 15

T9® Input Method	15
Traditional Input Method	15
"123" Numeric Input Method	
Symbol Input Method	
Input Different Languages	16

Contacts 17

Making Calls from the Contacts	17
Searching for a Contact	17
Viewing Contacts in Phone/SIM	17
Other Operations	17
Groups	18

Messaging 20

Messages	20
Email	
Broadcast Inbox	25
Templates	25
Music 26	
Music Library	
Playlists	
Organiser & Tools 28	
Alarms	
Calendar	
Task	
Memo	
Synchronise	
Calculator	
Unit converter	
Currency converter	
Voice recorder	
World Time	
Stopwatch	
Timer	
Service dial number	
My Files 34	
Browser 35	
Open homepage	
Open new page	

Saved pages	
History	
Resume	
Settings	

Entertainment 37

Games	37
Camera	37

Connections 39

Bluetooth	
	41

Settings 46

Phone Settings	46
Display Settings	
Message Settings	47
Call Settings	
Video Call	50
Contacts Settings	50
Java Settings	50
Connectivity	51
Network	51
Security	51
DRM Setting	52

Warnings and Precautions 53

Electronic Device	53
Hospital	53
Area with Inflammables and Explosives	53
Storage Environment	54
Children Safety	.54

Operating Environment	
Cleaning and Maintenance	
Environmental Protection	
Emergency Calls	56
Battery	
Charger	57
Using the USB Cable	58
Certification Information (SAR)	58
Acronyms and Abbreviations 61	
Appendix 62	
Index 1	

1 Getting to Know Your Phone

Your HUAWEI U1315 phone can operate in virtually all countries, automatically switching between WCDMA 850/1900 and GSM/GPRS/EDGE 850/ 1800/1900 networks. This allows you to enjoy communication wherever you use your mobile phone.

Note The services supported by your phone should be also supported by the network from where you use the phone. For details, please consult your service provider.

Packing List


Your phone package box contains the following:



- One HUAWEI U1315 mobile phone
- 2 One travel charger
- 3 One Li-ion battery
- 4 One user Guide
- 5 One headset
- 6 One USB data cable

Your Phone


Your Phone




Back View



Side View



Home Screen



Icon bar

This area displays the phone status. The following table illustrates all the icons that may appear on this bar.

Icon	Description
Щ	Indicates signal strength. The more bars that appear, the stronger the signal.
	The phone is currently in a GSM network.
G	The phone is currently in a GPRS net- worfk.

Your Phone

lcon	Description
E	The phone is currently in a EDGE net- work.
MG	The phone is currently in a WCDMA network.
	You are using the roaming service.
	Bluetooth is enabled.
۲	Indicates network connection state.
	Indicates security connection state of the network.
E»	The phone is in a call.
	Forwarding all incoming voice calls to line 1.
	Call line 2 is enabled currently.
	Forwarding all incoming voice calls to line 2.
Ø	Alarm clock is enabled.
	You have new text messages.

lcon	Description
Ś	You have new PUSH messages.
J	You have new multimedia messages.
ß	You have new voice mail.
	SD card is inserted.
Ja Ja	Ringtone is enabled.
	The vibration mode is enabled.
	The phone is in mute mode.
	The normal profile is activated.
n	The headset is plugged in.
	Your PC connects to the Internet
	through your phone.
A	Indicates power level of the battery.
•	The background play is activated.