







Email


Adding an account

- ① On the home screen, touch .
- ② Select an email account type.
- ③ Enter your **Email address, Password** or other information, then touch **Next**.
- ④ Follow the onscreen instructions to configure your account. The system then automatically connects to the server and checks server settings.



Sending an email

- ① On the home screen, touch .
- ② Touch .
- ③ Enter one or more recipients, and write your message. Touch  to upload any attachments.
- ④ Touch  to send the email.



Customize Home Screen

Changing the wallpaper

- ① On the home screen, touch and hold a blank area and touch **WALLPAPERS**.
- ② On the Wallpapers screen, you can set the following items:
 - **Lock screen wallpaper:** Set the wallpaper displayed on the lock screen.
 - **Home screen wallpapers:** Set the home screen wallpaper.
 - **Random change:** Have the home screen wallpaper change randomly.







Adding a widget

- ① On the home screen, touch and hold a blank area and touch **WIDGETS**.
- ② Flick left to view more widgets.
- ③ Touch and hold the widget you want to add and drag it to the home screen.





Text and Picture Messaging

Sending a message

- ① On the home screen, touch .
- ② Touch .
- ③ Touch the recipient text box and enter the contact name or phone number.
- ④ Write your message.
 -  You can touch  to select an attachment type and attach a file.
- ⑤ Touch **Send**.




Configuring an input method


- ① On the home screen, touch  > .
- ② Touch **Language & input**.
- ③ Under **Keyboard & input methods**, touch the input method you want to configure.



Internet




Turning on your mobile network


On the home screen, flick down from the status bar to open the notification panel. Touch  to turn on your phone's mobile network.

-  When you don't need to access the Internet, turn off your mobile network to save battery power and reduce mobile data usage.






Browsing web pages

- ① On the home screen, touch .
- ② Enter a website address in the address box. Your phone then displays matching websites as you type.
- ③ Touch the website you want to visit.
 -  Your browser supports multi-page browsing. Touch  to switch between pages.







Camera and Video Recording

Taking a photo

- ① On the home screen, touch .
- ② Touch  to select a capture mode.
- ③ Frame the scene you want to capture. Let your camera focus automatically or touch the screen to focus on that specific area.
- ④ Touch .



Recording a video

- ① On the home screen, touch .
- ② Frame the scene you want to record.
- ③ Touch  to start recording.
 -  During the recording, touch an object or area you want to focus on.
- ④ Touch .



AT&T Services

Make the best of your phone with useful applications from AT&T.



AT&T Hot Spots: Take your Internet with you! With AT&T Wi-Fi access at more than 20,000 AT&T Wi-Fi hotspots nationwide - including hotels, convention centers, Starbucks®, and McDonald's® - it's easy to stay connected.



AT&T Navigator: Get voice-guided, turn-by-turn driving directions and traffic updates right on your phone!



Mobile TV: Enjoy LIVE sports, breaking news and hundreds of on-demand & downloadable TV shows.



MyAT&T: Track your usage, review and pay your bill, and update your data plan services.



YP: Find restaurants, bars, businesses, and more, whether around the corner or across the nation.

Note: Data usage and subscription charges may apply. For more AT&T applications, open the AT&T tab in Android Play Store.

Model: HUAWEI Y536A1



31010SHM_01