
ATTACHMENT E.


DATE: MARCH 13, 2001


- USER'S MANUAL

REPORT NO: HCT-F01-0301 FCC ID: PJIL18C0D080 DATE: MARCH 13, 2001





REPORT NO: HCT-F01-0301







2. Safety Information 1. Introduction imageFlat You can prevent serious electrical shock and other hazards by keeping in mind This Monitor has been engineered and manufactured to assure your safety. the following: Hyundai ImageFlat L80A is a highly ergonomic color display unit This manual contains instructions for installing and operating the Hyundai ImageFlat L80A. VESA DDC1/2B compatibility **VESA DPMS (Display Power Management Signalling)** Most Advanced image scaling Fast and Accurate Auto Adjustment Digital signal Input by DVI-D compatibility. Connection to PC, S-Vedio, VTR, DVD Player etc. Advanced Digital On-Screen-Controls Supporting full scan flicker-free picture quality 18.1" viewable SXGA LCD 100-240V AC input voltage material and never touch them with metallic or cord. Never cover the ventilation openings with any inflammable materials. Do not place anything wet on the monitor or the power 1/25 NEXT









imageFlat 3-3. Connecting the 3-2. Selecting a suitable 15 pin D-sub DVI-D cable monitor this guide. on. If not, repeat steps 1,2,3 and 4 or refer to the Troubleshooting section of Turn on the monitor using the power switch and check that the power LED is Plug the other end of the power cord to your computer's mains supply or to a Plug the power cord connection to connection on the monitor. connection on your computer and screw it down. Connect the audio cable to Insert the other 15-pin /DVI-D signal cable connector into the 15-pin VGA/DVI-D Position the monitor directly in front of you at a comfortable reading distance Position the monitor so that the top of the screen is no higher than eye level. Place the monitor in a position where no light shines directly onto or is equipment and allow at least 10cm on each side for ventilation. Place the monitor at least 30cm from other electrical or heat-emitting 100V-240V earthed electrical outlet. the display unit and the system unit. background such as a window. reflected on the screen. (around 45 to 90cm) To reduce eye strain, avoid installing the display unit against a bright electric shock, always connect your equipment to power is off on all units. To avoid any possibility of Before you start cabling your monitor, check that the properly earthed outlets. 5/25 NEXT








TEL: +82 31 639 8518


FAX: +82 31 639 8525
























FAX: +82 31 639 8525


TEL: +82 31 639 8518



















TEL: +82 31 639 8518





imageFlat Contacting service problem, contact an authorized service agent. If the monitor is sent for Unplug the display unit from the power outlet and contact a service agent service, use the original package if possible. If the above troubleshooting hints do not help you find a solution to the The monitor exhibits a distinct change in performance. the monitor. The monitor has been exposed to rain, or water or liquid has been spilled onto The monitor has been dropped or the cabinet has been damaged. The monitor does not operate normally according to the operating instructions. 25/25 NEXT

