

GC-300 Electronic Game Caller Operating Instructions



CALL OF THE WILD
A NEW REVOLUTION IN ELECTRONIC GAME CALLERS

Log on to icotec.com and join the RELOAD forum. RELOAD is a forum designed for predator hunters who are interested in sharing their expertise, wisdom and opinions. For those not as experienced in predator hunting, it's a great place to learn tips and get to know hunters who can lend you insight. We look forward to seeing you online.

90-DAY LIMITED WARRANTY

Your ICOTec product is warranted to be free of material defects and workmanship for 90 days after the date of purchase. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than an authorized service contractor. Any return made under this warranty must be accompanied by the items listed below:

- 1) A check/money order in the amount of \$10.00 to cover the cost of postage and handling
- 2) Name and address
- 3) An explanation of the defect
- 4) Proof of purchase with date of purchase
- 5) Product should be well packed in a sturdy shipping carton with return postage prepaid to the address listed below:

Attn.: Repairs

ICOTec, LLC
5247 Secor Rd. Unit 5
Toledo, OH 43623

This warranty gives you specific legal rights.

Specifications and product designs are subject to change without prior notice or obligation.

©2012 ICOTec. All rights reserved.

Thank you for the purchase!

Please fill out your product registration information and mail it back to us **within 15 days** of your purchase date. Or, you may go to our web site to register your product. Please retain your original receipt in the event that you would need to return the unit for a warranty repair.

Failure to mail in your product registration card, or registering your product on our web site within the 15 day period of the purchase will result in the voiding of the warranty.

First Name: _____

Last Name: _____

Street Address: _____

City: _____

State: _____

Zip: _____

Email Address: _____

Date of Purchase: _____

Model Number: _____

Serial Number: _____

Setup & Operation Instructions

ICOTec GC300 Electronic Game Caller

1

Add Batteries

Open battery panel with phillips screw driver, place 4 new AA batteries as indicated, close panel and replace screw.

2

Turn Power Switch On

Slide switch to the right, red LED indicator will light up if unit is on. If it does not light up, open panel and be sure all batteries are new and in proper position.

3

Raise Antenna

Place antenna in upright position on main unit.

4

Select Prey Call

Raise antenna on remote control and press button of desired call sound.

5

Adjust Volume

Press volume up arrow for louder or volume down arrow for quieter.

6

Add Second Call

Press second desired call sound, both calls play until you select STOP.

7

End Calls

Press STOP.

FCC Notice to User

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Check out more of our products at your favorite retailer or online at icotec.com.

If your retailer does not yet carry our products, ask them to.



Predator Game Calls & Trail Cameras

ICOTec

Hunting, Fishing and Outdoor Technology.

**GC-300 Electronic Game Caller
Warranty Registration Card**

Mail to:

ICOTec

ATTN: Warranty Department

5247 Secor Road, Unit 5

Toledo, OH 43623

Or, Log on to:

www.icotec.com

Predator Calls (GC300)

Coyote Female	Bobcat Adult
Coyote Howl	Cottontail Distress
Coyote Male	Coyote Pup Distress
Crow Baby Distress	Fawn Distress
Raccoon Baby Distress	Gray Fox Distress
Woodpecker Baby Distress	Jack Rabbit Distress