


- Remocon

Driver Set Up




1. After click [Start] button, select "Control Panel".
2. Double click "System" icon.
3. Select "[Hardware]" tap on "System Properties" screen.

Driver Set Up




4. Select "[Device Manager]" button on "System Properties" screen.

Driver Set Up



5. Select "Never Ending Tech Remocon" item.
6. Mouse right button after click, select "Properties" item.

Driver Set Up



7. In general tap, click "Reinstall Drive" button.

Driver Set Up



8. After select "Install the software automatically [Recommended]" item, click "Next" button.

Driver Set Up



9. While find and install driver, "Warning" opens


10. Click "Continue Anyway" button.

Driver Set Up



11. Click "Finish" Button.


Driver Set Up



12. All driver installs completed.


Power VCR

- Program Menu



Power VCR

- Program Menu



Power VCR

- Program Menu

Video display



-   Switches between large and small screen mode
-   Activates the Always On Top function (off/on)
-  Maximizes video display to full screen
-  Enters the surfing mode for previewing channels simultaneously

Power VCR


- Program Menu

Modes controls




- Win 98 Setup

Win98 Driver Set Up



1. After click [Start] button, select "Control Panel".
2. Double click "System" icon.
3. Select "[Hardware profiles]" tap on "System Properties" screen.

Win98 Driver Set Up



4. Select "PCI Multimedia Device" item.
click "Properties" button.

Win98 Driver Set Up



5. In general tap, click "Reinstall Driver" button.

Win98 Driver Set Up



6. click "Next" button.

- Win 98 Setup

Win98 Driver Set Up



7. After select **"Search for a better Driver than the one your device is using now.[Recommended]"** item, click **"Next"** button.

Win98 Driver Set Up



8. Check "V" to "specify a location".

9. After input "D:\Option\English\TV\Win98_Me" to blank, click "Next" button.

Win98 Driver Set Up



10. Click **"Next"** button.


Win98 Driver Set Up



11. Click **"Finish"** Button.

• Win 98 Setup

Win98 Driver Set Up



12. Select "PCI Multimedia video Device" item.
click "Properties" button.

Win98 Driver Set Up



13. In general tap, click "Reinstall Drive" button.

Win98 Driver Set Up



14. Click "Next" button.

Win98 Driver Set Up



15. After select "Search for a better Driver than the one your device is using now.[Recommended]" item,
click "Next" button.

• Win 98 Setup

Win98 Driver Set Up



16. Check "V" to "specify a location".
17. After input "D:\Option\English\TV\Win98_Me" to blank, click "Next" button.

Win98 Driver Set Up




18. Click "Next" button.

Win98 Driver Set Up



19. Click "Finish" button.

Win98 Driver Set Up



20. All driver installs completed.


- Win 2000 Setup

Win2000 Driver Set Up




1. After click [Start] button, select "Control Panel".
2. Double click "System" icon.
3. Select "[Hardware]" tap on "System Properties" screen.

Win2000 Driver Set Up




4. Select "[Device Manager]" button on "System Properties" screen.

Win2000 Driver Set Up



5. elect "Multimedia controller" item.
6. Mouse right button after click, select "Properties" item.

Win2000 Driver Set Up



7. In general tap, click "Reinstall Drive" button.


- Win 2000 Setup

Win2000 Driver Set Up



8. Click "Next" button.

Win2000 Driver Set Up



9. After select "Search for a suitable Driver for my Device [Recommended]" item, click "Next" button.

Win2000 Driver Set Up



10. Check "v" to "specify a location". Click "Next" button.

Win2000 Driver Set Up



11. After input "D:\Optin\English\TV\Win2000_Xp" to blank, click "OK" button.

- Win 2000 Setup

Win2000 Driver Set Up




12. Click "Next" button.

Win2000 Driver Set Up



15. Click "Finish" Button.

Win2000 Driver Set Up



16. "Found New hardware Wizard" opens by "Plug & Play" action.
17. Click "Next" button.

Win2000 Driver Set Up



16. "Found New hardware Wizard" opens by "Plug & Play" action.
17. Click "Next" button.

- Win 2000 Setup

Win2000 Driver Set Up



18. After select "Search for a suitable Driver for my Device [Recommended]" item, click "Next" button.

Win2000 Driver Set Up



19. Check "v" to "specify a location". Click "Next" button.

Win2000 Driver Set Up



20. After input "D:\Optin\English\TV\Win2000_Xp" to blank, click "OK" button.

Win2000 Driver Set Up



21. Click "Next" button.

- Win 2000 Setup

Win2000 Driver Set Up



22. While find and install driver, "Warning" opens.

23. Click "Yes" button.

Win2000 Driver Set Up



25. "Found New hardware Wizard" opens by "Plug & Play" action.


26. Click "Next" button.

Win2000 Driver Set Up



24. Click "Finish" Button.


Win2000 Driver Set Up



27. After select "Serach for a suitable Driver for Device [Recommended]" item, click "Next" button.

- Win 2000 Setup

Win2000 Driver Set Up



28. Check "V" to "specify a location".
Click "Next" button.

Win2000 Driver Set Up




29. After input "D:\Optin\English\TV\Win2000_Xp" to blank, click "OK" button.

Win2000 Driver Set Up



30. Click "Next" button.

Win2000 Driver Set Up



31. While find and install driver, "Warning" opens

32. Click "Yes" button.


- Win 2000 Setup

Win2000 Driver Set Up



33. Click **"Finish"** Button.

Win2000 Driver Set Up



34. Select **"Multimedia video controller"** item.

35. Mouse right button after click, select **"Properties"** item.

Win2000 Driver Set Up



36. In general tap, click **"Reinstall Drive"** button.

Win2000 Driver Set Up



37. Click **"Next"** button.

- Win 2000 Setup

Win2000 Driver Set Up




38. After select "Serach for a suitable Driver for my Device [Recommended]" item, click "Next" button.

Win2000 Driver Set Up




40. After input "D:\Optin\English\TV\Win2000_Xp" to blank, click "OK" button.

Win2000 Driver Set Up



39. Check "V" to "specify a location". click "OK" button.

Win2000 Driver Set Up



41. click "Next" button.

- Win 2000 Setup

Win2000 Driver Set Up



42. While find and install driver, "Warning" opens.


43. Click "Yes" button.

Win2000 Driver Set Up



44. Click "Finish" Button.

Win2000 Driver Set Up



45. All driver installs completed.

• Win Xp Setup

WinXP Driver Set Up




1. After click [Start] button, select "Control Panel".
2. Double click "System" icon.
3. Select "[Hardware]" tap on "System Properties" screen.

WinXP Driver Set Up




4. Select "[Device Manager]" button on "System Properties" screen.

WinXP Driver Set Up



5. Select "Multimedia controller" item.
6. Mouse right button after click, select "Properties" item.

WinXP Driver Set Up



7. In general tap, click "Reinstall Drive" button.


- Win Xp Setup

WinXP Driver Set Up



8. After select "Install from a list or specific location [Advanced]" item, click "Next" button.

WinXP Driver Set Up



9. Check "V" to "Include this location in the search".

10. After input "D:\Option\English\TV\Win2000_Xp" to blank, click "Next" button.

WinXP Driver Set Up



11. While find and install driver, "Warning" opens.

12. Click "Continue Anyway" button.

WinXP Driver Set Up



13. Click "Finish" Button.


• Win Xp Setup

WinXP Driver Set Up



14. "Found New hardware Wizard" opens by "Plug & Play" action.
15. After select "Install from a list or specific location [Advanced]" item, click "Next" button.

WinXP Driver Set Up



16. Check "V" to "Include this location in the search",
17. After input "D:\Option\English\TV\Win2000_Xp" to blank, click "Next" button.

WinXP Driver Set Up



18. While find and install driver, "Warning" opens
19. Click "Continue Anyway" button.

WinXP Driver Set Up



20. Click "Finish" Button.

• Win Xp Setup

WinXP Driver Set Up



21. "Found New hardware Wizard" opens by "Plug & Play" action.
22. After select "Install from a list or specific location [Advanced]" item, click "Next" button.

WinXP Driver Set Up



23. Check "v" to "Include this location in the search".
24. After input "D:\Option\English\TV\Win2000_Xp" to blank, click "Next" button.

WinXP Driver Set Up



25. While find and install driver, "Warning" opens
26. Click "Continue Anyway" button.


WinXP Driver Set Up



27. Click "Finish" Button.

• Win Xp Setup


WinXP Driver Set Up



28. Select "Multimedia video controller" item.

29. Mouse right button after click, select "Properties" item.

WinXP Driver Set Up




30. In general tap, click "Reinstall Drive" button.

WinXP Driver Set Up



31. After select "Install from a list or specific location [Advanced]" item, click "Next" button.

WinXP Driver Set Up



32. Check "V" to "Include this location in the search".

33. After input "D:\Option\English\TV\Win2000_Xp" to blank, click "Next" button.

- Win Xp Setup

WinXP Driver Set Up



34. While find and install driver, "Warning" opens.


35. Click "Continue Anyway" button.

WinXP Driver Set Up



36. Click "Finish" Button.

WinXP Driver Set Up



37. All driver installs completed.