

Ancall Quick Start Guide

Battery installation



Find the tiny hole on the side. Pop open the tray. Install the battery. Close the tray, Done!

Download & Setting up Your App

1. Download Ancall app in the App Store or from the Google Play.
2. Launch the App and create your Ancall account.
3. Log in to Ancall app.
4. Follow the prompts to allow your Ancall device access to Bluetooth.
5. Briefly press the button on the Ancall device and claim it in your app.

LED indicator guide

- If it has No light, the power supply is not working, please check the battery is well installed or check Ancall official web site for further information.
- Red light flashes 4 times: Setting Error. Please install the battery again.
- Blue light flashes 4 times: Ancall Smart Tracker is initializing.
- Click the Ancall button & Blue light flashes once: connection is on.
- Click & hold for 3 sec. then red light flashes 3 times.

Name: Ancall Smart Tracker
 Model No.: AC-GS11
 Dimension: 38mm*38mm*7.5mm
 Voltage: <3V
 Current: <0.02mA
 Battery: Replaceable CR2032 Coin Battery
 Battery life: Standby Time Up to 12 months
 Connectivity: Bluetooth 4.0 (Bluetooth Low Energy)
 Alert Range: 6~50ft / 2~15m
 Alert: 73 dB loud speaker
 Number of pairing per phone Up to 5
 Compatibility: Bluetooth 4.0 BLE device

CAUTION:

To assure continued FCC compliance:
 Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

FCC Label Compliance Statement:
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Scale	比例	1:1
Size	尺寸	95x95mm
Thickness	印刷	四色印刷
Material	材質	120g銅版紙
Cover	表面處理	整面亮P

Inventec Besta Co., Ltd.		
MODEL CAF11AAB0G	FILE NO. CAF11AABMANUCVART_1V1	
DRAW NAME 英文使用手冊		11 / 23
APPROVAL	CHECK	DESIGN Vanessa Lin