

USING CALLER ID AND CALL WAITING ID

One of the best features of your phone is *Caller ID*, which allows you to see information about an incoming call before you pick up the phone. With *Caller ID* service from your local telephone company, The MRS1100 telephone displays and records information about the call in a log.

Possibly even better than *Caller ID* is *Call Waiting ID*. In addition to providing normal *Caller ID* information, *Call Waiting ID* allows you to see caller information while you are on a call. Now you can have the information you need to choose whether or not to answer a waiting call.

Before you use these features on your MRS1100 telephone, you must first subscribe to the services through your local telephone company, and set "CALL WAITING ID ON or OFF" correctly during the **SETTING UP YOUR PHONE** procedure.

For more details on **CALLWAITING ID ON/OFF**, see **STEP 10. Turning on Callwaiting ID** on page 10.

RECEIVING NEW CALLS

When you receive a new call, the information is stored under **CALLER** area.

When you press *◀ (review) ▶# key, it tells you:

- ☐ How many total calls you have.
- ☐ How many new calls you have since you last reviewed your calls.

ALL 23 NEW 03

When you receive a call, the CS201 displays the caller information sent by the Telephone Company, called a *Call Record*.

The call record consists of the following information:

- ☐ The caller's name(If available)
- ☐ The caller's telephone number
- ☐ The time and date of the call
- ☐ A call record number
- ☐ NEW CALL LCD indicator
- ☐ LOW BATTERY indicator
- ☐ LONG DISTANCE indicator
- ☐ MESSAGE WAITING (VOICE MAIL) indicator

Total call records

NEW CALL	25 10 / 25 10 : 35 PM	BATT LONG
SMITH JOHN		
5 5 5 5 5 5		

✉

REVIEWING CALL RECORDS

To review a call Record:

1. Press *◀ (review) ▶# key to see how many new calls you have.
2. Use *◀ (review) ▶# key to move though the Call Record list
3. Press **FLASH** key to exit call records review mode.

ISV CO., LTD.
FCC ID: PE3ISD-210
JOB #: 594U0
EXHIBIT #: 8Q

- Press (review) ►# key to see the most recent call record.
- Press *◀ (review) key to see earlier calls.

When you reach either end of the Call Record list,
you see an 'END OF LIST' message. If you
continue to press *◀ (review) ►# key,
you scroll through the list again.

END OF LIST

DIALING FROM CALL RECORDS

You can use the TALK key to dial any number in your caller ID list.

1. Press *◀ (review) ►# key to see your Call Records and to find the desired call record.
2. Press TALK key to dial directly when you review the caller ID list.
The phone dials automatically 7 digits, 10 digits and long distance calls.

SAVING CALL RECORDS

Your phone stores up to 60 Call Records before the memory becomes full.

When the next call comes in, the oldest record drops off and makes room for the new Call Records.

To save specific calls, delete old and unnecessary call records to keep from filling your phone's memory.

DELETING CALL RECORDS

You can either delete a single record or you can delete all Call Records at one time.

To delete a single record:

1. Press to *◀ (review) ►# key to see your Call Records.
2. Use *◀ (review) ►# key to find the desired Call Record.
3. Press DELETE key once, and the MRS1100 asks if you want to erase this Call Record.
4. Press DELETE key again to erase the Call Record.

The MRS1100 deletes the Call Record, gives you
a confirmation beep,

CALL 25 10 / 25 10 : 35 PM

DELETE ?

5 5 5 5 5 5


If you do not wish to delete the Call Record, press *◀ (review) ►# key to cancel.

To delete all Call Records:

1. Press *◀ (review) ►# key . The display shows you how many call records you have.
2. Press DELETE key and the MRS1100 asks if
you want to delete all Call Records.

ALL 23 NEW 03


- 3. Press **DELETE** key again and the MRS1100 clears all Call Records, gives you a confirmation beep.




SEEING LONG RECORDS

If you receive long records on caller ID information, you could see that to use the ▲ (VOL) ▼ key. the ▲ (VOL) ▼ key allows you to scroll back and forth to see long records.

- 1. Press *◀ (review) ▶# key.
The display shows you long records




- 2. Press ▲ (VOL) ▼ key to see remain numbers



READING DISPLAY MESSAGES

The MRS1100 informs you of status by displaying the following messages :

Message	Display
ALL CALLS & NEW CALLS: This message lets you know how many call records you have, and how many of those call records are new, In this example, you have 23 call records, and 3 new calls.	ALL 23 NEW 03
CHARGING: The handset BATTERY is getting low. Place the handset in the base in order to recharge.	ALL 23 NEW 03
DELETE ALL?: You pressed the DELETE key after pressing the *◀ (review) ▶# key.	DELETE ALL ?
DELETE ? : To delete a single record, You pressed DELETE key after pressing the *◀ (review) ▶# key.	CALL 25 10 / 25 10 : 35 PM DELETE ? 5 5 5 5 5 5
END OF LIST: You have reached the end of the call records. Press either *◀ (review) ▶# key to see other records.	END OF LIST
DATA ERROR : The message sent is incomplete data This message usually indicates temporary interference. There is no problem with the phone.	DATA ERROR
MESSAGE WAITING : The MRS1100 flashes LED (baseunit) slowly to alert you and appears on the display “ Message waiting “ When you receive new messages in your mail box.	
NO CALLS: There are no call records in the caller ID memory.	NO CALLS