

# Software Drivers and Utilities

**T**his chapter introduces the software drivers and utilities supplied with your computer.

---

## Drivers Listing

---

---

To take advantage of dedicated functions on your computer, you need to install specific drivers. Your dealer should have installed the drivers for you. You only need to re-install them when you re-install the operating system. For installation instructions, see the README or other text files on the CD.

Described below are what the drivers are for:

### **Audio driver**

The audio driver is required for using the audio functions of the computer.

**6**

### **VGA driver**

The VGA driver is required for setting high-resolution displays of the computer.

### **CD-ROM drive driver**

The CD-ROM drive driver is required for using the CD-ROM drive under MS DOS.

### **PCMCIA**

### **CCD Driver**

For CCD camera

### **Card Reader**

### **IR**

### **Mini PCI**

For LAN and Modem functions