

**DO NOT PRINT PINK DIELINE**  
**PAPER SIZE is A5 - 148mm X 210mm**  
**Print Double Sided**



**LED Candle  
with Built-In  
Bluetooth® Speaker**  
**Model: ITS-B-418**



**Instruction Manual**



Please read this instruction manual carefully before use and keep for future reference.

**CONTENTS**

Safety Instructions.....1  
Turning ON / OFF the Unit.....3  
Playing Audio.....3  
Battery Charging.....4  
Troubleshooting.....4  
Important Information.....5  
Warranty.....6

**PRODUCT SPECIFICATIONS**

Bluetooth Version	2.1 + EDR
Bluetooth Range	Up to 33 feet (10 meters)
Play Time	3 hours of Play Time (At Max Volume) 4 hours of Play Time (At 50% Volume)
	Battery 3.7V 500mA Lithium-Ion
Charging Input	DC 5V, 1.0A
Charging Time	1.5 Hours
Speaker:	One 3-Watt Speaker
Connections:	Micro USB
Product size:	3 x 3 x 9 in (76.2 x 76.2 x 229mm)
Included:	LED Candle with Built-In Bluetooth Speaker, Micro USB Charging Cable, User Manual

**NOTE:** As a result of continual improvements, the design and specifications of this product are subject to change without notice.

Made in China.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.  
Other trademarks and trade names are those of their respective owners.

**SAFETY INSTRUCTIONS**

The lightning flash with arrowhead within an equilateral triangle is intended to alert the user to the presence of unshielded "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

**CAUTION**  
RISK OF ELECTRIC SHOCK  
DO NOT OPEN

**CAUTION: TO PREVENT RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVERS (IF BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PROFESSIONAL.**

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**Before using the unit, be sure to read all operating instructions carefully, please note that these are general precautions and may not pertain to your unit. For example, this unit may not have the capability to be connected to an outdoor antenna.**

- Read these instructions - All safety and operating instructions should be read before the product is operated.
- Keep these instructions - The safety and operating instructions should be retained for future reference.
- Heed all warnings - All warnings on the product and in the operating instruction manual should be adhered to.
- Follow these instructions - All operating and use instructions should be followed.
- Do not use this apparatus near water. Do not use the product near water and moisture, for example: near a bathtub, washbowl, kitchen sink or laundry tub; in a wet basement; or near a swimming pool.
- The product must not be exposed to dripping or splashing, and not object filled with liquid should be placed on top of the product.
- Clean only with slightly moist, lint-free cloth. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet and in the back or bottom are provided for ventilation, to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should never be placed near or over a radiator or heat source. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture does not operate normally, or has been dropped.
- Power source - The product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
- Power lines - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- Overloading - Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.



**SAFETY INSTRUCTIONS**

- Object and liquid entry - Never push objects of any kind into the product as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid on the product.
- Service - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified servicing personnel.
- Replacement parts - When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original part. Unauthorized substitutions may result in fire or electric shock or other hazards.
- Safety check - Upon completion of any service or repairs to this product ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- Damage requiring service - Unplug the product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
  - when the power-supply cord or plug is damaged.
  - if liquid has been spilled or objects have fallen into the product.
  - if the product has been exposed to rain or water.
  - if the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
  - if the product has been dropped or the cabinet damaged in any way.
  - when the product exhibits a distinct change in performance - this indicates a need for service.
- The marking information is located at the bottom of the apparatus.

**Warning**  
Please refer the information on exterior bottom enclosure for electrical and safety information before installing or operating the apparatus.

- Caution:**
- Use of control and adjustments or performance of procedures other than those specified here may result in hazardous radiation exposure.
  - If this product develops trouble, contact qualified service centers, and do not use the product in a defective state.

- Usage**
- Before use, choose unit installation location carefully. Avoid placing in direct sunlight or close to a source of heat. Also avoid locations subject to vibrations and excessive dust, cold or moisture. Keep away from sources that hum, such as transformers or motors.
  - Do not open the unit as this might result in damage to the circuitry or electrical shock. If a foreign object should get into the set, contact your dealer.
  - Do not attempt to clean the unit with chemical solvents as this might damage the finish. Use a clean, dry cloth.
  - Be sure to unplug the unit if you do not intend to use it for an extended period of time, such as while on vacation.
  - Keep this manual in a safe place for future reference.

**TURNING ON / OFF THE UNIT**

**Turning the unit ON:**  
Slide the ON/OFF switch on the base of the candle to the ON position. The LED Candle will illuminate and a tone will beep indicating the unit is searching for a Bluetooth enabled device.

**Turning the unit OFF:**  
Slide ON/OFF switch to OFF. LED Candle & Bluetooth speaker will turn off.

**NOTE:**  
Candle and Speaker feature work simultaneously and can not be used or turned on/off individually.

**PLAYING AUDIO**

- Bluetooth Connection:**
- Turn ON the candle, the speaker will automatically begin searching for a Bluetooth device indicated by an audible tone.
  - Activate the Bluetooth function on your external device.
  - Select "ITS-B-418" on your device to begin pairing. You will hear an audible beep, signifying your device is paired.
  - Begin playing music on your device. You can control playback, pause, next and previous functions on your connected device.

If your device asks for password or PIN number, please enter "0000."

- NOTE:**
- The operational range between this unit and a Bluetooth device is approximately 33 feet (10 meters). The device will also disconnect when the device is moved beyond the operational range.
  - To reconnect the device to the unit, place it within the operational range.
  - Before you connect a Bluetooth device to this unit, familiarize yourself with the Bluetooth capabilities of your device.
  - Compatibility with all Bluetooth devices is not guaranteed.
  - Any obstacle between this unit and a Bluetooth device can reduce the operational range.
  - Keep this unit away from any other electronic device that may cause interference.

**BATTERY CHARGING**

- Recharge the internal battery by inserting the supplied Micro USB Cable into the DC 5V Input port on the side of the candle. Connect the other end to a PC or other charger (smartphone charger) with 5V output (not included). The red LED located by the input port will remain lit while charging. When the charging process is complete the LED will turn blue. Charging will take up to 1.5 hours, depending on charging source. PLEASE NOTE: The Candle will work while charging.

**Caution:** The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the trash or in a fire. Do not dispose device in standard garbage disposal sites. Dispose of device at available Battery Recycling Sites after fully discharging battery. Not doing so may violate local disposal laws and regulations. Please refer to local regulations for proper battery disposal.

**TROUBLESHOOTING**

**Unit is not powering ON:**  
- The Units Battery may be fully drained. Connect the unit to a USB power source to recharge the battery.

**Unable to connect to the speaker:**  
- Check if the Bluetooth connection is activated on your device. If not, then turn ON your devices Bluetooth connection. See "Bluetooth Connection" for more help.

**The Device is Connected via Bluetooth but there is no sound Playing:**  
- The Bluetooth connection may be out of working distance. Move your device closer (33 feet or 10 meters) so that it is within the proper range.  
- Check to see if your Bluetooth enabled device is in playback mode. If it is not, put it in playback mode.

**IMPORTANT INFORMATION**

**FCC Statement**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is measured RF output power is less than the SAR exclusion threshold value for human head and body. Therefore, SAR test is not necessary.

**WARRANTY STATEMENT**

**Innovative Technology Electronics Corp.  
Limited Warranty: 90 Days Labor, One Year Parts**

Innovative Technology Electronics Corp. (IT) warrants the product to be free from "Defects" in materials under normal use for a period of "One Year" from the date of the original purchase. The Warranty is "Not" transferable. IT agrees, within the initial "90 Day" period, to repair or replace the product if it is determined to be defective at "No Charge". It is further agreed that IT will cover the cost to repair or replace damaged "Parts" only for a total period of "One Year" from the date of the original purchase. The warranty does not cover cosmetic damage, antennas, AC cords, cabinets, headbands, ear-pads, or damage due to line power surges, connection to improper voltage supply or settings, misuse, mishandling, accident, acts of God or attempted repair by an unauthorized service agent.

**To obtain service, the purchaser MUST present an original sales receipt / proof of purchase. Please contact us at [www.ithomeproducts.com](http://www.ithomeproducts.com) to request an RMA (Return Material Authorization) number to return products for service or replacement.** Returns without an RMA number on the package will be refused and returned to sender. Upon receipt of the returning item and our full inspection (IT) may issue a replacement to customer for the same item or of one that has equivalent value and features. To return an item, supply full name, return address, phone number, item purchased, receipt of purchase and reason for return to obtain RMA number.

All returns must be in the original packaging or reasonable substitute to prevent damage. Customer "Must" include full name, shipping address and telephone number inside of package. No return will be shipped back to a PO Box or APO address.

- Please include your check or money order in the amount of:
- US\$5.00 for items \$10.00 to \$39.99 (Price Paid Per Unit)
  - US\$10.00 for items \$40.00 to \$99.99. (Price Paid Per Unit)
  - US\$16.00, for items \$100.00 and up. (Price Paid Per Unit)
  - Shipping fees are non-refundable

to be payable to Innovative Technology Electronics Corp. (for handling and return shipping charges) (IT) will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any / all of the necessary information. Send all inquiries or RMA request via our website [www.ithomeproducts.com/support](http://www.ithomeproducts.com/support).

Innovative Technology Electronics Corp.  
1 Channel Drive  
Port Washington, NY 11050  
Toll free: 1-877-483-2497  
**Website for support: [www.ithomeproducts.com/support](http://www.ithomeproducts.com/support)**

There are no express warranties except as listed above. REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER. (IT) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.