

“Selfie” Stick - Expandable Mobile Phone Holder


PACKAGE CONTENTS


- Selfie stick
- Adjustable mobile phone holder
- Camera mount
- Bluetooth® remote control
- Quick Setup Guide

FEATURES

- Light-weight aluminum construction
- Bluetooth® shutter remote control
- Adjustable locking head for multi-angle shots

PAIRING YOUR BLUETOOTH DEVICE

- 1 Press and hold  (shutter) on the remote control to enter pairing mode. The light blinks blue and red.
- 2 Make sure that your phone is within 33 feet (10 meters) of the remote control.
- 3 Turn on your Bluetooth device (such as a phone), turn on Bluetooth, then put it in pairing mode. For more information, see the documentation that came with your phone.
- 4 On your Bluetooth device, select **NS-SSTK2B**. The remote control pairs with your Bluetooth device and the light turns off.



ATTACHING YOUR DEVICE

Phone holder

- 1 If the camera mount is attached, remove the locking screw and detach the adapter.
- 2 Line up the phone holder and selfie stick screw holes, then insert and tighten the locking screw.
- 3 Pull up the mobile phone holder, then insert your phone in a landscape position.
Note: The mobile phone holder adjusts to fit phones that are 1.5 – 3" in width.


GoPro adapter

- 1 If the phone holder is attached, remove the locking screw and detach the phone holder.
- 2 Line up your GoPro and selfie stick screw holes, then insert and tighten the locking screw.

Camera mount

- 1 If the phone holder is attached, remove the locking screw and detach the phone holder.
- 2 Line up the camera mount and selfie stick screw holes, then insert and tighten the locking screw.
- 3 Screw your camera onto the camera mount.

USING YOUR SELFIE STICK

- 1 Put your device in picture or video mode. For example, open your camera app if you're using a phone.
Tip: Use your phone's front-facing camera to aim.
- 2 Pull the adapter head to extend the selfie stick to the length that you want, then adjust the angle by tilting the tilting the phone holder, GoPro, or camera mount.
- 3 Aim your camera, then press  (shutter) on the remote control.
Tip: Attach the remote control to the handle of your selfie stick for easy access.

REPLACING THE REMOTE CONTROL BATTERIES

- 1 Remove the rubber back from the remote control.
- 2 Slide off the battery cover.
- 3 Insert a **CR2032L** battery. The positive side should face up.
- 4 Replace the battery cover and rubber back.

STORING YOUR SELFIE STICK

- Make sure the mobile phone holder is attached at the top. Fold the mobile phone holder down, then screw the camera mount to the bottom of the selfie stick. Use the Velcro strap to attach the remote control to the selfie stick's handle.

TROUBLESHOOTING

Remote control will not pair with my phone

- Move your phone and remote control closer together.
- Make sure that your phone and remote control are not paired to another Bluetooth device.
- Make sure that you selected **NS-SSTK2B** on your phone.
- Turn your phone off, then on. Re-pair your remote control and phone.
- The remote control battery may be depleted. Replace the battery.

"NS-SSTK2B" does not appear on my phone

- Move your phone and remote control closer together.
- Put your remote control in pairing mode, then refresh your list of Bluetooth devices. For more information, see the documentation that came with your phone.

IMPORTANT SAFETY INSTRUCTIONS

- Make sure that your smartphone is completely secured to your selfie stick.
- Always be fully aware of your surroundings when using your selfie stick. Never put yourself or others in a dangerous situation.

SPECIFICATIONS

Length (collapsed): 11.1 in. (28.3 cm)

Length (fully extended): 39.0 in. (99.0 cm)

Weight (with remote): 6.35 oz. (180 g)

LEGAL STATEMENTS

FCC statement:

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

FCC Caution:

"Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment."

RSS-Gen & RSS-210 statement:

"This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

RSS-102 Statement:

"This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment. "

"Cet équipement est conforme à l'exposition aux rayonnements Industry Canada limites établies pour un environnement non contrôlé. "

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico) www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries. Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A. ©2015 Best Buy. All rights reserved. Made in China