

Wireless Guitar Setup Instructions:



Install 4 AA batteries into wireless quitar.



Turn on your wireless guitar, and wait until the guitar and the eceiver are synchronized. The ight on the guitar (behind the strum bar) & the receiver will



Plug wireless receiver into game console.



low your wireless guitar is ready ao. ROCK ON

(To setup a second wireless guitar, repeat step 2 & 3 after the first wireless guitar is setup).

Wired Guitar Setup Instructions:




Plug wired guitar into game console.



Now your wired guitar is ready togo, ROCK ON!

Guitar Controls:



	Pause
b: SELECT button:	Activate STAR POWER
c: GREEN button:	Activate the GREEN note/Confirm
	Activate the YELLOW note
f: BLUE button:	Activate the BLUE note
	Activate the ORANGE note
h: STRUMBAR:	Move the STRUM BAR up and down to activate the
	color buttons and to navigate the menu
	Press WHAMMY BAR down to alter the sound of the song
j: TILT SENSOR:	Activate the STAR POWER. To activate, tilt
	the guitar up or down



Notice:

- This product is made for indoor use only.
- Keep the product at room temperature.
- · Product contains electrical components; · Small parts may be a choking hazard for keep it away from moisture
- Modifying or disassembling the controller in any way will void the warranty
- The controller must be used with care to avoid injury.
- TAC will not be liable for injury resulting from the improper use of the controller
 - children under 3



This product comes with three (3) month limited warranty from the date of purchase against manufacturing defect.

For more information or to activate the warranty register the product at: http://www.theantcommandos.com/warranty For technical support, email us at: support@theantcommandos.com For Frequently Asked Questions visit us at: http://www.theantcommandos.com/FAQDisplayaspx

IMPORTANT INFORMATION REQUIRED BY THE FCC

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.