
Portable Digital Audio Player

EVOLUTION IHP3-064

User's Manual

What is 'MP3' ?

MP3 is a abbreviated form of 'MPEG1 Layer 3' which is the standards of digital data compression technology used for coding audio -visual information. And MP3 file is an audio file made by using the audio data compression technology.

What is 'MP3' player?

MP3 player is a digital audio player which can decode MP3 files stored in flash memory. With MP3 player, you can enjoy your favorite music which you downloaded from internet and also can record/play back lectures or important business meetings.

FCC Statements

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

FCC ID : PNWIHP3-064

MADE IN KOREA

FCC Caution : Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment

* Only supplied interface cable should be used, or may cause undesired operation.


How to connect to PC?

Your PC will recognize the connection of Evolution automatically.
Then follow as below pictures instruct.


1. Select 'Next'




2. Select 'Next'



3. Select 'Next'




4. Select the Disk




-> Choose the 'Drive folder' in the CD

5. Select 'Next'



6. Finish



How to use Managing Program?

Find the folder which you have extracted the zip file. Then double click the “evolution.exe” file.

Then the window of the Managing Program will be displayed as shown below.



How to use Managing Program?

1. Memory Format

To download MP3 files in your memory, the memory should be formatted first.

To format, click  icon

2. Download/Upload

1) Download

To download MP3 files from PC to your player, click  icon.

* If [Open] window is displayed, choose the songs you to desire to download and click [Open] to start download.

2) Upload

To upload MP3 files from the player to your PC, click  icon.

3. Refresh

To refresh memory, press  icon.

4. Delete

To delete files, choose the files you desire to delete.

And click  icon.