

The Intermec logo is displayed in a bold, blue, sans-serif font. It is positioned to the left of a blue square icon containing a white circular graphic with a stylized 'C' shape. The entire logo and icon are set against a background of overlapping, light blue circles and lines that resemble an orbital or network diagram.

**Intermec**



**User's Manual**



**CN3 Mobile  
Computer**





**Intermec**



User's Manual

**CN3 Mobile  
Computer**

Intermec Technologies Corporation

Worldwide Headquarters  
6001 36th Ave.W.  
Everett, WA 98203  
U.S.A.

[www.intermec.com](http://www.intermec.com)

The information contained herein is provided solely for the purpose of allowing customers to operate and service Intermec-manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec Technologies Corporation.

Information and specifications contained in this document are subject to change without prior notice and do not represent a commitment on the part of Intermec Technologies Corporation.

© 2006-2007 by Intermec Technologies Corporation. All rights reserved.

The word Intermec, the Intermec logo, Norand, ArciTech, Beverage Routebook, CrossBar, dcBrowser, Duratherm, EasyADC, EasyCoder, EasySet, Fingerprint, i-gistics, INCA (under license), Intellitag, Intellitag Gen2, JANUS, LabelShop, MobileLAN, Picolink, Ready-to-Work, RoutePower, Sabre, ScanPlus, ShopScan, Smart Mobile Computing, TE 2000, Trakker Antares, and Vista Powered are either trademarks or registered trademarks of Intermec Technologies Corporation.

There are U.S. and foreign patents as well as U.S. and foreign patent applications pending.

Wi-Fi is a registered certification mark of the Wi-Fi Alliance.

Microsoft, Windows, and the Windows logo are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Bluetooth is a trademark of Bluetooth SIG, Inc., U.S.A.

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit ([www.openssl.org](http://www.openssl.org)).

This product includes cryptographic software written by Eric Young ([EAY@cryptsoft.com](mailto:EAY@cryptsoft.com)).

Bluetooth is a trademark of Bluetooth SIG, Inc., U.S.A.

miniSD is a trademark of the SD Card Association. The SD logo is a trademark.

SiRF and the SiRF logo are registered trademarks of SiRF Technology, Inc. SiRFstarIII is a trademark of SiRF Technology, Inc.

## Document Change Record

This page records changes to this document. The document was originally released as Version -001.

Version Number	Date	Description of Change
002	01/2007	Added information about the InstallSelect application, the clean boot method, the color camera, and CDMA radios.
003	04/2007	<ul style="list-style-type: none"><li>• Added information about GPS on the CN3.</li><li>• Added information about using the FTP server.</li><li>• Created an appendix for specifications and accessories information.</li></ul>



# Contents

Before You Begin . . . . .	xi
Safety Information . . . . .	xi
Global Services and Support . . . . .	xi
Who Should Read This Manual . . . . .	xii
Related Documents . . . . .	xii
Patent Information . . . . .	xiii
<b>1 Using the Computer . . . . .</b>	<b>1</b>
Introducing the CN3 Mobile Computer . . . . .	2
Front View . . . . .	2
Rear View . . . . .	3
Features . . . . .	4
Learning Software Build Versions . . . . .	4
Resetting Your Computer . . . . .	5
Preferred Reset Method . . . . .	5
Secondary Reset Method . . . . .	5
Clean Boot Process . . . . .	5
Scanning Bar Codes . . . . .	6
Scanning with the Area Imager . . . . .	6
Improving the Performance of the Area Imager . . . . .	7
Reading Distances . . . . .	8
Using the Batteries . . . . .	9
Charging the Battery . . . . .	9
Maximizing Battery Life . . . . .	10
Removing and Installing the Battery . . . . .	10
Checking the Battery Status . . . . .	11
Understanding the Low Battery Warnings . . . . .	12
Adjusting the Beeper . . . . .	12
Using the Color Camera . . . . .	14
Using the Intermec Settings Applet . . . . .	15
Using the Keypad . . . . .	16
QWERTY Keypad . . . . .	16
Numeric Keypad . . . . .	16
Using the Color-Coded Keys . . . . .	17
Capitalizing Characters . . . . .	17
Entering Characters on the QWERTY Keypad . . . . .	17
Entering Characters on the Numeric Keypad . . . . .	18
Using the Power Switch . . . . .	19
Coming Out of the Idle Mode . . . . .	19

Resuming Activity after an Unattended Mode . . . . . 19

Using the Screen . . . . . 20

Software Tools . . . . . 21

    SmartSystems Foundation Console ([www.intermec.com/SmartSystems](http://www.intermec.com/SmartSystems)) . . . . . 21

    SmartSystems Platform Bundles (SSPB) . . . . . 21

    Intermec Resource Kits ([www.intermec.com/IDL](http://www.intermec.com/IDL)) . . . . . 21

Using the Speakers . . . . . 21

    Front Speaker . . . . . 22

    Rear Speaker . . . . . 22

    Adjusting the Volume . . . . . 22

Using the Status LEDs . . . . . 23

Using the Storage Card . . . . . 24

Setting Vibrate Mode . . . . . 25

Setting Up GPS on Your CN3 . . . . . 27

    Using the GPSID Installed on the CN3 . . . . . 27

    Learning About Additional GPS Options for the CN3 . . . . . 28

**2 Windows Mobile** . . . . . 29

Software Builds . . . . . 30

Where to Find Information . . . . . 30

Basic Usage . . . . . 30

    Today Screen . . . . . 30

    Programs . . . . . 31

    Navigation Bar and Command Bar . . . . . 32

    Pop-up Menus . . . . . 32

    Notifications . . . . . 32

    Entering Information . . . . . 33

        Typing With the Onscreen Keyboard . . . . . 34

        Using Block Recognizer . . . . . 35

        Using Letter Recognizer . . . . . 35

        Using Transcriber . . . . . 35

        Selecting Typed Text . . . . . 36

    Writing on the Screen . . . . . 36

        Selecting the Writing . . . . . 36

        Converting Writing to Text . . . . . 37

    Drawing on the Screen . . . . . 38

        Creating a Drawing . . . . . 38

        Selecting a Drawing . . . . . 38

    Recording a Message . . . . . 39

    Using My Text . . . . . 40

    Finding and Organizing Information . . . . . 40

    Customizing Your Computer . . . . . 41

        Adjusting Settings . . . . . 41



Adding or Removing Programs . . . . .	41
Microsoft ActiveSync . . . . .	44
Microsoft Outlook Mobile . . . . .	45
Calendar: Scheduling Appointments and Meetings. . . . .	46
Synchronizing Calendar. . . . .	46
Why Use Categories in the Calendar? . . . . .	46
What Is an All Day Event?. . . . .	47
What Is a Recurrence Pattern?. . . . .	48
Viewing Appointments . . . . .	48
Creating or Changing an Appointment . . . . .	48
Creating an All-Day Event . . . . .	49
Setting a Reminder for an Appointment . . . . .	50
Adding a Note to an Appointment . . . . .	50
Making an Appointment Recurring. . . . .	51
Assigning an Appointment to a Category. . . . .	51
Sending a Meeting Request . . . . .	52
Finding an Appointment. . . . .	53
Deleting an Appointment . . . . .	53
Changing Calendar Options . . . . .	54
Contacts: Tracking Friends and Colleagues . . . . .	54
Creating a Contact . . . . .	55
Synchronizing Contacts. . . . .	55
Viewing Contacts . . . . .	56
Changing a Contact . . . . .	57
Adding a Note to a Contact. . . . .	57
Assigning a Contact to a Category. . . . .	57
Copying a Contact . . . . .	58
Sending a Message to a Contact. . . . .	58
Finding a Contact . . . . .	58
Deleting a Contact . . . . .	59
Changing Contacts Options . . . . .	59
Tasks: Keeping a To Do List . . . . .	59
Creating a Task . . . . .	60
Synchronizing Tasks . . . . .	60
Notes: Capturing Thoughts and Ideas . . . . .	61
Creating a Note. . . . .	61
Synchronizing Notes . . . . .	62
Messaging: Sending and Receiving E-mail Messages . . . . .	62
Synchronizing E-mail Messages . . . . .	63
Managing E-mail Messages and Folders. . . . .	63
Connecting to a Mail Server . . . . .	64
Composing and Sending Messages . . . . .	65
Companion Programs . . . . .	66
Word Mobile . . . . .	66
Creating a Document . . . . .	66
Typing Mode . . . . .	67
Writing Mode . . . . .	68
Synchronizing Word Mobile Documents . . . . .	68
Excel Mobile. . . . .	69
Creating a Workbook . . . . .	69

Tips for Working in Excel Mobile . . . . .	69
PowerPoint Mobile . . . . .	70
Windows Media Player for Windows Mobile . . . . .	71
Internet Explorer Mobile . . . . .	72
Favorite Links . . . . .	72
Mobile Favorites . . . . .	72
Using Internet Explorer Mobile . . . . .	74
Viewing Mobile Favorites and Channels . . . . .	74
Browsing the Internet . . . . .	74

### **3 Configuring the Computer . . . . . 75**

Developing Applications for the Computer . . . . .	76
Packaging Applications for the Computer . . . . .	76
Installing Applications on the Computer . . . . .	77
Using Microsoft ActiveSync . . . . .	77
Using the FTP Server . . . . .	78
Using a Storage Card . . . . .	78
Using the SmartSystems Console . . . . .	79
Using Wavelink Avalanche . . . . .	79
Using InstallSelect . . . . .	80
Using the InstallSelect Application . . . . .	80
Understanding Software Feature Descriptions . . . . .	81
Launching Your Application Automatically . . . . .	83
RunAutoRun . . . . .	83
AutoExec . . . . .	84
AutoRun . . . . .	85
AutoCopy . . . . .	86
AutoReg . . . . .	86
AutoCab . . . . .	87
Customizing How Applications Load on the Computer . . . . .	88
Configuring Parameters . . . . .	89
Configuring the Computer With Intermec Settings . . . . .	89
Synchronizing the Computer System Time with a Time Server . . . . .	89
Configuring the Computer through the Network . . . . .	90
Configuring the Computer in a TCP/IP Direct Connect Network . . . . .	90
Configuring the Computer in a UDP Plus Network . . . . .	91
Reprogramming the CN3 Keypad . . . . .	92
Configuring the Color Camera . . . . .	92
Configuring the SF51 Cordless Scanner . . . . .	94
Setting the Imager . . . . .	94
Enabling Bluetooth . . . . .	95
Creating an SF51 Connection Label . . . . .	95
Viewing SF51 Scanner Information from Your Computer . . . . .	96

Using Configuration Parameters . . . . . 97

**4 Maintaining the Computer . . . . . 99**

Upgrading the Operating System on your Computer . . . . . 100  
     Using a Storage Card to Upgrade the Computer . . . . . 101  
         Upgrading Both Operating System and SSPB Files . . . . . 101  
         Upgrading the SSPB Files . . . . . 102  
     Using the SmartSystems Console to Upgrade the Computer . . . . . 102

Troubleshooting Your Computer . . . . . 103

Cleaning the Scanner and Camera Windows and Screen . . . . . 106

**5 Network Support . . . . . 109**

Wireless Network Support. . . . . 110

Personal Area Networks. . . . . 110  
     Configuring with the Wireless Manager . . . . . 110  
     Enabling Bluetooth After a Clean Boot. . . . . 111  
     Using the Wireless Printing Applet. . . . . 116  
     Connecting to Bluetooth Audio Devices. . . . . 119  
         Searching for Bluetooth Headsets . . . . . 119  
         Audio Device Icons . . . . . 120  
         Connecting to a Bluetooth Headset. . . . . 121  
     Configuring Bluetooth Using Intermec Settings. . . . . 122  
     Connecting with Bluetooth . . . . . 122

Local Area Networks (LANs). . . . . 126

Using the CDMA Radio Phone Application . . . . . 127  
     Using the Wireless Manager to Turn on the Phone . . . . . 127  
     Activating the Phone . . . . . 128  
     Using the CDMA Phone . . . . . 130

Using the GSM/EDGE Radio Phone Application . . . . . 135  
     Using the Wireless Manager to Turn on the Phone . . . . . 135  
     Activating the Phone . . . . . 136  
     Using the GSM/EDGE Phone . . . . . 136

Remote Access (Modems) . . . . . 139  
     Connecting to an Internet Service Provider . . . . . 140  
     Connecting to Work. . . . . 143  
     Creating a VPN Server Connection to Work . . . . . 145  
     Ending a Connection . . . . . 147

iConnect . . . . . 147  
     FTP Server . . . . . 147  
     Network Interfaces . . . . . 148  
         No Networking. . . . . 148  
         Wireless Communications. . . . . 148

## Contents

Ping Test .....	149
ISpyWiFi .....	150
Starting the Utility .....	150
Pinging .....	154
Logging Supplicants .....	155
Configuring Security .....	156
Choosing Between Microsoft and Funk Security .....	156
Configuring Funk Security .....	156
Configuring Microsoft Security .....	175
Configuring Preferred Networks .....	177
Loading Certificates .....	182
Wireless Network .....	182
SmartSystems™ Foundation .....	185
<b>A Specifications</b> .....	187
Physical and Environmental Specifications .....	188
Accessories for the Computer .....	190
<b>I Index</b> .....	191

## Before You Begin

This section provides you with safety information, technical support information, and sources for additional product information.

### Safety Information

Your safety is extremely important. Read and follow all warnings and cautions in this document before handling and operating Intermec equipment. You can be seriously injured, and equipment and data can be damaged if you do not follow the safety warnings and cautions.

This section explains how to identify and understand dangers, warnings, cautions, and notes that are in this manual..



**A warning alerts you of an operating procedure, practice, condition, or statement that must be strictly observed to avoid death or serious injury to the persons working on the equipment.**



**A caution alerts you to an operating procedure, practice, condition, or statement that must be strictly observed to prevent equipment damage or destruction, or corruption or loss of data.**



**Note:** Notes either provide extra information about a topic or contain special instructions for handling a particular condition or set of circumstances.

### Global Services and Support

#### Warranty Information

To understand the warranty for your Intermec product, visit the Intermec web site at [www.intermec.com](http://www.intermec.com) and click Service & Support. The Intermec Global Sales & Service page appears. From the Service & Support menu, move your pointer over Support, and then click Warranty.

Disclaimer of warranties: The sample code included in this document is presented for reference only. The code does not necessarily represent complete, tested programs. The code is provided “as is with all faults.” All warranties are expressly disclaimed, including the implied warranties of merchantability and fitness for a particular purpose.

#### Web Support

Visit the Intermec web site at [www.intermec.com](http://www.intermec.com) to download our current manuals (in PDF). To order printed versions of the Intermec manuals, contact your local Intermec representative or distributor.

Visit the Intermec technical knowledge base (Knowledge Central) at [intermec.custhelp.com](http://intermec.custhelp.com) to review technical information or to request technical support for your Intermec product.

## Telephone Support

These services are available from Intermec Technologies Corporation.

Service	Description	In the U.S.A. and Canada, call 1-800-755-5505 and choose this option
Order Intermec products	<ul style="list-style-type: none"><li>Place an order.</li><li>Ask about an existing order.</li></ul>	1 and then choose 2
Order Intermec media	Order printer labels and ribbons.	1 and then choose 1
Order spare parts	Order spare parts	1 or 2 and then choose 4
Technical Support	Talk to technical support about your Intermec product.	2 and then choose 2
Service	<ul style="list-style-type: none"><li>Get a return authorization number for authorized service center repair.</li><li>Request an on-site repair technician.</li></ul>	2 and then choose 1
Service contracts	<ul style="list-style-type: none"><li>Ask about an existing contract.</li><li>Renew a contract.</li><li>Inquire about repair billing or other service invoicing questions.</li></ul>	1 or 2 and then choose 3

Outside the U.S.A. and Canada, contact your local Intermec representative. Click Contact from the Intermec web site to search for your representative.

## Who Should Read This Manual

This manual is written for the person who is responsible for installing, configuring, and maintaining the CN3 Mobile Computer.

This document provides you with information about the features of the CN3, and how to install, configure, operate, maintain, and troubleshoot it.

Before you work with the CN3, you should be familiar with your network and general networking terms, such as IP address.

## Related Documents

This table contains a list of related Intermec documents and part numbers.

Document Title	Part Number
<i>CN3 Mobile Computer Quick Start Guide</i>	962-054-115
<i>Intermec Computer Command Reference Manual</i>	073529
<i>TE 2000 Terminal Emulation Programmer's Guide</i>	977-055-008

The Intermec web site at [www.intermec.com](http://www.intermec.com) contains our documents (as PDF files) that you can download for free.

**To download documents**

- 1** Visit the Intermec web site at [www.intermec.com](http://www.intermec.com).
- 2** Click **Service & Support > Manuals**.
- 3** In the **Select a Product** field, choose the product whose documentation you want to download.

To order printed versions of the Intermec manuals, contact your local Intermec representative or distributor.

**Patent Information**

4882476; 4894523; 4953113; 4961043; 4970379; 4988852; 5019699;  
5021642; 5038024; 5081343; 5095197; 5144119; 5144121; 5182441;  
5187355; 5187356; 5195183; 5216233; 5216550; 5195183; 5195183;  
5218191; 5227614; 5233172; 5241488; 5243602; 5258606; 5278487;  
5288985; 5308966; 5322991; 5331136; 5331580; 5342210; 5349678;  
5359185; 5371858; 5373478; 5389770; 5397885; 5410141; 5414251;  
5416463; 5442167; 5464972; 5468947; 5468950; 5477044; 5486689;  
5488575; 5500516; 5502297; 5504367; 5508599; 5514858; 5530619;  
5534684; 5536924; 5539191; 5541419; 5548108; 5550362; 5550364;  
5565669; 5567925; 5568645; 5572007; 5576529; 5592512; 5594230;  
5598007; 5608578; 5616909; 5619027; 5627360; 5640001; 5657317;  
5659431; 5671436; 5672860; 5684290; 5719678; 5729003; 5742041;  
5761219; 5764798; 5777308; 5777309; 5777310; 5786583; 5793604;  
5798509; 5798513; 5804805; 5805807; 5811776; 5811777; 5818027;  
5821523; 5828052; 5831819; 5834753; 5834749; 5837987; 5841121;  
5842070; 5844222; 5854478; 5862267; 5869840; 5873070; 5877486;  
5878395; 5883492; 5883493; 5886338; 5889386; 5892971; 5895906;  
5898162; 5902987; 5902988; 5912452; 5923022; 5936224; 5949056;  
5969321; 5969326; 5969328; 5979768; 5986435; 5987192; 5987499;  
5992750; 6003775; 6012640; 6016960; 6018597; 6024289; 6034379;  
6036093; 6039252; 6064763; 6075340; 6095422; 6097839; 6102289;  
6102295; 6109528; 6119941; 6128414; 6138915; 6149061; 6149063;  
6152370; 6155490; 6158661; 6164542; 6164545; 6173893; 6195053;  
6234393; 6234395; 6244512; 6249008; 6328214; 6330975; 6345765;  
6356949; 6367699; 6375075; 6375076; 6375344; 6431451; 6435411;  
6484944; 6488209; 6497368; 6532152; 6538413; 6539422; 6621942;  
6641046; 6681994; 6687403; 6688523; 6732930

Docking Station/Device

5052943; 5195183; 5317691; 5331580; 5544010; 5644471

There may be other U.S. and foreign patents pending.

***Before You Begin***