














# CN70e



## To synchronize the CN70e with your Windows PC, visit:

若要將 CN70e 與 Windows PC 同步，請訪問：

若要將 CN70e 與 Windows PC 同步，請訪問：

Pour synchroniser le CN70e avec votre PC Windows, allez voir:

Für Informationen zum Synchronisieren des Modells CN70e mit Ihrem Windows-PC besuchen Sie bitte:

אתר האינטרנט של CN70e עם Windows PC, ראתו את:

Untuk menyinkronkan CN70e dengan PC Windows, kunjungi:

CN70e をお使いの Windows PC と同期させるには、以下でご参照ください：

CN70e 를 귀하의 Windows PC 와 연동시키려면, 다음을 방문하세요:

Para sincronizar o CN70e com seu PC com sistema operacional Windows, visite:

Чтобы синхронизировать CN70e с ПК, работающим в системе Windows, посетите:

Para sincronizar el CN70e con su computadora Windows, visite:

โปรดดูวิธีการเชื่อมข้อมูลอุปกรณ์ CN70e ของคุณเข้ากับ Window PC ของคุณได้ที่:

[www.windowmobile.com/getstarted](http://www.windowmobile.com/getstarted)