

Bluetooth BlueSynergy



User's Guide



INDEX

INDEX	4. Advanced functions	10
1. INTRODUCTION	4.1 Quick dial buttons	
1. INTRODUCTION	4.2 Advanced call features	10
1.1 Basic features2	4.3 Managing mobile phones	11
1.2 Description3	4.4 Dialing settings	12
2. STARTING	4.5 Other settings	12
2. STARTING 4	5. CONFIGURATION VIA PC WITH JABLOTOOL	
2.1 Package contents4	31 CONTINUE VIA 1 C WITH JABLOTO CLIMIN	
2.2 Assembly and power up4	6. TROUBLESHOOTING	1.4
2.3 Pairing the BlueSynergy with your mobile phone5	O. IROUBLESHOOTING	14
2.4 First use6	7. TECHNICAL DATA	15
3. BASIC FUNCTIONS8		
3. DASIC I ONCTIONS	7.1 Bluetooth support	15
3.1 Dialing and answering calls8	7.2 Technical specifications	16
3.2 Contacts8	7.3 Warranty	16
3.3 Messaging10	7.4 Safety Instructions	17
3.4 Call history10	7.5 Disposal Information	

1. INTRODUCTION

1.1 BASIC FEATURES

Thank you for purchasing BlueSynergy.


The device offers a comfortable and very efficient way to operate both your mobile phone and landline at the office or at home.

With BlueSynergy you can:


- make and answer phone calls
- send and receive text messages
- synchronize contacts and calls with your mobile phone
- use free JabloTool software to operate all functions from your PC



1.2 DESCRIPTION




1	New text message indicator	13	ALT key to write special characters	
2	Cellular network signal indicator	14	Shift key (upper case / lower case)	
3	Name of currently paired mobile phone	15	Cancel (ESC) key	
4	Data synchronization in progress	16	Confirm (OK) key	
5	Time and date	17	Navigation keys	
6	Mobile phone battery indicator	18	Text messages	
7	Missed call indicator	19	Call history	
8	Name of current cellular network	20	Contacts	
9	Active lines	21	Speakerphone	
10	Context keys	22	Backspace	
11	Speed dial buttons	23	Redial function	
12	Start writing a text message	24	SPACE key	



2. STARTING

2.1 PACKAGE CONTENTS

Unpack the phone and check the package contents.



2.2 ASSEMBLY AND POWER UP

 Connect the cord between the receiver and the console. Connect the phone cable to the connector at the rear of the phone and to your landline socket.



 First connect the power adaptor to the connector at the rear of the phone and then plug the adaptor into the wall socket.




Choose the desired language and confirm by pushing the Select button.



2.3 PAIRING THE BLUESYNERGY WITH YOUR MOBILE PHONE

The BlueSynergy needs to be connected to your mobile phone by a procedure called pairing. This guide will instruct you in this pairing procedure:

- Once the BlueSynergy is powered up for first time (or choosing Menu > Settings > Mobile phones > Add...)
 it automatically enters the pairing mode.
- Make your mobile phone visible for BlueSynergy please check your mobile phone user guide for detailed instructions. Ensure that the Bluetooth function is activated on your mobile phone and visible to other devices. This usually involves going to a Setup, Connect or Bluetooth menu on your mobile phone and selecting the option to Discover or Add a Bluetooth device.
- Then select the Next on the BlueSynergy and it will find your mobile phone. Please note that you may also see some other Bluetooth devices that are within working range of the BlueSynergy. Select the mobile phone that you want the BlueSynergy to pair with and choose Pair.
- Accept pairing your mobile phone by selecting YES or OK on your mobile phone, if the mobile phone asks for a passkey or PIN, enter "0000" (4 zeros). Your mobile phone should confirm that the pairing procedure has finished
- Confirm with YES if your mobile phone asks to allow the BlueSynergy profiles functions (such as hands-free, DUN, IrMC, SyncML, PBA, etc.).
- The BlueSynergy will warn you about functions that your mobile phone doesn't support via Bluetooth.





Please note that the working range for BlueSynergy is up to 10 meters. If there are obstructions between the BlueSynergy and your mobile phone (such as walls, metal objects, etc.) the working range may narrow considerably.



Once you have finished the pairing, you can use the BlueSynergy to make calls instead of your mobile phone. If your mobile phone supports contact and call history synchronization, this will start automatically (as indicated by the symbol •).



Functions not supported by your mobile phone are shown in a small dashed font.



Supp. functions:

V headset function

V contact sync.

V call history sync.

X sendtreceive SMS


MAC: 00-1E-E2-BF-F5-76

Back




2.4 FIRST USE


Making a call



▶ Making a call using your contact list



Sending a text message



3. BASIC FUNCTIONS

3.1 DIALING AND ANSWERING CALLS

BlueSynergy supports basic call functions of your mobile phone. You can dial numbers, answer or reject incoming call. redial last number.

BlueSynergy can be operated similarly to any landline phone. Just pick up the receiver (or press activate speakerphone) and type a number or select a contact from the contact list.

Press any time during a call to switch between receiver and speakerphone mode.

To end active call, put down the receiver or press button.

Before dialing a number, BlueSynergy asks you to choose the line for dialing. If you defined some dialing rules (please see chapter **4.4 Dialing settings** for more info), BlueSynergy will first try to choose a line automatically.

3.2 CONTACTS

There are two types of contacts in the BlueSynergy:

Synchronized contacts

These contacts are copied from your paired mobile phone. If the mobile phone supports contact synchronization, you'll see all of its contacts in the BlueSynergy contact list. They're marked with a mobile phone icon. You cannot **add**, **edit** or **delete** them using the BlueSynergy: This is only possible using the mobile phone.



► Internal contacts

If your mobile phone doesn't support contact synchronization, you won't be able to see any of its contacts in the BlueSynergy. But there's an internal contact list available for you in the BlueSynergy.



You can **add**, **edit** or **delete** its contacts using the BlueSynergy or JabloTool (synchronization with MS Outlook is available), but you will not see them in your mobile phone. Internal contacts are marked with a dual phone icon. This internal list is by default disabled for mobile phones supporting contact synchronization (it can be enabled in

Menu > Settings > Service > Internal contacts).

If there's no mobile phone connected to the BlueSynergy, only internal contacts are available.

The BlueSynergy can store up to 500 contacts for each paired mobile phone and additional 500 in the internal list.

Each contact includes the following items:

- First and last name
- Up to 3 phone numbers (mobile, office and home number)
- Ring tone for this contact

Search contacts:

Use the QWERTY keyboard and simply start to type the last name of the contact you want to find. The BlueSynergy will navigate through the contact list as you type.

▶ Browse contact list:

Press the or select Menu > Contacts to browse the contact list. Use the UP and DOWN arrow to move within the list. Use the QWERTY keypad to search the list. Press the LEFT context key to open the Options menu for the selected contact.

Call a contact:

Press or use the **Call** command from the **Options** menu to call the selected contact. Depending on the settings, the telephone may ask you whether to make the call via GSM or via landline.



Contacts

Contacts:

Call

Edit

🖀 Landy, Pamela

🕱 Palmer, David

🛪 Savant. Doug

Palmer, David

Netions

Write a text message:

Use the **Send SMS** command from the **Options** menu to write a text message for the selected contact.

View contact details:

Press the RIGHT arrow or use the **Details** context option to see the details of the contact.

Please note that the following edit operations are available for internal contacts only.

Add new contact:

Use the **Add new...** command from the **Options** menu to add a new contact.

Edit a contact:

Use the **Edit** command from the **Options** menu to open the contact editor.

▶ Delete a contact:

Press or use the **Delete** command from the **Options** menu to delete a selected contact.

Use the **Delete all** command to delete all contacts.

Synchronization

The BlueSynergy automatically synchronizes the contacts in your mobile phone when your mobile phone comes within working range of the *Bluetooth* radio. The BlueSynergy starts to update the contacts (contacts are copied from your mobile phone to the internal memory of the BlueSynergy). This can take some time, depending of the type of synchronization your mobile phone supports. The synchronization process is indicated by an icon on the ICD.



Please note that the BlueSynergy only READS data from your mobile phone's memory. To prevent any possible unwanted changes in your mobile phone, the BlueSynergy never writes anything into your mobile phone's memory.

To avoid excessive discharging of your mobile phone battery, automatic synchronization will not be run more than once per hour.

If you wish to apply the most recent changes in your mobile phone contacts to the BlueSynergy, go to the contact list and select **<Synchronize now>** to activate synchronization manually.



3.3 MESSAGING

Writing a text message

Press key to start writing a new text message. Hold A / a key for 2 seconds to switch between modes Abc, abc and ABC for writing upper-case letters.

Use key to write national characters. Press it repeatedly to cycle last written character through its national variants.

Hold GYMBOL for 2 seconds to show extended symbol table. Select a symbol and press Insert to place it into your message.

Reading received message

Receipt of a new text message is indicated by an acoustic signal, flashing of the red indicator light and by the envelope icon on the LCD. Press key to read received message. Use UP and DOWN ARROW to scroll through the message.

FromMarley, Peter 54% Hi Audrey, I am sorry, but I will be late today. Do not Back Options

3.4 CALL HISTORY

BlueSynergy stores call history. There can be up to 100 calls stored in the memory. If the memory is full, the oldest record of the same type is automatically erased.

Use **Menu** > **Calls** or press to browse call history.

BlueSynergy synchronizes call history with the mobile phone, if the mobile phone supports it.

Use menu **Filter** to view only **Missed** (T), **Incoming** () or **Outgoing** () calls.

Landline calls are only visible with currently active mobile phone. If you use BlueSynergy with another mobile phone, you will not see landline calls made when the previous mobile phone was active.

4. ADVANCED FUNCTIONS

4.1 QUICK DIAL BUTTONS

There are six buttons on your BlueSynergy that can be used for frequently called numbers or emergency numbers.

Entering a new number

Hold down the selected quick dial button until the **Phone number** dialogue appears. Enter phone number and press **OK**.



Connecting a quick dial button with a contact from your phonebook

Find the contact name in your phonebook and press and hold the selected **quick dial button** for about **2 seconds** until you see the confirmation on the display.

Additional 6 memories are available when you use dial button with the A/a kev.



Please consider that numbers added to quick dial buttons are accessible for all users of BlueSynergy device.

4.2 ADVANCED CALL FEATURES



Some of the advanced call functions will not work properly unless they are supported by your provider and paired mobile phone.



Please note that call waiting, conference and call transfer are not available for landline calls.

Call waiting

The call waiting function indicates an incoming call even when another call is in progress.



Please check first that the call waiting function is activated on your mobile phone — see your mobile phone manual for detailed instructions.




If a new incoming call is indicated, press to answer the waiting call. You can also select **Options** and the **Switch** function by using the **selection key.** The first call is put on hold. To switch between the calls, press again. Either call can be canceled by

► Conference call

The conference call function is a network service that allows up to six people to take part in a conference call.

To arrange a conference call:

- Establish a call to the first participant.
- To add a new participant into the conference call, enter the phone number directly, press or select the contact from the contact list and press the Select key.
- You may put the first call on hold if you want by pressing the Options selection key and then the Hold selection key. Select the number of another participant in the call and press
- When the new call has been answered, press Options and Join calls.







The message Conference appears on the display.



To add another participant to the conference call, repeat the previous steps. The maximum number of remote parties is 5.

▶ Call transfer

The call transfer function allows you to forward an active call to another phone number.

During the call, press the **Options** selection key, and select **Hold**. Enter the phone number you want to transfer the call to (or select the name from the contacts) and press . As soon as the call is answered, press the **Options** selection key and then select **Transfer**. You can hang up once the connection is established.

Incoming calls from both lines


When there are incoming calls from both lines at one moment, phone shows both of them on one screen. Use up/down arrows to choose a call to answer. The other call is dropped!

4.3 MANAGING MOBILE PHONES

Select **Menu > Settings > Mobile phones** to browse phones stored in BlueSynergy.

Use **Add...>** command to add new mobile phone to the list. It is possible to add up to 3 mobile phones to your BlueSynergy. Please note that only one mobile phone can be actively operated with BlueSynergy at the same time.

Use **Options** to open context menu where you can enable/disable power saving mode for each phone or delete a phone from the list.





4.4 DIALING SETTINGS




Please note that dialing settings are not available for BlueSynergy BTP-06B.

Rules for numbers

Select **Menu** > **Settings** > **Dialing** > **Rules for numbers** to browse rules. Rules define which line will be used to dial a number for particular phone number or group of phone numbers.

Each rule contains a mask and a selected line. Mask is a string which describes how a number should look like. When dialing a phone number, BlueSynergy compares it with the mask. If it matches, BlueSynergy uses line defined in the rule to dial the number.




The mask contains digits and wildcard characters? or *(eg. 7?? or 555*).

Wildcard character? represents one unspecified digit. If the mask is 12? then all of numbers 120, 121 or 125 will match with the mask. If the mask is 7?? then all numbers starting with 7 and being three digits long will match with the mask.

Wildcard character * represents group of digits with unspecified number of digits. If the mask is **12*** then all of numbers 123, 1246, 12345 or 12 will match with the mask. If a mask is only * then all numbers will match with the mask.

Warning: You can use either ? or * in the mask, not both. * is only allowed to be the most right character in the mask. Mask 1*2 is not allowed.



When there are more rules defined, BlueSynergy goes through them starting with the top one.

BlueSynergy removes country code (eg. +420) from dialed numbers before they are compared with the rules. Thus you don't need to care if you have in your phonebook numbers with or without country code.

Rules for contacts

Use **Menu > Settings > Dialing > Rules for contacts** to choose preferred line for each type of contact number (home / business / mobile). Choose Always ask, if you do not want to specify rule for particular type of contacts.

When dialing a number, BlueSynergy first checks **Rules for numbers**. If no match is found, then Rules for contacts are applied.

Country setting

Use **Menu** > **Settings** > **Dialing** > **Country setting** to configure your BlueSynergy for the landline network in your country. Press LEFT or RIGHT ARROW to browse through countries or press first letter of your country to skip directly to it.

Moreover appropriate country code is automatically selected (see Rules for numbers for details).

Outside line prefix

Use **Menu** > **Settings** > **Dialing** > **Outside line prefix** to configure the digits that have to be dialed to reach an outside line. This is commonly used to insert an ,0' or ,1' before the phone number when dialed on a private phone system, such as in a hotel or a place of business.

BlueSynergy will automatically add this prefix to all numbers longer than 6 digits. Please note that this prefix is only used for landline calls.

4.5 OTHER SETTINGS

Use **Menu > Settings > Phone** to configure settings like date & time, current language or LCD parameters. Use **LCD settings** dialogue to adjust contrast and backlight intensity of the LCD. Use UP and DOWN ARROW to select a setting and LEFT and RIGHT ARROW to change value.

Use Menu > Settings > Sound to configure ring and message alerts, volume levels during a call and key tones.

Use **Menu > Settings > Service** to access special service functions. This menu allows you to get firmware and hardware version, enter service code, reset all settings to factory defaults or change BlueSynergy's Bluetooth name (which is shown in connected mobile phone).



5. CONFIGURATION VIA PC WITH JABLOTOOL







The latest version of the installation software can be downloaded at www.jablotool.com/download.

The most convenient way to set up the BlueSynergy and configure its parameters is by using a **PC** and the **JabloTool software**.

Load the installation CD to your computer, start the "INSTALL.EXE" and follow the program instructions.



JabloTool provides the most convenient way to set and operate all of the BlueSynergy functions and settings. It also has contact synchronization and Microsoft Outlook compatibility.



6. TROUBLESHOOTING

Problem / Error message	Solution
I am having pairing problems	You may have deleted the BlueSynergy pairing in your mobile. Try to pair both devices again by following the instruction in "Pair BTP with your mobile".
I hear a crackling noise I lose the connection	BlueSynergy is connected to your mobile phone by Bluetooth radio technology. The working range of this short range radio is up to 10 meters (33 feet) and it is sensitive to objects between the BlueSynergy and your mobile phone (such as walls, etc.) which can shorten the working range.
I cannot use the BlueSynergy to listen music from mobile phone	BlueSynergy doesn't support the Bluetooth stereo headset profile (A2DP) for music streaming and cannot be efficiently used for music listening.
I cannot use Reject call, call on hold, or Conference call	These features depend on on the ability of your mobile phone to support a hands-free profile. Even if the hands-free profile is implemented, reject call, call hold and conference call are optional features that are not supported by all mobile phones. Please consult your device manual for details. Please note that some features can only be operated from the primary device when paired with multiple mobile phones.
I do not have any contact in BlueSynergy	Your mobile phone probably does not support any of the Bluetooth profiles necessary to download the contacts from you mobile phone. You can still upload the contacts into the internal BlueSynergy memory via PC.

JABLOCOM periodically releases new versions of the BlueSynergy software as well as the JabloTool software — check www.jablocom.com/products/btp. If you discover abnormal behavior, please try to update the BlueSynergy firmware to the latest version. To do this, use JabloTool, right-click on your BlueSynergy in the device list and select Update firmware.



7. TECHNICAL DATA

7.1 BLUETOOTH SUPPORT

BlueSynergy supports following Bluetooth profiles:

- HFP (hands-free)
- DUN (dial-up networking)
- IrMC and SyncML (support for contact synchronization)
- PBA (call list and contact synchronization)



Please note that some mobile phones may not support all Bluetooth profiles and therefore some of the BlueSynergy functions may not be available when paired with your mobile phone.

Please check the following table for a list of brand-specific functions supported.

Manufacturer	Supported mobile phones	Main functions				
		Voice call (HF)	Contact sync	SMS send	SMS sync	Call log sync
Apple	iPhone, iPhone 3G, iPhone 3GS, IPhone 4	~	~			~
BlackBerry	8110 Pearl, 8520 Curve, 8310, 8900 Curve, 9000 Bold, 9500 Storm, 9700 Bold	~	~			~
E-ten Glofiish	M800, M700, M600	~				
нтс	Touch Diamond 2, Touch Diamond, Touch HD, Touch pro, Touch Pro2	~	~			~
IIIC	Tatoo	~				
HP IPAQ	614c, 914c	~	~			~
LG	KP500	~	~		~	
	KE970 Shine, BL-20	٧		~		
Motorola	V3 RAZR, KRZR K1, SLVR L7	>		~	~	
Nokia	2700 classic, 5130 XpressMusic, 5310 XpressMusic, 5610 XpressMusic, 5800 XpressMusic, 6300i, 6301, 6500 slide, 6500 classic, 6600i slide, 6700 slide, 7210 Supernova, 7900 Prism, 2323 classic, 2330 classic, 5000, 3720 classic, 6303 classic, 6700 classic, 5630 XpressMusic. 6210 Navigator, 6220 classic, 6710 Navigator, 6720 classic, 6730 classic, E52, E72, N78, N79, N85, N86 8MP, N96, N97 mini, X6	>	~	~		~
	6280, 6288, 3109 classic, 3110 classic, 3500 classic, 5200, 5300 XpressMusic, 6085, 6300, 6267, 2630, 2760	~	~	~		
	E50, E61i, E65, N73, N93, N93i, 3250, 6110 Navigator, 6120 classic, 6124 classic, 6290, E51, E63, E66, E71, 5700 XpressMusic, N76, N81, N82, E90 Communicator, N95, N95 8GB	>		~		
Palm	Treo 850	~	~			~
Sony Ericsson	C510, C702, C902, C903, C905, G502, K660i, K850i, V640, V640i, W508, W595, W705, W890i, W910i, W995, T715, K530i, K550i, K610, K770i, K800i, K810i, S500i, W580i, W610i, W660i, W850i, W880i, Z610i, U10i Aino	٧	~	~	~	~
Samsung	W205	~				
	GT-S5230	٧	~	~	~	
	Omnia	~	~			V
	C3050	~	~	~		
	SGH-U900 Soul	~		~	~	
	B2100 Xplorer, SGH-D900i, SGH-E250i, SGH-J700V	/			~	



GSM phones not supported by BlueSynergy:

LG KF310

Motorola RAZR 2 V8, A1890

Sony Ericsson W302 Vodafone VF533



The most recent list of supported mobile phones can be found at www.jablocom.com/products/btp.



7.2 TECHNICAL SPECIFICATIONS

Dimensions Display Contacts

SMS memory

Call history
Ringtones
Speed dialing
Hands-free calling
Operating temperature
AC power adaptor
Supported Bluetooth profiles

Phone support Range

Language Health and Safety standard

EMC

Radio parameters Landline connection 230 x 220 x 100 mm, weight 900g

Illuminated graphical LCD 132 x 65 dots, 82 x 40 mm

500 internal - synchronize with PC, additional 500 entires - synchronize with

mobile phone supporting IrMC Sync, SyncML or PBA profiles Memory for 100 records of received and sent messages, enabled by mobile phones with DUN profile

Memory for 100 records of missed, outgoing and incoming calls

20 built-in ringtones + selected ringtone of the connected mobile phone

6 memory keys with 12 memories, label for records

Built-in speaker and microphone -10°C to +55°C; 25 to 75% humidity 100-240 V AC/50 to 60 Hz; 6V/2A DC HF, DUN, SyncML, IrMC Sync, PBA Mobile phones and PDA with *Bluetooth*

up to 10 meters typical (free space)
Multilanguage support – additional language sets are available for download

EN 60950-1

EN 301489-1, EN301 489-17 EN 300 328 –V.1.7.1 RJ11 (analog line only)

7.3 WARRANTY



JABLOCOM s.r.o., hereby declares that this BlueSynergy Bluetooth Dual Phone is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The original conformity assessment document can be found at the web site www.JABLOCOM.com.

Regulatory information:

This device is only intended for use in the country in which it was sold.

Limited warranty:

Subject to the conditions of this Limited warranty, JABLOCOM s.r.o. guarantees this product to be free from defects in design, material and workmanship at the time of its original purchase by a customer and for a subsequent minimal warranty period under the national legislation in force. Should your product need warranty service, please return it to the dealer from whom it was purchased. The defects will be eliminated free of charge by repairing or, at our discretion, replacing it.

Warranty conditions:

If you wish to make a claim under the warranty, please return the product with all accessories in the original packaging to your dealer. The warranty is valid only if the original receipt issued to the original purchaser by the dealer, specifying the date of purchase and the IMEI/MAC corresponding with the product, is presented with the product to be repaired or replaced. Plastic parts, cables or accessories of the product must not be visibly damaged, the product must not show signs of contact with liquid, the warranty seal must not be broken and the fault must be described.

This warranty doesn't cover any failure of the product due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with instructions for use and maintenance of the product. Nor does this warranty cover any failure of the product due to accident, modification, adjustment, improper repair or acts of God.

The warranty provided doesn't affect the consumer's statutory rights under applicable national legislation in force, or the consumer's rights against the dealer arising from their sales/purchase contract.

Under no circumstances shall JABLOCOM be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

As the product is under continuous development, JABLOCOM reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Operations and some features are dependent on the type of mobile phone it operates with and some functions may not be supported by some mobile phones.



7.4 SAFETY INSTRUCTIONS

Read these guidelines. Not following them may be dangerous and/or illegal.

You alone are responsible for how you use your device and any consequences of its use. Do not switch the device on wherever the use of a wireless device is prohibited or when it may cause interference or danger.

Small Children

Do not leave your device and its accessories within the reach of small children or allow them to play with them. They could hurt themselves or others, or could accidentally damage the device. Your device contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.

Some countries may regulate the security device usage by special laws. Please study the possible law restrictions for certain country before installing the device.



Your device contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. Care must be taken when using the device in close proximity to personal medical devices, such as pacemakers and hearing aids. All wireless devices are susceptible to interference, which could affect performance.

We (JABLOCOM) are not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Your device is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless their age and health.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

A Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker. For this reason, always keep the phone's console more than 15 cm away from your pacemaker.

Hearing aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby. The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical devices

Please consult your doctor and the device manufacturer to determine if operation of your device may interfere with the operation of your medical device.

Hospitals

The device isn't designed to be used in hospitals, clinics or health care facilities without a consultancy with the staff or medical equipment producers. This request is designed to prevent possible interference with sensitive medical equipment

A Wireless devices can cause interference in aircraft.

Explosive environments

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your device or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.





The device isn't recommended to be used in a blasting area or in areas posted for turning off "two-way radios" or "electronic devices" to avoid interfering with blasting operations. Observe restrictions, and follow all regulations and rules.

Do not attempt to disassemble your device or its accessories — only qualified personal may install or repair device equipment. If your device or its accessory has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service centre.

Always treat your device and its accessories with care and keep it in a clean, dust-free place.

Do not paint your device or its accessories.

Do not expose your device or its accessories to open flames or lit tobacco products.

Do not expose your device or its accessories to liquid, moisture or high humidity.

Do not drop, throw or try to bend your device or its accessories.

Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.

Do not expose your device or its accessories to extreme temperatures below -10 or above +55 degrees Celsius.

Remember to make backup copies of all important data.

When connecting to any other device, read its user guide for detailed safety instructions.

7.5 DISPOSAL INFORMATION

Before disposing of the device, render it unusable.

When disposing of material, it is necessary to adhere to the pertinent national regulations for the disposal of waste.



All used packaging materials are ecological and may be reused or recycled. Please contribute actively to saving the environment and pay special attention to the correct disposal and reuse of packaging materials.



© Copyright 2011 by JABLOCOM, All rights reserved



Delivery contents:



Contact:

JABLOCOM s.r.o., Czech Republic support@jablocom.com, www.jablocom.com

