


REMOTE CONTROLLER (CCD-901T)



1. TRANSMIT INDICATION LED

The LED will light up each time a button is pressed.

2. CHANNEL UP BUTTON

3. CHANNEL DOWN BUTTON

Use to select the receiver (CCD-901R) channel up or down sequentially.

4. SCAN BUTTON

To set the receiver (CCD-901R) into the SCAN mode.

5. MUTE BUTTON

Press MUTE button to stop audio transmission, again to resume sound.

Notice:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

