

# **QUICK START GUIDE**

### KIT CONTENT



Serie No.

## SYSTEM INTRODUCTION




### **GETTING STARTED**

#### 1. Connect the gateway box to the Internet

- (1) Connect gateway box to your router via the Ethernet cable. Then plug in the supplied power cable.
- (2) The power LED indicator becomes steady RED and you will hear the gateway box beep twice. This means the gateway box is ready for APP setup.
- (3) Launch 'OMGUARD SHC' APP. The APP will automatically search the available gateway box and brings up the system DID/password. If it is not shown, Please check the system DID on the bottom of the gateway box. Enter the system DID and default password 123456 manually.

Note: The gateway box should be powered on and connected to the Internet at all times.

You can continue to setup the camera and sensor(s) now.








2. Set up the IP Camera

- (1) Connect the IP Camera to your router via the Ethernet cable.
- (2) Plug in the power adapter and wait until both RED and GREED LED begin flashing.

Note: DO NOT begin the APP setup process until both LEDs become steady on.



(3) Launch the 'OMGUARD SHC' APP. Click the 'ADD' icon + and choose 'Camera' to add the device to

Follow the APP wizard setup process to add the

Note: The APP will search the available IP Camera in LAN area. If the camera you're setting doesn't appear in the searching list, please enter the camera ID (DID) and password manually.

#### Installing the IP Camera:

- (1) Secure the camera stand on the stable surface.
- (2) Mount the camera into camera stand. Adjust the viewing angle and fix the camera tightly.

#### 3. Pair the Motion Sensor

Launch the 'OMGUARD SHC' APP. Click the 'ADD' icon + and choose 'Motion Sensor' and 😝 to initiate the pairing process, following with pressing the pairing button located inside the battery compartment to complete the process.


### Installing the Motion Sensor:

(1) Place the motion sensor upward, facing the location to be monitored. The detection distance is up to 16

For maximum coverage, it is recommanded to place the motion sensor highup with its back against the corner of walls to ensure best detection coverage.

(2) Use the double-sided tape to fix the motion sensor.













#### 4. Pairing the Power Switch

Launch the 'OMGUARD SHC' APP. Click the 'ADD' icon + and choose 'Power Switch' and to initiate the pairing process, following with press/hold the front panel button until LED flashing blue.

To initiate the switch function, press / hold the front panel button turned orange, following with pressing the pairing button on the device .

#### 5. Pairing the Door / Window Sensor

Launch the 'OMGUARD SHC' APP. Click the 'ADD' icon + and choose 'Door Sensor' and 😝 to initiate the pairing process, following with removing and reinstalling the battery compartment cover to complete the process.

#### Installing the Door/Window Sensor

Using the double-sided tape:

- (1) Apply the double-sided tape to the backs of the Door/Window sensor.
- (2) Select a location on the door/window. The large piece of the sensor should be fixed on the immovable frame of the door/window.
  - Align the small piece to the large one. Fix the small piece on the movable part of the door/window
- (3) When it is finished, open the door or window to test if the sensor has been correctly installed. You'll receive an alert from the mobile device if the APP and sensor have been corrected installed.








#### Using the mounting screws:

- (1) Fix the first mounting screw directly onto the door/ window frame (A). Place (hang) the larger piece on to the mounted screw, remove the battery compart ment cover to fix the second mounting screw (B).
- (2) Open back cover of the small piece. Use the mounting screws to fix the back cover on the movable part of the door/window frame (C). Mount the senor onto the back cover.
- (3) When it is finished, open the door or window to test if the sensor has been correctly installed. You'll receive an alert from the mobile device if the APP and sensor have been corrected installed.




#### 6. Indoor Siren

Launch the 'OMGUARD SHC' APP. Click the 'ADD' icon + and choose 'Siren' and 🚯 to initiate the pairing process, following with pressing the pairing button inside the battery compartment to complete the



#### Installing the Siren:

It is recommanded to install (wall-mount / place on flat surface) the Siren in a highly visible location with minimum obsticles near for maximum visual and sound alert deterrence in critical situations. A/C power option is available, choose a suitable power outlet location for the installation.



#### 7. Pairing the Remote Control

Launch the 'OMGUARD SHC' APP. Click the 'ADD' icon + and choose 'Panic Remote' and 😝 to initiate the pairing process, following with press/hold the camera

button until the LED flashing blue.





List of triggered events from device(s) and playback from camera(s).





### 8. APP Operation

Display device status in realtime. Tap "Status" to refresh the status page.

Setup groups of devices for instant function activation / deactivation.

- 1. Choose "+" to start a new "control".
- 2. Naming the control and select device(s).
- 3. Save



Setup various scenarios for system to launch preconfigured settings governing the behaviour of lights, cameras and sirens.

- 1. Choose a device (initiator) from the list.
- 2. Choose "+" to add additional device (follower). Repeat to add additional device(s). (ত্ৰ)
- 3. Save.

Example: "Motion PIR" (initator) > "Power Switch" (follower) > "Save".







## STATUS INDICATOR





Sensor Off



Sensor Triggered



**Power Low** 



Vandal Alert

Edit Mode



Delete









FCC Compliance Statement: This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Ce dispositif ne peut causer d'interférences; et
- ( 2 ) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.