TS3 (LTK-1300HN) Paging System

Manual

NOTICE

This manual, software and electronic circuitry are copyrighted. All rights reserved. Under the copyright laws, this manual, software and electronic circuitry may not be copied, in whole or in part without written prior consent of Lee Technology.

All information provided in this document is carefully prepared and offered in good faith as a guide in the installation, use and servicing of our products. Installers must ensure that the final installation operates satisfactorily within the relevant regulatory requirements. Lee Technology accepts no responsibility for incorrect installation. Lee Technology reserves the right to change products, specifications and installation data at any time without notice.

Lee Technology makes certain limited warranties with respect to defective diskettes, documentation and electronic circuitry. Please see the associated information contained on this page.

LIMITED WARRANTY

With respect to the physical documentation and physical electronic circuitry enclosed herein, Lee Technology warrants the same to be free of defects in materials and workmanship for a period of one year from the date of purchase. In the event of notification within the warranty period of defects in material or workmanship, Lee Technology will replace the defective diskettes, documentation and electronic circuitry. The remedy for breach of this warranty shall be limited to replacement and shall not encompass any other damages including but not limited to loss of profit and special incidental, consequential, or other similar claims.

Lee Technology Korea specifically disclaims all other warranties, expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose with respect to defects in the documentation and electronic circuitry and the program license granted herein, in particular, and without limiting operation of the program license with respect to any particular application, use or purpose.

IMPORTANT SAFETY INFORMATION

Caution: Any changes or modifications (including the antenna) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

1. PRODUCT INTRODUCTION

1) SUMMARY

LEETEK's Handheld Transmitter (new 10 key) was designed to help restaurants manage incoming customers efficiently and distinctively with portability and convenience. With simple operation of this product, a restaurant can provide instant notification to customer when customer's table is ready, making them feel special and welcome. Freed from long lines, your restaurant looks more inviting to people walking in, customers are encouraged to wait without fears of missing their table, resulting in higher traffic, while overall restaurant traffic flows more smoothly, leading to faster table turns. By offering perfect customer service the instant a customer appears, you will enjoy greater competitiveness, revenues and profits.

2) SPECIFICATION

FEATURE	BENEFIT		
TECHNOLOGY	° UHF Technology (450~470MHz)		
	° Eliminates dead spots and costly repeaters		
Handheld Transmitter	° Wireless Pager Programmability		
(new 10 key)	° Durable and Sturdy to withstand industry conditions		
	° Portability and convenience		
	° Simple operation		
	° Smart Charging System with own Charger Base		
	° Preset message		
RESTAURANT SYSTEM ID	° Unique Base ID to eliminate overlapping message		
RECHARGEABLE BATTERY	° Smart Charging eliminates over-charging and extend battery		
	life		
APPLICATION	° Restaurant, Café, Hotel, Pharmacy, Church, Super market, Car		
	Wash and Auto Dealer shop		

Thank you for purchasing Handheld Table Scout.

We are confident our cutting edge products and first rate service will satisfy your needs for years to come. Please read the manual thoroughly to familiarize yourself with the procedures for proper care of your system.

1. To Page

1)To page the pager.

Press the pager number and then press Enter key

- ; Enter Pager no. >> Press Enter key >> Sending
- Cf. Preset and Message menu options shall be programmed OFF if you want to page the pager only without sending any messages.
- Cf. Example to page the pager no. 7

Action	Transmitter display		
Press "7"	No>7		
Press "Enter"	Sending		
	AM 10:00 (Current time)		

2)To send the Preset or Message(Numeric number)

Table scout is able to send one of them, Preset or Message (max. 12 Numeric numbers) to the pager as described below

(1) To send the Preset (PRESET/PRE / Default: C)

Preset menu (PRE) shall be set ON and Message(MSG) menu shall be set OFF prior to use the preset Menu.

- Press the pager number and press Enter key,
- Enter the preset number and press Enter key
- ; Enter Pager no. >> Enter key >> Enter one of the preset number 1~4 >> Enter key >> Sending
- Cf. Example to send the preset no. 3 to the pager no. 7

Action	Transmitter display		
Press "7"	No>7		
Press "Enter"	PRESET		

Press "3" PRESET3
Press "Enter" Sending

AM 10:00 (Current time)

(2)To send Message(Numeric numbers)

Message menu(MSG>ON) shall be set ON and Preset menu(PRE>OFF) shall be set OFF prior to use Message menu option

- Press the pager no. and press Enter key
- Enter the numeric numbers and then press Enter key
- ; Enter Pager no. >> Press Enter key >> input the max. 12 numeric numbers >> Press Enter key >> Sending
- Cf. Example to send the numeric number message (12345678) to the pager no.7

Action	Transmitter d	isplay
Press "7"	No>7	
Press "Enter"	Μ	
Press "12345678"	M78 . (123	456 will not be displayed but included)
(Press "876543"	M876543	if send 876543)
Press "Enter"	Sending	
	AM 10:00	(Current time)

(3) Priority in Preset and Message menu option

- Message menu has the priority to be sent while the both, Preset menu &
 Message menu have been set ON in displaying the message on the pager.
- On the LCD, Preset menu is described as PRESET or PRE and Message menu as MESSAGE or MSG.

4. Pro-Host use

To send the message to the Pro-host or a pager, Enter the table no. and press the function key (Seat, Close, Clear, Bus)

Cf. Example to send the message that clear the table no. 23

Action	Transmitter display
Press "23"	No>23

Press "Clear" Sending

AM 10:00 (Current time)

Cf. In this case, the pagers display "20237"

5. Power On/Off

1) Power Off

Following the below steps to turn its power off.

Action	Transmitter display
Press "Bus" & "Close" for 3 sec Press "0000"	P/W P/W0000
Press "Enter"	

2) Power On

Place the Handheld Table scout into the charging base and take it off from the charger

Then the Handheld Table Scout will be ON automatically