




Quick Setup Guide

This HD Quick Setup Guide is intended to help you connect your TV to your HD signals.

Important Notes

- Please read the "Important Safety Precautions" and "Warnings" sections in your users guide before you begin using your TV.
- Please visit www.jvc.com or call customer service at **1-800-252-5722** if you encounter a problem with your TV, or to order additional cables or wall mounts.

Make sure you have the following



Satellite / Basic Cable / Cable Box / DVR / DVD Connections

Note:
• Refer to your optional device's users guide for the best way (if applicable) to connect them as well as "Connecting Your Devices" in your TV users guide.

	HDMI
	DVI to HDMI (with Composite Audio Cables)
	Component (Y, Pb, Pr, L, R)
	*Coaxial 75Ω (VHF/UHF)
	S-Video
	*Composite (V, L, R)


- HDMI to HDMI Cable connection - BEST**
DVI to HDMI Cable and Audio L/R Cable connection - BETTER
 - Component Cable and Audio L/R Cable connection - GOOD**
 - Over-The-Air Antenna - OK**
- * Component is best used for analog signal.
* Analog composite is better than analog coaxial.*

* Coaxial Cable can receive over-the-air or unscrambled cable HD (ATSC/QAM) transmissions when connected directly to the TV (not through a VCR/DVD).

Connecting to an HD Signal

Notes:

- Please choose only one connection type.
- You cannot view HD quality signals with Composite or S-Video cables (Y/C).



General Note:
• Refer to your cable or satellite provider for more detailed information about their services, equipment and service costs. Some channels may be unavailable if you are using DVI or HDMI connection.

