

## Errata for SR-HD2500 (All Models)

### Page 17 in the instruction manual

#### Connecting using a component video cable

**Wrong:**

**Memo :** \_\_\_\_\_

- After connecting a component video cable, change the unit setting to "COMPONENT OUTPUT".

For more details, refer to "COMPONENT OUTPUT" (page 85).

**Correct:**

**Memo :** \_\_\_\_\_

- After connecting a component video cable, change the unit setting to "SDI/COMPONENT OUTPUT".

For more details, refer to "SDI/COMPONENT OUTPUT" (page 85).

### Page 77 in the instruction manual

**Wrong:**

HDMI VIDEO MODE ..... (page 85)

**Correct:**

VIDEO PRIORITY MODE ..... (page 85)

**Wrong:**

COMPONENT OUTPUT ..... (page 85)

**Correct:**

SDI/COMPONENT OUTPUT ..... (page 85)

### Page 83 in the instruction manual

#### ■ HDMI CONNECTION

**Wrong:**

**Memo :** \_\_\_\_\_

- During data output from the [HDMI] terminal, setting to "SDI/COMPONENT" automatically outputs data in the "COMPONENT OUTPUT" setting.
- During data output from the [HDMI] and [COMPONENT VIDEO OUT] terminals, setting to "SDI/COMPONENT" automatically outputs data in the "COMPONENT OUTPUT" setting.

**Correct:**

**Memo :** \_\_\_\_\_

- During data output from the [HDMI] terminal, setting to "SDI/COMPONENT" automatically outputs data in the "SDI/COMPONENT OUTPUT" setting.
- During data output from the [HDMI] and [COMPONENT VIDEO OUT] terminals, setting to "SDI/COMPONENT" automatically outputs data in the "SDI/COMPONENT OUTPUT" setting.

### Page 84 in the instruction manual

- HDMI OUTPUT RESOLUTION

**Wrong:**

**Memo :** \_\_\_\_\_

In this case, set "HDMI VIDEO MODE" to "OFF".

OSD of the [VIDEO OUT]/[S-VIDEO OUT] terminals may be cut off with the above conditions even when "OFF" is selected.

**Correct:**

**Memo :** \_\_\_\_\_

In this case, set "VIDEO PRIORITY MODE" to "SDI/COMPONENT".

OSD of the [VIDEO OUT]/[S-VIDEO OUT] terminals may be cut off with the above conditions even when "SDI/COMPONENT" is selected.

### Page 85 in the instruction manual

**Wrong:**

#### ■ COMPONENT OUTPUT

**Memo :** \_\_\_\_\_

- If "HDMI VIDEO MODE" is set to "ON", the unit will output at "480i" regardless of the current setting.
- If "HDMI VIDEO MODE" is set to "OFF", or when a HDMI connection is used, DVD videos will be output at "480p" even if "720p" or "1080i" has been set.

**Correct:**

#### ■ SDI/COMPONENT OUTPUT

**Memo :** \_\_\_\_\_

- If "VIDEO PRIORITY MODE" is set to "HDMI", the unit will output at "480i" regardless of the current setting.
- If "VIDEO PRIORITY MODE" is set to "SDI/COMPONENT", or when a HDMI connection is used, DVD videos will be output at "480p" even if "720p" or "1080i" has been set.

### Page 111 in the instruction manual

**Wrong:**

COMPONENT OUTPUT ..... 85

**Correct:**

SDI/COMPONENT OUTPUT ..... 85

## Page 105 in the instruction manual

### Wrong:

Problem	Symptom	Action	Reference Page
The aspect ratios of the HDMI output and component output are different	When two monitors are connected respectively to the HDMI output and component output terminals of this unit, the screen aspect ratio of the component output may not be appropriate if "HDMI VIDEO MODE" is set to "ON".	When two monitors are connected simultaneously, users are recommended to set "HDMI VIDEO MODE" to "OFF".	(page 85)

### Correct:

Problem	Symptom	Action	Reference Page
The aspect ratios of the HDMI output and component output are different	When two monitors are connected respectively to the HDMI output and component output terminals of this unit, the screen aspect ratio of the component output may not be appropriate if "VIDEO PRIORITY MODE" is set to "HDMI".	When two monitors are connected simultaneously, users are recommended to set "VIDEO PRIORITY MODE" to "SDI/COMPONENT".	(page 85)