

TROUBLE SHOOTING

PROBLEM	SOLUTION
Car will not START	1. Power switch is off. Turn on. 2. Batteries are installed with incorrect polarities. Check the + and - markings to make sure the batteries are properly aligned. 3. Batteries are drained. Charge batteries and/or install new batteries.
Car does not respond to controls.	1. Transmitter controller battery is drained. Replace the 9V controller battery. 2. Vehicle is out of range. Bring controller closer to the vehicle. 3. Interference from surrounding electrical machinery. Bring to a wide open space.
Car does not drive straight.	1. Adjust the steering dial underneath the front axle, left or right, until the wheels point straight forward.
Car does not move	1. Release the trigger immediately, and rest your car for few minutes.

WWW.JADATOYS.COM

Battery Safety Information

- Ensure that battery polarity is correct.
- Use only batteries of the recommended type (or equivalent).
- Do not mix old batteries with new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove depleted batteries immediately or if vehicle will not be used for a long duration to avoid possible leakage.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit terminals.
- Remove rechargeable batteries from vehicle before recharging.
- Rechargeable batteries are to be recharged by adults only.
- Dispose of batteries safely. Do not expose batteries to fire, as batteries may leak or explode.
- Do not disassemble the battery pack.
- Do not overcharge the battery. Use only the charger provided. Charging the battery pack with a charger other than the one provided may result in damage to the battery, improper charging, and/or explosion.

QUICK TIPS

- Vehicle power loss or malfunctioning is often a result of weak batteries. Replace/recharge batteries to obtain optimum performance. The vehicle's running time may change, depending on your driving style.
- Radio frequency interference can result in poor vehicle performance. Interference can be caused by other R/C vehicles operating under the same frequency, electrical wires, large buildings, and CB radios. Try to stay away from these!
- Point your transmitter controller antenna up—not down toward the vehicle. If the vehicle gets too far away, it may not work properly.
- Don't operate the vehicle in sand, water, or snow.
- Don't store the vehicle near heat or in direct sunlight. Always turn switches OFF and remove batteries for storage.

Cleaning instruction:

- Always remove the batteries before cleaning! Using a clean, damp cloth (plain water) wipe dirt and debris from the surface of the vehicle. Use a dry cloth to dry the surface of the vehicle.
- Do not immerse the vehicle in water.
- Do not use any chemicals to clean the vehicle - use plain water only.
- Allow the vehicle to completely dry before reinstalling batteries.

COMPLIANCE WITH FCC REGULATIONS (VALID IN U.S. ONLY) THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION OF THIS DEVICE IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
2. THIS DEVICE MUST ACCEPT ANY HARMFUL INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

This device generates and uses radio frequency energy and if not used properly may cause interference to radio and television reception. It has been tested and found to comply with the limits set by the FCC which are designed to provide reasonable protection against such interference.

FCC Warning:

CAUTION:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important! Problems?



Before taking your new R/C back to the retailer, call our friendly R/C technicians at:

1-800-679-5232

between the hours of 9 am to 5 pm Pacific Time; Monday - Friday.

WWW.JADATOYS.COM

Questions or problems with your vehicle?

DO NOT RETURN IT TO THE STORE!

U.S.A & Canada
60-Day Limited Warranty
Jada Toys R/C Products

Jada Toys, Inc. warrants to the original consumer purchaser that this product will be free of defects in material and workmanship for sixty (60) days from the date of purchase. Jada Toys will repair or replace the product, at our sole option, in the event of such a defect within the warranty period.

In the event of a defect covered under this warranty, first call the toll-free number listed below. Many problems can be solved in this manner. If necessary, you will be instructed to return the product, postage pre-paid and insured, to the address below.

Enclose your name, address, telephone number, copy of dated sales receipt, and a brief explanation of the defect. Repair or replacement, and return shipment, will be free of charge. Please return on the defective part or unit, packed securely. This warranty does not cover damage resulting from unauthorized modification, accident, misuse or abuse. If the product is returned without a dated sales receipt, the product may be excluded from coverage under this warranty.

Jada Toy's liability for defects in material and workmanship under this warranty shall be limited to repair or replacement, at our sole option, and in no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). This warranty is exclusive, and is made in lieu of any express or implied warranty. **Valid only in U.S.A. and Canada.** This warranty gives you specific legal rights and you may have other rights, which may vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

TOLL-FREE NUMBER: 1-800-679-JADA (5232) (valid only in U.S.A. and Canada)

Hours: 9:00 A.M. – 5:00 P.M. Pacific Time; Monday – Friday. Expect some delay in January following the holiday season. Please be patient and keep trying the toll-free number.

Address for Returns:
Consumer Relations, Jada Toys, Inc
938 Hatcher Ave.
City of Industry, CA 91748

CAUTION-ELECTRICALLY OPERATED PRODUCT:

Not recommended for children under 8 years of ages. As with all electric products, precautions should be observed during handling and use to prevent electric shock.
INPUT: 120V AC 60Hz 3.0W
OUTPUT: 12V DC 200mA