



SPEED RACER™

Keep these instructions for future reference: they contain important information.

IMPORTANT: Please read all "Consumer Information" before operating your vehicle.

CAUTION: ELECTRICALLY OPERATED PRODUCT

Not recommended for children under 8 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

ADULT SUPERVISION REQUIRED.

Surfaces may become hot and cause burns if electronics get wet. Do not operate vehicle through water or snow.

Consumer Information:

Note to Adults: to ensure that the child's play is both safe and fun, please review all operating instructions and safety rules with your child.

CONTENTS

Vehicle	x 1PC
Transmitter Controller	x 1PC
Antenna for Transmitter Controller	x 1PC
9.6V Ni-Cd Battery Pack	x 1PC
Charger for 9.6V Ni-Cd Battery Pack	x 1PC
9V battery	x 1PC

Safety Tips

- NEVER drive your vehicle on streets! They're for real cars!
- DO NOT pick up vehicle while in motion.
- Avoid collisions with wall or hard surfaces.
- Keep fingers, hair and loose clothing away from tires and the wheel hubs while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries when not in use.
- Regularly examine battery charger, cord, and plug enclosure and other parts for damage. In the event of any damage to such parts, do not use the battery charger until it has been properly repaired.
- For transformer toys and toys with battery boxes: toy is not to be connected to more than recommended number of power supplies.
- Recommended rechargeable battery 9.6V 700MAH Ni-Cd.
- Be sure to rest your vehicle for at least 5 minutes after every 15 minutes of operation.

BEFORE BATTERY INSTALLATION

Your new R/C is designed to work with standard R/C 9.6-volt Ni-Cd batteries and charger.
Controller is designed to work with a 9-volt alkaline battery.

For detailed information regarding Ni-Cd battery charging and safety, please follow the specific instructions that came with your battery pack and charger.

BATTERY CHARGING:

(When using 9.6V Ni-Cd Battery Pack)

****RECHARGEABLE BATTERIES ARE TO BE CHARGED BY ADULT ONLY****

(The rechargeable Ni-Cd battery pack is not charged, please charge battery for 4 (four) hours prior to use)




1. Plug the wall pack battery charger into wall outlet.
2. Connect the cables leading from the Battery Pack and the charger together by snapping the jack and the socket tightly. (See diagram 1)
3. To disconnect cables, press down on the clip and pull apart. (See diagram 1)
4. After charging for 4 (four) hours, the battery will be warm. This condition is normal for fully charged batteries. DO NOT overcharge the battery.
5. After use, the battery pack will be hot!!! Wait at least 20 minutes until the battery cools before recharging. Recharging a warm or hot battery pack will greatly shorten the use life of the battery.

INSTALLING BATTERIES IN THE R/C 9.6V Ni-Cd

1. Push the power switch to "OFF" position on vehicle.
2. To install the 9.6V Ni-Cd battery (included), use a Phillips screwdriver (not included), to remove the battery compartment door underneath the vehicle. (See diagram 2)
3. Remove the battery compartment door.
4. Plug the battery pack into the cable by snapping the jack and socket lightly.
5. Replace the battery compartment door and use Phillips screwdriver to lock the compartment door.

INSTALLING CONTROLLER 9 VOLT BATTERY

1. Open the battery cover as shown (See Diagram 3)
2. Install one 9V battery (included) with polarity (+/-) as shown inside battery compartment.
3. Replace battery cover.



© 2008 Speed Racer Enterprises, Inc. All Rights Reserved. Speed Racer is a trademark of Speed Racer Enterprises, Inc. and is used under license.

Jada oval mark is a trademark of Jada Toys, Inc.

©2008 Jada Toys, Inc., City Of Industry, CA 91748