

4+
2.4GHz #87374

HULK SMASH RC INSTRUCTIONS

* Please remove try-me cable from VEHICLE and REMOTE CONTROL before use.

CAUTION: ADULT SUPERVISION REQUIRED. ALWAYS PLAY IN SAFE SURROUNDINGS. AWAY FROM STREETS OR HIGHWAY VEICLES.

VEHICLE:
 X6 1.5V AA (LR6) ALKALINE BATTERIES INCLUDED

REMOTE CONTROL:
 X2 1.5V AA (LR6) ALKALINE BATTERIES REQUIRED NOT INCLUDED

CONTENTS:
 - RC VEHICLE
 - REMOTE CONTROL
 - HULK'S LEFT ARM

TM & © 2015 MANUFACTURED BY JAKKS PACIFIC, INC., 2951 29TH STREET, SANTA MONICA, CA 90405 U.S.A. All other symbols, marks, logos, and designs (collectively "Trademarks") are Trademarks of and proprietary to their respective owners and used under license. Contents may vary in style, color, shape and decoration from images shown on package or in advertising. Questions or comments? www.jakks.com, consumers@jakks.com, or 1-877-875-2557 in North America. Retain packaging and instructions since they contain important information. MADE IN CHINA.



ARM ASSEMBLY INSTRUCTION

ADULT ASSEMBLY REQUIRED

1. Take Hulk's left arm and locate the junction on the left of Hulk's body. Align the rib on arm to the slot of hexagonal junction.
2. Plug Hulk's left arm in and push until the arm is completely attached with the body.

BATTERY REPLACEMENT / INSTALLATION

ADULT INSTALLATION REQUIRED
 Requires 6 "AA" (LR6) ALKALINE BATTERIES for vehicle and 2 "AA" (LR6) ALKALINE BATTERIES for remote control. Batteries for the vehicle are included. When performance diminishes, replace with fresh batteries.

VEHICLE

1. Unplug the Try-me cable at the back of vehicle and remote control.
2. Locate and open BATTERY COVERS on BACK and BOTTOM of the vehicle as shown. Use a Phillips/cross head screwdriver (not included) to loosen screws. Screws remain attached to cover.
3. Replace / install 4 - 1.5V AA (LR6) ALKALINE BATTERIES in the back and 2 - 1.5V AA (LR6) ALKALINE BATTERIES in the BOTTOM in the orientation shown.
4. Replace BATTERY COVERS and tighten screws.

Note: Always replace all 6 batteries at the same time.

REMOTE CONTROL


1. Locate and open BATTERY COVER as shown. Use a Phillips/cross head screwdriver (not included) to loosen screws. Screws remain attached to the cover.
2. Install 2 - 1.5V AA (LR6) ALKALINE BATTERIES in the orientation shown.
3. Replace BATTERY COVER and tighten screws.

BATTERY SAFETY INFORMATION

WARNING! Battery acid leakage can cause personal injury and cause damage to the product and surrounding property. If battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. Immediately wash any clothing or other surface that comes in contact with leaked battery acid. Leaking batteries may make "popping" sounds. Dispose according to local, State or Federal Battery Laws.


TO AVOID BATTERY PROBLEMS:
 NEVER mix old and new batteries or different brands of batteries. NEVER mix alkaline, standard (carbon-zinc), rechargeable (nickel-cadmium) batteries with this product. NEVER dispose of batteries in fire, as they may leak and explode. NEVER use rechargeable batteries. ALWAYS remove exhausted batteries from toy. ALWAYS have an adult install batteries consistent with installation instructions. ONLY use batteries specified by manufacturer. Batteries are to be inserted with the correct polarity. The supply terminals are not to be short-circuited. Non-rechargeable batteries are not to be recharged.

CONTROLS REMOTE CONTROL



1. Push joystick FORWARD to drive VEHICLE forward with powered SMASHING ARMS. The more the joystick push FORWARD, the higher the VEHICLE speed.
2. Pull joystick BACKWARDS to spin VEHICLE without powering SMASHING ARMS. This will TURN and change direction of the VEHICLE. The more the joystick push BACKWARD, the higher the VEHICLE speed. Tips: Keep hand position over the floor to have the best performance.
3. Press SPIN BUTTON to move SMASHING ARMS into WHEELIE position. Vehicle will SPIN for five seconds. Keep pressing the SPIN BUTTON for longer spinning time.

VEHICLE



OPERATION

1. VEHICLE: Move the ON/OFF/TRY-ME SWITCH to the ON position.
2. REMOTE CONTROL: Move the OFF / ON SWITCH to the ON position.

3. Place the VEHICLE on ground and point the REMOTE CONTROL directly at the VEHICLE. The LED light on REMOTE CONTROL will flash when pairing with the VEHICLE. Pairing process is completed when the LED light is solid on and the VEHICLE is ready to go. Use the FORWARD/ROTATE to maneuver the VEHICLE. Pairing is required every time the VEHICLE/REMOTE CONTROL is turn ON.
 Note: When LED light on REMOTE CONTROL is keep flashing, switch off both VEHICLE and REMOTE CONTROL and repeat pairing process.

Note: This vehicle is for indoor use only. Works best on tile, hardwood floor and other smooth hard surfaces. Not recommended for use on carpets, grass, loose dirt, wet surface or concrete. Never use in water or mud. Never use near glass and other fragile objects.

SPIN MODE

4. Press SPIN BUTTON to have the vehicle spin for 10 seconds. Hold down the SPIN BUTTON to keep the vehicle spinning.
 NOTE: Hulk's arms need to be in the same position on each side. Rotate left arm FORWARD/BACKWARD if necessary to match right arm position.
 NOTE: Wheelie SPIN is un-achievable if fist's starting position is at front of toe.

NOTE: Wheelie SPIN does not success all of the time due to a combination of fist position/floor friction/battery power factors. If wheelie SPIN does not success, repeat SPIN mode one or more times.

CUSTOM SMASH MODE

There are EIGHT different positions for the SMASHING ARMS. Each position gives different forward driving actions based on when the FISTS hit the ground.

1. To change arm position, rotate LEFT ARM forward or backwards the desired number of clicks.
2. Drive VEHICLE forward, SMASHING ARMS will nudge the VEHICLE left or right in different combinations to find new results.

CORRECTION

If the VEHICLE flips over, first try to continue pushing the joystick FORWARD. When Hulk's arms are not in the same position on each side, the vehicle may not always self-right.
 Tips: Try to lower down the forward speed if the vehicle keep flipping over continuously.

IMPORTANT SAFETY INFORMATION

- NEVER drive near traffic, buildings, trees, people or other obstructions.
- NEVER operate during storms or other adverse weather conditions.
- ALWAYS point away from face, eyes, people, animals and property when driving.
- ALWAYS use alkaline batteries only.
- Never use in water or mud.
- Never use near glass and other fragile objects.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Vehicle won't move.	Vehicle / Remote Control switch is switched OFF.	Move switch to ON position.
	Weak Remote Control batteries.	Press any direction button. If indicator light does not activate, replace batteries in the Remote Control.
	Vehicle is stuck.	Move vehicle to a smoother surface, clean tires, make sure surface or floor is clean as well.
	Weak vehicle batteries.	Replace batteries.
	Remote Control is not close enough to vehicle.	Make sure the Remote Control is placed within the signal receiving range.
Vehicle won't do high speed wheelie spins after pressed spin button.	Large friction between tires and floor.	Use on tile, hardwood floor and other smooth hard surfaces.
	Hulk's arms are not in the same position on each side.	Rotate left arm forward or backwards the desired number of clicks.
	weak vehicle batteries.	Replace batteries.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment does not emit radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil répond aux exigences du chapitre 15 de la FCC. Son utilisation respecte les deux conditions suivantes:

- (1) Cet appareil n'émet pas de causes d'interférences dangereuses et (2) Cet appareil accepte tout type d'interférences, y compris celles pouvant altérer son fonctionnement.

AVIS EN GARDE : tout changement ou modification non approuvés expressément par le fabricant responsable de la conformité pourrait annuler le droit d'accès à la fonctionnalité de cet appareil.

REMARQUE : cet appareil a été testé et vérifié conforme aux normes du chapitre 15 de la FCC relatives aux appareils numériques de classe B. Ces normes visent à offrir une protection acceptable contre les interférences dangereuses dans une installation résidentielle. Cet appareil ne génère ni émet d'énergie radio. Il peut néanmoins causer des interférences nuisibles à la réception des communications radio si il est installé et utilisé conformément aux instructions. Cependant, il n'y a pas de garantie quant à l'absence d'interférences dans une installation particulière. Les interférences avec la radio ou la télévision hertzienne peuvent être mises en évidence en allumant et en éteignant l'appareil. Les manipulations suivantes permettent de corriger de telles interférences :

- Changer l'emplacement ou l'orientation de l'antenne de réception.
- Augmenter la distance entre les appareils en cause.
- Brancher les appareils sur deux prises électriques distinctes.
- Consulter le vendeur ou un technicien radio-TV expérimenté si nécessaire.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

JAKKS Pacific® Battery, Solar or Electrically-Operated Product 90 DAY LIMITED WARRANTY
 Pour produit à fonctionnement électrique, solaire ou à piles de JAKKS Pacific® GARANTIE LIMITÉE DE 90 JOURS

Thanks for purchasing a great JAKKS Pacific® product! Please immediately register your product online at www.jakks.com/warranty. Registration is not required for our 90-day limited warranty.

IMPORTANT NOTICE TO CONSUMER:
 The 90-day LIMITED WARRANTY applies to the original product purchase, provided the product: 1) was purchased from an authorized JAKKS™ distributor/dealer/retailer; and 2) is returned at your expense, postage pre-paid and insured, along with the original dated sales receipt to the address noted below. Please retain a copy of your original receipt as proof of purchase. The product will not be returned to you.

If you return the product to us without the original dated sales receipt, this warranty coverage will not apply. If the product is determined by JAKKS to be defective and returned to JAKKS within the 90-day warranty period, we will at our option repair or replace it. Return shipment to you may take up to 6 weeks, depending upon your location. If your product is repaired or replaced, it will be warranted for the longer of the original warranty or for 30 days after warranty service.

SCOPE OF LIMITED WARRANTY: The product is warranted to be: a) tested and inspected before shipment, and b) free of defects in material and workmanship for 90 days from date of purchase. If a covered defect occurs within the warranty period, then at our sole option, we will repair or replace the product or provide you with another product of equal value.

WHAT IS NOT COVERED BY LIMITED WARRANTY:
 THIS WARRANTY IS VOID IF THE PRODUCT HAS BEEN MODIFIED OR REPAIRED BY USER OR OTHERS OR IF IT HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, IMMERSION IN WATER, NEGLIGENCE, ABUSE, MISUSE, BATTERY LEAKAGE, IMPROPER BATTERY INSTALLATION, UNAUTHORIZED SERVICE, LOSS OF PARTS, WEATHER, ACTS OF GOD, ANY ACTION OR OMISSION WHICH CONSTITUTES A VIOLATION OF THE ORIGINAL INSTRUCTIONS, OR ANY OTHER CAUSES NOT ARISING OUT OF DEFECTS IN THE ORIGINAL PRODUCT.

EXCLUSIONS FROM LIMITED WARRANTY: THIS WARRANTY IS EXCLUSIVE OF AND IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES OR WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SPECIAL, INCIDENTAL AND CONSEQUENTIAL DAMAGES ARISING FROM LEGAL USE OR MALFUNCTION OF THIS PRODUCT ARE EXCLUDED BOTH FOR PROPERTY DAMAGE AND PERSONAL INJURY TO THE EXTENT LEGALLY PERMITTED.

ADDITIONAL LEGAL RIGHTS: This warranty provides specific legal rights. You may have other or different rights in your state or country. **QUESTIONS OR COMMENTS:** If you experience product difficulties or have questions or comments, you may contact our Consumer Relations department as follows:
 Phone: 877-875-2557 (toll-free, North America only) or 909-594-7771 (Monday-Friday, 7:30AM-4:30PM Pacific GMT -8)
 Mail: JAKKS Consumer Relations, 21749 Baker Parkway, Walnut, California USA 91789.
 Email: consumers@jakks.com

WHEN WRITING TO US: Please include: 1) product name; 2) item number; 3) purchase date; 4) description of the problem being experienced; and 5) your name, address and phone number. Additionally, if eligible under the warranty and as advised by JAKKS Consumer Relations, also include the defective product and the ORIGINAL dated sales receipt evidencing product purchase. Please retain a copy of your receipt.

Nous vous remercions d'avoir fait l'acquisition de cet article de JAKKS Pacific®!

AVIS IMPORTANT AU CONSOMMATEUR : Cette GARANTIE LIMITÉE DE 90 JOURS ne s'applique qu'au produit acheté en France, sous sa présentation originale et assuré. L'accompagnement du reçu daté d'achat original et l'adresse indiquée plus bas doivent être conservés.

Si le produit est jugé défectueux par JAKKS et nous a été renvoyé dans le délai de garantie, nous nous réservons l'option de le réparer ou le remplacer. L'expédition de retour prendra jusqu'à 6 semaines en fonction de la localité d'achat. Si l'article est renvoyé, il sera soumis à l'approbation de notre service client.

ÉTENDUE DE LA GARANTIE LIMITÉE : Elle est garantie que ce produit a été : a) testé et inspecté avant l'expédition et b) exempt de vice de matière et de défauts de fabrication.

CE QUE LA GARANTIE LIMITÉE NE COUVRE PAS : Cette garantie ne couvre pas les dommages causés par une utilisation incorrecte, un accident, une immersion dans l'eau, une négligence, un abus, une utilisation incorrecte de piles, une installation incorrecte de piles, une négligence, une utilisation abusive, une utilisation incorrecte de piles, des catastrophes naturelles, de toute action ou omission qui constitue un écart par rapport aux directives d'emploi ou toute autre raison autre que causée par un vice de matière ou de fabrication.

EXCLUSIONS DE LA GARANTIE LIMITÉE : CETTE GARANTIE EXCLUT ET REMPLACE TOUTE AUTRE GARANTIE EXPRESSE OU TACITE CONCERNANT LA PRÉSENTE GARANTIE EST NULLE SI LE PRODUIT A FAIT L'OBJET DE MODIFICATIONS OU DE RÉPARATIONS PAR L'UTILISATEUR OU AUTRUI OU SI LA PRÉSENTE GARANTIE EST NULLE EN RAISON D'UN ACCIDENT, D'UN DÉFAUT D'INSTALLATION, D'UN DÉFAUT D'ENTRETIEN, D'UNE MALFONCTION, D'UNE OMISSION, D'UNE MANIPULATION NON AUTORISÉE, DE PERTE DE PIÈCES, D'ENTRÉE EN CHOC, DE CATASTROPHES NATURELLES, DE TOUTE ACTION OU OMISSION QUI CONSTITUE UN ÉCART PAR RAPPORT AUX DIRECTIVES D'EMPLOI OU TOUTE AUTRE RAISON AUTRE QUE CAUSÉE PAR UN VICE DE MATIÈRE OU DE FABRICATION.

DROITS SUPPLÉMENTAIRES : Cette garantie fournit des droits spécifiques. Ils peuvent être différents selon les états, les provinces ou les pays. **QUESTIONS OU COMMENTAIRES :** Si cet article présente des problèmes de fonctionnement ou pour toute question ou commentaire, veuillez contacter notre service à la clientèle comme suit:
 par téléphone : 877-875-2557 (appel sans frais à partir de l'Amérique du Nord uniquement) ou le 909-594-7771 (du lundi au vendredi, de 7h à 16h -30, heure du Pacifique / GMT - 8)
 par courrier : JAKKS Pacific, Inc. Consumer Relations, 21749 Baker Parkway, Walnut, California USA 91789.
 par e-mail : consumers@jakks.com

LES DROITS SUPPLÉMENTAIRES : Cette garantie fournit des droits spécifiques. Ils peuvent être différents selon les états, les provinces ou les pays. **LES DROITS SUPPLÉMENTAIRES :** Cette garantie fournit des droits spécifiques. Ils peuvent être différents selon les états, les provinces ou les pays.

QUESTIONS OU COMMENTAIRES : Si cet article présente des problèmes de fonctionnement ou pour toute question ou commentaire, veuillez contacter notre service à la clientèle comme suit:
 par téléphone : 877-875-2557 (appel sans frais à partir de l'Amérique du Nord uniquement) ou le 909-594-7771 (du lundi au vendredi, de 7h à 16h -30, heure du Pacifique / GMT - 8)
 par courrier : JAKKS Pacific, Inc. Consumer Relations, 21749 Baker Parkway, Walnut, California USA 91789.
 par e-mail : consumers@jakks.com