



正面

<p>Rocksteady XS</p> <p>Congratulations on purchasing the Rocksteady XS, the best performing portable speaker on the market.</p> <p>Play music through the Rocksteady XS via Bluetooth®, 3.5mm line-in (cable included), or MP3 music via a USB thumb drive.</p> <p>With its slim design and long lasting rechargeable lithium-ion battery, you can bring your music with you virtually anywhere you go.</p> <p>* Bluetooth® version only.</p>	<p>FRONT</p>  <p>BACK</p> 	<p>FRONT</p> <ol style="list-style-type: none">Mode – Switches from Bluetooth®, Line-in, USBPlay, pause, stop when in USB modeVOL-: Volume downVOL+: Volume upSkip track back in USB modeSkip track forward in USB mode <p>BACK</p> <ol style="list-style-type: none">USB – Insert your USB thumb drive to play your MP3 musicMICRO USB – Charging port (charger included)LINE IN – 3.5mm input to play audio from virtually any device (via headphone jack or audio output)POWER – Switch power on/off to your Rocksteady XS <p>* Bluetooth® version only.</p>	<p>LED Light</p> <p>The base of the Rocksteady XS contains LED lights which communicates the status of the device.</p> <p>Solid Blue – Rocksteady XS is on and ready to play</p> <p>Flashing Blue – Rocksteady XS is on and is in Bluetooth® mode</p> <p>Solid Red – Rocksteady XS is plugged in and charging</p> <p>Solid Purple – The Rocksteady XS is charging and is on, ready to play.</p> <p>Plugged in and No Light – Rocksteady XS is done charging</p> <p>How to Connect to...</p> <ol style="list-style-type: none">When you turn it on, default will be Line -In mode.Press mode button once to enter Bluetooth® and Bluetooth® pairing mode.If USB drive is inserted, press mode button again to enter USB mode. <p>* Bluetooth® version only.</p>	<p>Troubleshooting Bluetooth®</p> <p>Unable to Pair to Bluetooth® device</p> <ol style="list-style-type: none">Make sure device has Bluetooth® capabilityMake sure the Rocksteady XS is powered to the “On” positionReboot your Bluetooth® device, and power off and on your Rocksteady XS.Newer Bluetooth® devices will not require a pin. Should a pin be prompted, enter 0000. <p>Safety Information</p> <p>Please read these safety warnings and cautions carefully to ensure your personal safety and to prevent property damage.</p> <p>Fire and Electric Shock Hazard</p> <p>*Do not expose your Rocksteady XS speaker to liquid, moisture, high levels of humidity, or rain. Do not use the Rocksteady XS speaker near a bathtub, sink, sauna, pool, or steam room.</p> <p>Exposure of the Rocksteady XS speaker to moisture could result in electric shock or product failure.</p> <p>* Bluetooth® version only.</p>
---	--	---	--	--

1

2

3

4

5

反面

<p>* Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to the Rocksteady XS speaker.</p> <p>Such actions could result in electric shock or product failure.</p> <p>Clean the Rocksteady XS speaker only with a dry cloth.</p> <p>Do not expose your Rocksteady XS speaker to extremely high or low temperatures.</p> <p>Do not leave your Rocksteady XS speaker in direct sunlight for extended periods of time.</p> <p>Do not leave your Rocksteady XS speaker near open flames such as cooking burners, candles, or fireplaces.</p> <p>Battery/Charger Hazard</p> <p>Do not dispose of your Battery/Charger in the trash. Please dispose at a certified recycling center</p> <p>Do not dispose of your Rocksteady XS in a fire. The battery could explode causing injury or death.</p> <p>Only charge the battery in accordance with the user instructions supplied with the Rocksteady XS.</p> <p>Do not attempt to disassemble the Rocksteady XS charger or force open the built-in battery.</p> <p>Do not charge the Rocksteady XS in damp areas or in extremely high or low temperatures.</p> <p>Do not clean the Rocksteady XS when it is being charged. Always unplug the charger pryor to cleaning.</p>	<p>FCC STATEMENT</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:</p> <ul style="list-style-type: none">Reorient or relocate the Rocksteady XS.Increase the separation between the Rocksteady XS and the receiver.Connect the Rocksteady XS into an outlet on a circuit different from that to which the receiver is connected.Consult the dealer or an experienced radio /TV technician for help.	<p>FCC NOTICE: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none">This device may not cause harmful interference, andThis device must accept any interference received, including interference that may cause undesired operation. <p>FCC CAUTION</p> <ul style="list-style-type: none">Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. <p>FCC ID:</p> <p>To locate the FCC identification number, please look underneath the battery of the Rocksteady XS.</p> <p>Limited 90 Day Warranty</p>	<p>Killer Concepts, LLC, warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase.</p> <p>All service and warranty requests must be made by contacting Killer Concepts, LLC:</p> <p>Email support@killerc.com to obtain a RMA number</p> <p>Disclaimer of Warranty.</p> <p>NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.</p> <p>This warranty is valid only in the United States of America and Canada and does not extend to owners of the product other than to the original purchaser. In no event will Killer Concepts, LLC or any of its affiliates, contractors, resellers, their</p>	<p>officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.</p> <p>Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your Killer Concepts, LLC product.</p> <p>Questions?</p> <p>Visit www.killerc.com</p>
--	---	--	--	--

6

7

8

9

10