US F17 FL 5F63EA7 IM (size: A4 x 2 pp.) 1C BK

ENG



CAUTION-ELECTRIC TOY: Not recommended for children under 8 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock. CAUTION-SUPERVISION REQUIRED-ELECTRIC TOY ELECTRIC TOY-UNPLUG WHEN NOT IN USE. INPUT: 100-240VAC-50/60Hz- MAX 0.2A OUTPUT: 6.4VDC = 600mA

Contents

-RC Vehicle x 1
-RC Transmitter x 1
-Instruction Manual x 1
-6.4V Rechargeable
Battery Pack x 1
-Charger x 1
-9V Battery x 1







- Battery Precaution

 1. The 6.4V LiNium Rechargeable Battery Pack must be charged before use by wildling the bettery charger which included

 2. Do not overcharge the battery pack, Do not charge for more than 6 hours

 3. Do not charge the battery pack if it shows leakage, corrosion, or has bose or

Battery Installation

For Vehicle (Fig. 1 and Fig. 2)





- . Connect the 6.4V lithium rechangeable better peak to the street of refer Verhale.
 . Plug the charger into the standard AC socket.
 . Plug the charger into the standard AC socket.
 . The charging lite for a full charge is about 3 hours.
 . When charging lite for a full charge is about 3 hours.
 . When charging lite completed, unplug the charger from the AC socket.
 Disconnect the rechangeable battery outs from the battery charger one. Red LED indicates the battery is charging, When LED turns green char is complete.

For Transmitter (Fig. 3 and Fig. 4)





How To Play











