



Package Contents

Wireless Speaker x 1pc
Micro USB Charging Cable x 1pc
Instruction Manual x 1pct

Power On/Off

1. Long press the switch key, the product is turned on.
2. The middle button is to adjust the time, consecutive press 2 times, enter the clock adjustment mode, then press the button one time, the number will change. Consecutive press twice, enter the minute adjustment mode, then press the button one time, the number will change.
3. The button on the right is used to set the alarm clock. Consecutive press 2 times, enter the alarm setting mode, then press the button one time, the number will change. Set the alarm that you want.

Pair wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
2. Power on the wireless speaker.
3. Activate the Bluetooth function on your phone within range and select " Vivitar VCB60015BT " from the list shown.
4. You will hear a beep sound when pairing is successful.

Charging your wireless speaker

1. Use the Micro USB cable provided with this wireless speaker.
2. Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
3. The LED Indicator light will turn red while charging and will turn off once fully charged.

NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth speaker if it has been not used for more than 12 months.

Technical specification

Driver Diameter: ----- 40 mm
 Impedance: ----- 4 Ohms
 Frequency Response: ----- 20Hz - 20KHz
 Battery Capacity: ----- 300 mAh
 Battery Type: ----- Lithium Battery 3.7V
 Charging time: ----- 1-2 Hours
 Playing time: ----- 1-2 Hours
 Bluetooth Range: ----- 32.8 Feet
 Bluetooth Version: ----- 4.2

FAQ

- ◆ **If the wireless speaker cannot be paired with your device, please try the following:**
 Ensure that your speaker is in pairing mode or reconnection mode.
 Ensure that Bluetooth search function of your mobile device is activated.
- ◆ **If the wireless speaker cannot be recharged:**
 If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

⚠ Safety instructions for the lithium battery and charging the product

- The input voltage to the product is 5V 1A.
- In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/104 deg °F.
- Do not heat above 70 deg °C/158 deg °F, eg. Do not expose to sunlight or throw into fire.
- Switch off the product after use.
- Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.